# **Sentilo Documentation**

Release 2.0.0

**Sentilo** 

# Contents

1	Setup	3
2	Quickstart	17
3	API Docs	19
4	Architecture	79
5	Integrations	87
6	Catalog and Maps	101
7	Multi Tenant	163
8	Tutorials	177
9	Technical FAQ	211
10	Platform Testing	215
11	Sentilo Official Docker Images	219

Contents:

Contents 1

2 Contents

# CHAPTER 1

Setup

This guide describes how to: **download, configure, compile and install the last version of Sentilo in your own runtime environment**. Moreover, it details which are the infrastructure elements necessary for running Sentilo and how should be their default configuration settings. It's assumed you have the skills to configure and install the necessary software base(Operating System, Maven, JDK, Mongo DB, Redis, etc).

The main topics are:

- Prerequisites: describes the software elements that have to be installed before download the code.
- **Download and build**: explains the steps to obtain the Sentilo code, to adapt it and how to build the platform artifacts.
- **Platform infrastructure**: describes the mandatory infrastructure components for running Sentilo and its default configuration settings.
- Deploy the artifacts: describes the necessary steps to deploy all the Sentilo modules

# 1.1 Prerequisites

Sentilo uses Maven as a mechanism for building and managing the dependencies of the platform. In order to build **Sentilo**, it is necessary to ensure the next set of prerequisites:

- JDK 1.8.x +
- Git (optional)
- Maven 3 +
- Ensure that the the Java SDK and Maven executables are accessible using your PATH environment variable.

## 1.2 Download and build code

The Sentilo code must be downloaded from Github. Once downloaded, you can build it using a script named *build-Sentilo.sh* which constructs the Sentilo artifacts "out-of-the-box".

#### 1.2.1 Download the source code from Github

The source code of the project can be obtained from git, cloning the remote project in a local directory named sentilo:

```
git clone https://github.com/sentilo/sentilo.git sentilo
```

An alternative method is to download a ZIP file from github repository and decompress it in a folder named sentilo:

https://github.com/sentilo/sentilo/archive/master.zip

In both cases, we will finally have a new directory named *sentilo* with the source code.

# 1.3 Compiling and build artifacts

## 1.3.1 Without changing the default configuration

If you want to build Sentilo out-of-the-box (i.e. build all artifacts that define the Sentilo platform without changing any of the default settings that are defined), we distribute a script named ./scripts/buildSentilo.sh which can be used to build Sentilo from the command line.

This script compiles the code and build the artifacts from scratch, but it doesn't deploy them in the execution environments. This process must be done manually by different reasons, for example:

- The deployment environment could be distributed in different servers. In example, Tomcat server and Pub/Subscribe server.
- it's not required to install all the components, like the relational database agent.

Once this script is executed, the result of the construction of the artifacts will be located, by default, in the directory ../sentilo-deploy-artifacts (local from current directory).

The content of the sentilo-deploy-artifacts directory will be:

- conf: contains all the Sentilo configuration files, both for the service, the catalog application and for all the agents
- sentilo-agent-activity-monitor: contains the directory structure resulting from running mynappassembler:assemble on the sentilo-agent-activity-monitor module
- sentilo-agent-alert: contains the directory structure resulting from running mvn appassembler:assemble on the sentilo-agent-alert module
- **sentilo-agent-federation:** contains the directory structure resulting from running mvn appassembler: assemble on the *sentilo-agent-federation* module
- sentilo-agent-historian: contains the directory structure resulting from running mvn appassembler:assemble on the sentilo-agent-historian module
- sentilo-agent-kafka: contains the directory structure resulting from running mvn appassembler:assemble on the sentilo-agent-kafka module
- **sentilo-agent-location-updater:** contains the directory structure resulting from running mynappassembler: assemble on the *sentilo-agent-location-updater* module

- **sentilo-agent-metrics-monitor:** contains the directory structure resulting from running mynappassembler: assemble on the *sentilo-agent-metrics-monitor* module
- sentilo-agent-relational: contains the directory structure resulting from running mvn appassembler:assemble on the sentilo-agent-relational module
- sentilo-catalog-web: contains the war of the web application once packaged
- sentilo-platform-server: contains the directory structure resulting from running mynappassembler:assemble on the sentilo-platform-server module

## 1.3.2 Changing default settings

If you want modify the code before to build it, you should import it into an Eclipse workspace with maven plug-in installed. Below we explain how to do it by using the M2E plugin.

- Open the Eclipse workspace to import the code:
  - Go to File> Import> Existing Maven Projects
  - Select ./sentilo as the root directory
  - Select all projects and import

Warning: be sure that JDK 1.8, or later, is correctly configured in your Eclipse environment.

After modifying the code, to compile and build the artifacts, our recommendation is to use the above mentioned buildSentilo.sh script.

## 1.4 Platform infrastructure

Before describing how to install all the Sentilo components, we're going to explain how to configure each element of the infrastructure.

Sentilo uses the following infrastructure elements (they are grouped into two categories):

- Mandatory
  - Redis 6.2.2
  - MongoDB 4.4.2
  - Tomcat 8.5.32 +
- Optional
  - MySQL 5.5.x (Sentilo has been tested on MySQL 5.5.34 but you could use your favourite RDBMS) It is
     only necessary if you want to install the relational agent
  - Elasticsearch 6+ It is only necessary if you want to install the activity-monitor agent.
  - openTSDB 2.2.0 + It is only necessary if you want to install the historian agent

You must ensure that you have all these elements installed properly (you can find information on how to install them in each provider site).

Below we explain the default settings for each Sentilo module.

## 1.4.1 Default settings

Sentilo configuration uses the Spring and Maven profiles to allow its customization depending on the runtime environment. By default, the platform comes with a predefined profile named **dev**, which considers that each of these infrastructure elements are installed on the same machine and listening in the following ports:

• Redis: 6379

• MongoDB: 27017

Tomcat: 8080MySQL: 3306

• Elasticsearch: 9200

• openTSDB: 4242

The default configuration for the entire platform is located in the file: /sentilo-common/src/main/resources/properties/sentilo.conf.


All other specific settings can be found in the subdirectory /src/main/resources/properties of each platform's module.

In general, Sentilo's configuration is described in the sentilo.conf file, while the rest of the components are described in their own .conf file.

The sentilo.conf file must be deployed in the default directory /etc/sentilo, in which the necessary parameters according to our installation must be overwritten later.

The other configuration files for agents, for example, can be overwritten in the same way, deploying them in the same directory specified above, and with the specific name set by each of the agents.

Therefore, we will have the files with the base configuration inside the package of each one of the modules (classpath) and the configuration files with the specific values displayed in the /etc/sentilo directory, which will overwrite the original ones. In this way, we can change any Sentilo parameterization just by modifying the deployed file and restarting the instance:



For example, here we can see a default configuration (first lines) and the overridden values for different execution environments for Redis host:

```
-- classpath:sentilo.conf
sentilo.version=2.1.0
sentilo.redis.host=127.0.0.1

-- /etc/sentilo/sentilo.conf for DSV environment
sentilo.redis.host=192.168.2.106

-- /etc/sentilo/sentilo.conf for PRE environment
sentilo.redis.host=10.65.124.22
```

 $\label{lem:configuration} Each \ module \ will \ define \ the \ location \ of \ its \ configuration \ file \ within \ the \ \texttt{xxx-properties-context.xml} \ file.$ 

For example, this is the case of the relational agent:

**Note:** The variable \${sentilo.conf.dir} is resolved in compilation time and its default value is /etc/sentilo

These are the default params for the **sentilo.conf** file:

Param	Default value	Description
sentilo.master.application.id	sentilo-catalog	Identification of the master application of the
sentilo.version	2.0.0-HA	Indicates the deployed version of Sentilo, and
sentilo.redis.password	sentilo	Redis access password (same value as the req
sentilo.redis.expire.key.seconds	0	Lifetime of data in Redis: after this time the d
sentilo.redis.connTimeout	5000(ms)	Timeout waiting in the execution of any reque
sentilo.redis.client.maxTotal	10	Maximum number of connections in the pool
sentilo.redis.client.maxIdle	10	Maximum number of idle connections in the
sentilo.redis.client.maxWaitMillis	-1	Maximum timeout (ms) for a new connection
sentilo.redis.client.testOnBorrow	true	Indicates whether to validate a connection fro
sentilo.redis.client.testOnCreate	true	Same as the previous one, but at the time of co
sentilo.redis.client.testOnReturn	false	Same as the previous one but when returning
sentilo.redis.client.testWhileIdle	true	Same as above but the validation is performed
sentilo.redis.host	127.0.0.1	IP of the machine where the Redis server is (i
sentilo.redis.port	6379	Port on which the Redis server is listening for
sentilo.redis.cluster.nodes	127.0.0.1:6379	List with the addresses (ip:port) of the different
sentilo.redis.cluster.maxRedirects	3	Maximum number of redirects to follow betw
sentilo.mongodb.host	127.0.0.1	IP of the machine on which the node with PR
sentilo.mongodb.port	27017	Port on which the MongoDB server is listening
sentilo.mongodb.database	sentilo	Name of the db to connect to
sentilo.mongodb.user	sentilo	User to use when authenticating to the Mongo
sentilo.mongodb.password	sentilo	Password to use when authenticating to the M
sentilo.mongodb.cluster-type	STANDALONE	Instance mode. Switch to REPLICA_SET in a
sentilo.mongodb.rs	rs_sentilo	Name of replica set in case of cluster
sentilo.mongodb.pool.max-connections	100	Maximum number of connections that can be
sentilo.mongodb.application-name	sentilo	Name of the module that establishes the conne
sentilo.catalog.rest.endpoint	http://127.0.0.1:8080/sentilo-catalog-web/	API URL Rest of the catalog (used internally
sentilo.catalog.rest.credentials	platform_user:sentilo	Credentials (user:password) to use in the auth
sentilo.api.rest.endpoint	127.0.0.1:8081	Sentilo Rest API URL (used internally by the
sentilo.api.rest.identity.key		Token to be used internally in calls to Sentilo'
sentilo.agent.pending_events_job.batch	50	Maximum size (N) of the batch of pending me
sentilo.agent.pending_events_job.delay	30000 (ms)	Waiting time between executions of the job th
sentilo.agent.batch.size	10	Batch size in which an agent processes incom
sentilo.agent.batch.workers.size.min	0	Minimum number of workers to be used by a
sentilo.agent.batch.workers.size.max	3	Maximum number of workers to be used by a
sentilo.agent.batch.max.retries	1	Number of retries an agent performs before re

## 1.4.2 Redis settings

Sentilo default settings consider Redis will be listening on port 6379, host 127.0.0.1, and with the parameter requirepass enabled and with value **sentilo**.

If you change this behaviour, you need to modify the sentilo.conf file, by editing following properties:

```
sentilo.redis.host=127.0.0.1
sentilo.redis.port=6379
sentilo.redis.password=sentilo
```

See other available Redis settings in above table, under *sentilo.redis.*\* base path.

## 1.4.3 MongoDB settings

Sentilo default settings consider MongoDB will be listening on 127.0.0.1:27017, and requires an existing database named *sentilo*, created before starting the platform, with authentication enabled and with login credentials preconfigured as sentilo/sentilo (username~:*sentilo*), password~:*sentilo*).

If you change this behaviour, you need to modify the *sentilo.conf* file, by editing following properties:

```
sentilo.mongodb.host=127.0.0.1
sentilo.mongodb.port=27017
sentilo.mongodb.user=sentilo
sentilo.mongodb.password=sentilo
```

See other available MongoDB settings in above table, under *sentilo.mongodb*.\* base path.

#### **Data load**

Moreover, you need to load on *sentilo* database the basic set of data needed to run the platform. The data include, among other things:

- An user **admin**: user for log in into the catalog webapp as administrator.
- An user **sadmin**: user for log in into the catalog webapp with role super-admin.
- An user **platform\_user**: internal user used by the platform to synchronize information between its components.

To do this, you must load the data defined in the file:

```
./scripts/mongodb/init_data.js
```

For example, in your MongoDB machine, you should execute the following command from the directory where the file is located:

```
mongo -u sentilo -p sentilo sentilo init_data.js
```

**Note:** The file init\_data.js contains default passwords and tokens (which are ok for run Sentilo in a test environment). In order to avoid compromising your platform, we recommend to change them before installing Sentilo in a production environment.

If you change default values in the /sentilo/scripts/mongodb/init\_data.js file and load them to MongoDB, you will have to modify the following properties, located in **sentilo.conf** file, and restart Sentilo. So, following JS code from <code>init\_data.js</code>:

Corresponds with:

```
sentilo.api.rest.identity.

key=c956c302086a042dd0426b4e62652273e05a6ce74d0b77f8b5602e0811025066
sentilo.catalog.rest.credentials=platform_user:sentilo
```

, being *sentilo.api.rest.identity.key* the token of a *sentilo-catalog* application, and *sentilo.catalog.rest.credentials* value is a combination of user *platform\_user* and it's password.

#### **Test data load**

In order to validate the correct installation of the platform, we could load a set of test data. These data includes, among other things: sensor types, component types, apps and providers.

These data is defined in the file:

```
./scripts/mongodb/init_test_data.js
```

and, as pointed above, you should run the following command to load it:

```
mongo -u sentilo -p sentilo sentilo init_test_data.js
```

## 1.4.4 MySQL settings

**Note:** This software is mandatory only if you want to export the published events to a relational database using the Relational Database Agent. Otherwise, you can skip this step. Please, check this out for more info.

Sentilo default settings consider MySQL server will be listening on 127.0.0.1:3306, and requires an existing database named *sentilo*, created before starting the platform, with authentication enabled and accessible using credentials *sentilo\_user/sentilo\_pwd* (username~:*sentilo\_user*, password~:*sentilo\_pwd*).

If you change this behaviour, you need to modify the following properties:

```
sentilo.agent.relational.ds.jdbc.driverClassName=com.mysql.jdbc.Driver
sentilo.agent.relational.ds.url=jdbc:mysql://127.0.0.1:3306/sentilo
sentilo.agent.relational.ds.username=sentilo_user
sentilo.agent.relational.ds.password=sentilo_pwd
```

configured in the file:

```
sentilo-agent-relational/src/main/resources/properties/sentilo-agent-relational.conf
```

#### Creating the tables

Once we have MySQL configured, and the database *sentilo* created, the next step is to create the database tables required to persist historical platform data.

At the following directory of your Sentilo installation:

```
sentilo-agent-relational/src/main/resources/bd
```

you'll find the script to create these tables.

## 1.4.5 Tomcat settings

Sentilo default settings consider Tomcat will be listening on 127.0.0.1:8080.

If you change this behaviour, you need to modify the following property:

```
sentilo.catalog.rest.endpoint=http://127.0.0.1:8080/sentilo-catalog-web/
```

configured in the sentilo.conf file.

Your Tomcat should also be started with the user timezone environment variable set as UTC. To set Timezone in Tomcat, the startup script (e.g. *catalina.sh* or *setup.sh*) must be modified to include the following code:

-Duser.timezone=UTC

## 1.4.6 API server (Subscription/publication) settings

Sentilo default settings consider subscription/publication server (a.k.a. *PubSub* server) will be listening on 127.0.0.1:8081

If you change this behaviour, you need to modify the following properties:

```
sentilo.api.rest.endpoint=127.0.0.1:8081
```

configured in the sentilo.conf file.

## 1.4.7 Configuring logs

Sentilo uses **slf4j** and **logback** as trace frameworks. The configuration can be found in **logback.xml** file, located in the subdirectory **src/main/resources** of sentilo-common module of the platform.

By default, all platform logs are stored in the directory /var/log/sentilo

## 1.5 Platform installation

Once you have downloaded the code and you have modify, compile and built it, the next step is to deploy Sentilo artifacts. The platform has five artifacts:

- Web Application Catalog (is mandatory)
- Server publication and subscription (is **mandatory**)
- Alarms agent is not strictly mandatory, however you'll need it if you want to provide alerts.
- Location updater agent is not strictly mandatory, however you'll need it if you want to update locations in case you have mobile components.
- All other agents (are **optional**):

## 1.5.1 Installing the Web App Catalog

After build Sentilo, to install the Web App, you just need to deploy the WAR artifact in your Tomcat server, i.e., copy the WAR artifact into the *webapps* subdirectory of your Tomcat server.

You will find the WAR artifact at the following subdirectory:

./sentilo-catalog-web/target/sentilo-catalog-web.war

## 1.5.2 Installing API server (subscription/publication)

After build Sentilo (see Compiling and build artifacts), to install the API (pub/sub) server, you need to follow the following steps:

- a. Into the directory ../sentilo-deploy-artifacts/sentilo-platform-server/ you'll find two subdirectories named repo and bin:
- repo directory contains all libraries needed to run the process
- **bin** directory contains the script (*sentilo-server*) needed to initialize the process (there are two scripts, one for Linux systems and one for Windows)
- b. Copy these two directories in the root directory where you want to install this component (for example: /opt/sentilo-server).
- c. Once copied, for starting the process you just need to run the script:

```
$ <path_to_sentilo-server>/bin/sentilo-server
```

## 1.5.3 Installing agents

As have been mentioned previously, all agents are optional and you are free to choose which of them will be deployed, depending on your specific needs. Agents are internal modules oriented to expand the platform functionality without having to alter its core. You will find more information about them in the Integrations section of our documentation.

The *buildSentilo.sh* script builds also all agents. If you decide to install some of them, you just have to copy the contents of the **sentilo-deploy-artifactts** agent's directory to the path you want the agent to be installed (see Compiling and build artifacts).

For example, *Alert agent* would be installed like this:

- a. In the directory ../sentilo-deploy-artifacts/sentilo-agent-alert/ you'll find two subdirectories named **repo** and **bin**:
- repo directory contains all libraries needed to run the process
- **bin** directory contains the script (*sentilo-agent-alert-server*) needed to initialize the process (there are two scripts, one for Linux systems and one for Windows)
- b. Copy these two directories in the root directory where you want to install this component (for example: /opt/sentilo-agent-alert).
- c. Once copied, for starting the process you just need to run the following script:

```
$ <path-to-agent-alert>/bin/sentilo-agent-alert-server
```

All other agents follow the exact same directory structure.

**Note:** Agent configuration can be done at any time by modifying it own **agent-xxx.conf** file and restarting it. It is documented in their respective page

## 1.6 Enable multi-tenant instance

In order to enable multi-tenant feature you need to ensure that your Sentilo version is at least 1.5.0. Otherwise you will have to upgrade your Sentilo instance.

Once the above requirement is fulfilled, you only need to do the following steps:

## 1.6.1 Modify your Tomcat startup script

You should modify your Tomcat startup script (e.g *%TOMCAT\_HOME%/bin/catalina.sh* or *%TOM-CAT\_HOME%/bin/setenv.sh*) to add a new JVM property:

```
-Dsentilo.multitenant=true
```

Once you have added the JVM property, you must restart your Tomcat server.

## 1.6.2 Edit the Catalog web.xml file

The next step is to edit the Catalog file web.xml located at:

```
sentilo-catalog-web/src/main/webapp/WEB-INF/web.xml
```

You will find some lines that are commented into this file which are needed to enable the multi-tenant feature. Therefore you should uncomment them:

```
< ! --
    <filter>
        <filter-name>UrlRewriteFilter</filter-name>
        <filter-class>org.tuckey.web.filters.urlrewrite.UrlRewriteFilter</filter-</pre>
⇔class>
        <init-param>
            <param-name>logLevel</param-name>
            <param-value>slf4j</param-value>
        </init-param>
    </filter>
    <filter>
        <filter-name>tenantInterceptorFilter</filter-name>
        <filter-class>org.sentilo.web.catalog.web.TenantInterceptorFilter</filter-</pre>
⇔class>
    </filter>
<!--
    <filter-mapping>
        <filter-name>tenantInterceptorFilter</filter-name>
        <url-pattern>/*</url-pattern>
        <dispatcher>REQUEST</dispatcher>
    </filter-mapping>
    <filter-mapping>
        <filter-name>UrlRewriteFilter</filter-name>
        <url-pattern>/*</url-pattern>
        <dispatcher>REQUEST</dispatcher>
        <dispatcher>FORWARD</dispatcher>
    </filter-mapping>
```

Once you have uncomment the above lines, you should recompile the Catalog webapp module and redeploy it into your Tomcat server.

You will find more information about this feature in the Multi-Tenant section of our documentation.

## 1.7 Enable anonymous access to REST API

By default, anonymous access to REST API is disabled, e.g. all requests to REST API must be identified with the identity\_key header.

Enabling anonymous access to the REST API means that only *authorized* data of your Sentilo instance can be accessed. Access to authorized data is described below.

In order to enable anonymous access you should modify the file **sentilo-platform/sentilo-platform-service/src/main/resources/properties/sentilo-platform.conf**:

```
# Properties to configure the anonymous access to Sentilo
sentilo.server.api.anonymous.enable=false
sentilo.server.api.anonymous.entity-id=
```

If anonymous access is enabled (*sentilo.server.api.anonymous.enable=true*), then all anonymous requests to REST API are internally considered as is they have been performed by the application client identified by the *sentilo.server.api.anonymous.entity-id* property value (this application client should exist into your Sentilo Catalog), and therefore these requests will have the same data restrictions as the requests performed by this client application.

## 1.8 Enable Cluster Mode

Since version 2.0, Sentilo offers the possibility of configuring the instance to work in **cluster mode**, thus favoring *high* availability (HA).

Since this mode substantially improves response times and overall performance of all platform components, it is highly recommended to configure production environments using this method.

Sentilo will improve its performance thanks to the particularity of the Redis Cluster mode, which improves the response times of the stored data, as well as a great improvement in its transmission, partly thanks to the use of *Redis streams*, also introduced in the version 2.0.

## 1.8.1 Requirements

To activate the cluster mode or high availability of Sentilo it is necessary to modify a specific parameterization that we will discuss below.

In addition, the use of the **Redis cluster mode is mandatory**.

If you want to have several instances of the API Server and/or the Catalog, you must have a *web balancer*, such as **NGINX**, to be able to balance the load of the servers

## 1.8.2 Configuration

Once we have all the requirements ready (especially the *Redis Cluster mode*), we must make the following modifications in the Sentilo configuration:

- File **sentilo.conf**: configure the parameters associated with the *Redis cluster* (sentilo.redis.cluster. nodes, see it at *Default settings*)
- For every Sentilo artifact startup scripts: add the JVM param -Dspring.profiles.active=cluster.

Once this is done, we can start our instance in high availability cluster mode normally.

# 1.9 What next?

Check the Quick Start Page or Platform Testing page.

1.9. What next?

# CHAPTER 2

Quickstart

# 2.1 Prerequisites

You should have 4 components up & running: - Redis Server - MongoDB - Sentilo API, running at http://127.0.0.1: 8081 - Sentilo Catalog, running at http://127.0.0.1:8080/sentilo-catalog-web

The installation covered by the section Sentilo Setup. (No need to setup any agents or other optional components such as Elasticsearch or OpenTSDB). Alternatively, you can use our VM.

# 2.2 Create a Provider, Component and a Sensor

In order to create a publication of sensor data, we have to create first the Provider, Component and a Sensor.

We'll do that from the catalog application as *admin user*, using the admin/1234 credentials.

A provider is an entity that manages devices (sensors). We'll have to create one from the menu "Providers" -> "New Provider"

A component is a device that contains one or more sensors (such as a Raspberry PI). We'll have to create one from the menu "Components" -> "New Component". Make sure you select the provider created above.

Finally, we'll have to create a sensor from the menu "Sensors" -> "New Sensor". Make sure you select the component created above. Please select a numeric type of sensor.

## 2.3 Publish an Observation

In order to publish an observation, we'll use Sentilo's HTTP REST API. For that you can use the curl program of some more graphical tool such as Postman:

```
curl -X PUT -H "IDENTITY_KEY: <your provider's token>" http://<your sentilo url>/data/

→<your provider>/<your sensor>/42.0
```

The server should respond with HTTP status 200.

# 2.4 Read your Observations

```
curl -X GET -H "IDENTITY_KEY: <YOUR_KEY>" http://<your sentilo url>/data/<your_

provider>/<your sensor>
```

The response would be similar to:

Also, on the "Latest Data" tab of the sensor's page in the catalog will appear your value, in this case, a 42.0.

## 2.5 What next?

Check the API documentation here.

**API Docs** 

Contents:

## 3.1 General Model

#### 3.1.1 Intro

#### Sentilo offers an open source API based on REST interfaces.

Representational State Transfer (REST) is a style of architecture that exploits existing technologies and protocols of the World Wide Web (WWW).

The communication from external elements with Sentilo will be through HTTP protocol (Hypertext Transfer Protocol).

Here, briefly describes the concepts of REST terminology that Sentilo will use:

- **Resources:** Elements of the information system.
- Identifiers: Unique name that identifies a resource within the system.
- Representations: Format of the exchanged data.
- Operations: Actions that can be performed on a resource.
- Response codes: Result of the operation.

## 3.1.2 Resources

Resources, or pieces of information of Sentilo Platform, are:

- Sensor: item of hardware or software with the ability to generate an observation(data).
- **Component**: corresponding to a element of hardware or software, with geospatial location (fixed or mobile) who could be composed by 1 or more Sensors.

- Provider: entity that represents a grup of components and allows them to communicate with Sentilo for sending data and receive commands.
- Client application / Module: entity that consumes the data processed by the platform.

The actions that can be carried out are:

- Applications / Modules
  - Register on the platform, but always from the administration console.
  - Send orders to providers/sensors (order service).
  - Receive data from provider/sensors (data service).
  - Subscribe to system events (subscribe service).

#### Providers / Sensors

- Register on the platform (catalog service).
- Subscribe to system events (subscribe service).
- Publish data (data service).

Sensors and components have always a an associated typology.

#### 3.1.3 Identifier

Unique name that identifies a resource in the system.

In the case of Sentilo, it is an **URLs** (Uniform Resource Locator).

The base URL is composed as follows:

```
protocol://domain:port/service
```

and consists of the following parts:

- communication protocols: HTTP or HTTPS.
- domain: Platform server API domain (e.g. localhost).
- port: Port defined for communications with the server API (e.g. 8081).
- service: catalog, data, order, etc..

Every service has a custom URL format as specified for each services.

## 3.1.4 Representations

Data formats that will supports the platform is currently only JSON.

Example data in JSON format:

## 3.1.5 Operators

The platform operators are the **HTTP protocol methods**.

In general, the operation associated with the operations used by Sentilo are:

• **GET**: Request information.

• POST: Send new data.

• PUT: Update existing data.

• DELETE: Erase data.

The platform discriminates the action you want perform from the method used and by the service, provider or sensor specified in the URL invoked.

## 3.1.6 Response

The response to a request to the platform is managed through the response HTTP status codes.

Error Code	HTTP	Description
200	Success	Request accepted and processed correctly
4xx	Client Error	Error in request (Wrong format, forbidden mandatory parameters,)
401	Unauthorized	Unauthorized request: empty or invalid credential
403	Forbidden	Not authorized for the requested action
404	Not Found	The requested entity does not exist
429	Too Many Requests	Global quota or entity quota exceed
5xx	Server Error	Error processing the request

In case of error the response body will include a description of the problem detected, as shown in the following examples:

This payload is returned when no credential is sent:

```
{"code":401, "message": "Invalid credential null"}
```

This payload is returned when JSON payload could not be read as JSON:

```
"code":400,
    "message":"SIE03-1398350628224 Bad request data: could not read JSON payload.

>Please review the following error and try again",
    "errorDetails": ["org.sentilo.common.exception.MessageNotReadableException:_
    Unexpected character ('o' (code 111)): ....."]
}
```

# 3.2 Security

## 3.2.1 Securing API requests

The platform will validate any request received by the system following the terminology AAA (*Authentication, Authorization, Accounting*):

• Authentication: Identifying who is doing the request.

3.2. Security 21

- Authorization: Validating that the action requested on the resource associated can be done.
- Traceability: Auditing the action and who has performed it.

So, for each request received, the platform performs the following actions:

- Identify the petitioner through the header HTTP.
- Check that it can do the requested action on the resource indicated.
- Register the performed action.

**Note:** Sentilo itself does not provide a mechanism to SSL/TLS http protocol (inbound https requests). That's because we don't need to duplicate the work of others - Sentilo is typically deployed behind a reverse proxy or an API manager, which already handle the encrypted connections very well.

#### **Authentication**

To identify the petitioner, the platform uses an authentication mechanism based on tokens (**Token Based Authentication**).

It's necessary to establish a distribution mechanism outside the platform for send the tokens among the different users of the platforms securely. Future versions of Sentilo will include this feature.

The token will be included in the request by adding a header with key IDENTITY\_KEY.

An example of a service request (GET in this case) using the curl tool:

```
curl --request GET --header "IDENTITY_KEY: <YOUR_KEY>" http://<your_api_server.com>/
```

In case of incorrect or invalid token, the platform will respond with an error code 401.

#### **Authorization**

To validate the requested action on the resource indicated in the request can be performed, the platform uses a permit system that checks authorized entity (provider or application) is allowed to admin, write or read in a resource.

These permissions are defined via the catalog console of the platform and, by default, every entity can be administrated by its owner.

If an action on a resource is done without the appropriate permission, platform will return an error 403.

## 3.2.2 Securing Callbacks

If it's necessary to secure the push requests sent by the platform, Sentilo provides a HMAC mechanism for the callbacks.

This mechanism guarantees that:

- the message was sent by the platform
- the message was not altered after being sent
- it was rend to a specific endpoint of the subscription

#### How does it work?

The data flow is the following:

- 0. Prerequisite: A Subscription is created via API with a secretCallbackKey. You may subscribe to any event type.
- 1. The data/alarm/command event is generated. How the event is created and by which entity is irrelevant.
- 2. If there is a Subscription with a secretCallbackKey for this event, the message will be signed and headers X-Sentilo-Content-Hmac and X-Sentilo-Date will be created.
- 3. The external system receives the subscription and may check its authenticity using a same secretCallbackKey.

The system uses the SHA-512 algorithm. It accepts keys of any size, and produces a hash sequence of length 512 bits.

The target system should activate the security for callbacks when creates the subscription specifying the secret key (see more). This subscription should be done using HTTPs protocol to avoid compromising the key.

After the subscription has been created, all the related requests will include two new headers, one with the hash (X-Sentilo-Content-Hmac) and another with the timestamp (X-Sentilo-Date), as the following sample shows:

```
X-Sentilo-Content-Hmac:
j10Q+fU667GQoHYHWzLBpigRjLJmRvYn53KHZhApTbrcphYWBlRPSBHkntODuqsqx11Vj8rsc7DDziiutTq/
$\iff 5g==
X-Sentilo-Date: 10/06/2019T15:27:22
```

The responsibility of validating the headers will be always in the target system who is receiving the messages.

#### **Code Samples**

A simple NodeJS example that would check the authenticity of the message would be:

```
const crypto = require('crypto');
const message = '{"message":"26", "timestamp":"03/12/2020T07:36:27", "topic":"/data/
→TITAN/TITAN-S01", "type": "DATA", "sensor": "TITAN-S01", "provider": "TITAN", "time
→":1606980987614,"publisher":"TITAN","publishedAt":1606980987614,"publisherTenant":"
→","tenant":"","sender":"TITAN"}'
const endpoint = 'http://my.endpoint.com:1880/sentilo';
const secretKey = 'my_super_secret_key';
const headerXSentiloDate = '03/12/2020T07:36:27';
const headerXSentiloContentHmacValue = 'elMiy5BDqDB68UVMonNDCc/BH8YrLWtCP6CdvlB4T//
→uI87JmMvx+epPUDy8E3Rg4UC2Bm21n4Zj/CLx0EcEZA==';
// Step 1 - hash the message and finally base64
let md5body = crypto.createHash('md5').update(message).digest('base64');
// Step 2 - concatenate all the necessary values
let values = ['POST', md5body, 'application/json', headerXSentiloDate, endpoint];
let contentToSign = values.join('\n');
// Step 3 - HMAC and and finally base64
let hmac = crypto.createHmac('sha512', secretKey);
hmac.update(contentToSign);
```

(continues on next page)

3.2. Security 23

(continued from previous page)

```
let result = hmac.digest('base64')

// Finally compare with the X-Sentilo-Content-Hmac header
console.log(result == headerXSentiloContentHmacValue);
```

Alternatively, another validation example in Java:

24

```
import javax.crypto.Mac;
import org.apache.commons.codec.binary.Base64;
import org.apache.commons.codec.digest.DigestUtils;
import org.apache.commons.codec.digest.HmacAlgorithms;
import org.apache.commons.codec.digest.HmacUtils;
public class HmacHeaderExample {
 public static void main(final String[] args) {
    // incoming message
    final String body =
        "{\"message\":\"26\",\"timestamp\":\"03/12/2020T07:36:27\",\"topic\":\"/data/
→TITAN/TITAN-S01\",\"type\":\"DATA\",\"sensor\":\"TITAN-S01\",\"provider\":\"TITAN\",
→\"time\":1606980987614,\"publisher\":\"TITAN\",\"publishedAt\":1606980987614,\
→"publisherTenant\":\"\",\"tenant\":\"\",\"sender\":\"TITAN\"}";
    // You're on this endpoint
   final String endpoint = "http://my.endpoint.com:1880/sentilo";
    // Same secret key as the secretCallbackKey in the subscription
   final String secretKey = "my_super_secret_key";
    // Value of X-Sentilo-Date
   final String headerXSentiloDate = "03/12/2020T07:36:27";
    // Value of X-Sentilo-Content-Hmac
    final String headerXSentiloContentHmacValue = "elMiy5BDgDB68UVMonNDCc/
→BH8YrLWtCP6CdvlB4T//uI87JmMvx+epPUDy8E3Rq4UC2Bm21n4Zj/CLxOEcEZA==";
      // Step 1 - hash the message and finally base64
      final byte[] md5BodyDigest = DigestUtils.md5(body);
      final String md5Body = new String(Base64.encodeBase64(md5BodyDigest));
     // Result expected: cIQCRRWeoOyQQLS8rlOtLQ==
      // Step 2 - concatenate all the necessary values
      final String[] values = {"POST", md5Body, "application/json",...
→headerXSentiloDate, endpoint};
      final String contentToSign = String.join("\n", values);
      // Result expected
     // POST
     // cIQCRRWeoOyQQLS8rlOtLQ==
      // application/json
      // 03/12/2020T07:36:27
      // http://my.endpoint.com:1880/sentilo
      // Step 3 - HMAC and and finally base64
      final Mac mac = HmacUtils.getInitializedMac(HmacAlgorithms.HMAC_SHA_512,...
⇔secretKey.getBytes());
      final byte[] rawHmac = mac.doFinal(contentToSign.getBytes());
```

(continues on next page)

(continued from previous page)

```
final String signature = new String(Base64.encodeBase64(rawHmac));

// Finally compare with the X-Sentilo-Content-Hmac header
System.out.println(signature.equals(headerXSentiloContentHmacValue));
}
```

# 3.3 Rate Limiting

Since v1.9, Sentilo offers rate limiting features for the REST API.

Rate limiting prevents the Sentilo instance from request flooding. Also, protects external systems that are subscribed to Sentilo by limiting outcoming requests.

## 3.3.1 Setting global limits

You can set global incoming quota sentilo.server.api.global\_rate\_limit.quota in file sentilo-platform/sentilo-platform-service/src/main/resources/properties/sentilo-platform.conf. If left unset or set to 0, Sentilo won't apply any global limit.

The maximum body length can also be set globally with sentilo.server.api.payload.max\_length property.

```
# number of requests per hour
sentilo.server.api.global_rate_limit.quota=100

# Maximum body length in bytes
sentilo.server.api.payload.max_length=4096
```

If global rate limiting is set, every response of the API contains following headers:

Header	Description
X-RateLimit-Global-	Value of the sentilo.server.api.global_rate_limit.quota property
Inbound-Limit	
X-RateLimit-Global-	Number of remaining requests until the current limit per hour is exceed
Inbound-Remaining	
X-RateLimit-Global-	If the API limit is exceeded, this value indicates the number of minutes until the
Inbound-Reset	server will accept requests again. Otherwise is 0.


In case the global rate limit is exceed, the server will reject the request and return a HTTP error code 429.

In case the maximum payload size is exceed, the server responses with HTTP error code 400.

## 3.3.2 Limit requests by entity

A provider or an application can have particular limits, which can be configured in catalogue:

3.3. Rate Limiting 25



If input quota for a entity is different from 0, every response of the API contains following headers:

Header	Description
X-RateLimit-Inbound-	Value of the input quota
Limit	
X-RateLimit-Inbound-	Number of remaining requests until the current limit per hour is exceed
Remaining	
X-RateLimit-Inbound-	If the entity quota is exceeded, this value indicates the number of minutes until entity
Reset	will be permitted again. Otherwise is 0.

If output quota for a entity is different from 0, every subscription request that Sentilo sends to the subscription endpoint will contain following headers:

Header	Description
X-RateLimit-	Value of the output quota
Outbound-Limit	
X-RateLimit-	Number of remaining requests until the current limit per hour is exceed
Outbound-Remaining	
X-RateLimit-	This value indicates the number of minutes until the counter of remaining outgoing re-
Outbound-Reset	quests of the entity will be reset. Otherwise is 0.

For example, consider that the subscribed system receives a message, together with these headers:

• X-RateLimit-Outbound-Limit: 5

• X-RateLimit-Outbound-Remaining: 1

• X-RateLimit-Outbound-Reset: 58

We can see that this entity that is subscribed to Sentilo data has a output quota set to 5 notifications/hour, that it can still receive 1 more notification and that the current window is still valid during next 58 minutes.

As with the global limit, if the entity's input quota is exceed, the server will reject the request and return a HTTP error code 429. Global rate limit is prevalent to entity's quota, so the request is rejected when the lowest of the two is met.

# 3.4 Monitor API (Beta)

Since v1.9, Sentilo offers an internal Monitor API that enables direct access to select real-time information of the API server and other components. With this internal API you can also remotely restart API server, for example in case the main API is too busy.

The Monitor API runs on a different port then public API. The default port number is 7081 and is configured in /sentilo-platform/sentilo-platform-service/src/main/resources/properties/sentilo-platform.conf by property sentilo.server.monitor.socket.port:

sentilo.server.monitor.socket.port=7081

This API currently works with the Catalog Application token. You can find the catalog token in the Application section of the Catalog.

**Note:** The catalog application token is very sensitive information, since it is used for admin operations. Make sure you do store it in a private repository. Also make sure calls to the monitoring API are encrypted. See more in the Security section

List of API resources in the monitoring API:

Resource	Method	Description
/monitor/ping	GET	Simple service that responds with http code 200 if the server is up and run-
		ning.
/moni-	GET	Returns values of global rate limiting (incoming requests), for the last hour.
tor/rl_input_status		
/monitor/metrics	GET	Returns a list of components with their metrics
/monitor/restart	POST	Gracefully restarts the API server. No body needed.
/monitor/force-restart	POST	Forces a restart of the API server. No body needed.

## 3.5 Services

Index of different services.

### 3.5.1 Alarm

#### **Publish Alarm**

#### **Description**

This action allows you to publish an alarm related with an alert. Once the system receives the alarm, persists it and sends the notification to all who are subscribed to alarms alert.

http://<your\_api\_server.com>/alarm/<alert\_id>

Formats	json
Method	PUT
Permission	Writing
Return	No additional data is returned

#### **Parameters**

Each alarm will have its own associated information structure defined in the generic format (JSON).

The platform only persists and transfers the information to recipients without interpreting its contents.

Key	Description	Optional
message	Free field	Not

### Response data

This actions does not return additional data beyond the HTTP status code associated with each request to the platform.

### **Examples**

#### Post a new alarm associated with an alert

The following example shows how to send a request to the platform in order to publish a new alarm associated to an alert with identifier 43:

http://<your\_api\_server.com>/alarm/43

and like body message:

{"message":"Threshold limit exceeded: 32"}

**Note:** If the alert is in offline state, the server rejects the publication.

#### **Retrieve alarms**

#### **Description**

This action allows to retrieve the latest alarms related with an alert. In addition, the service can also specify search criterias to retrieve alarms: filter by a given time period and/or indicate the maximum number of alarms to be retrieved.

http://<your\_api\_server.com>/alarm/<alarm\_id>?<parameter>=<value>

Format	json
Method	GET
Permission	Reading
Return	Alarms associated with the alert

#### **Parameters**

Key	Description	Optional
from	Indicates the starting of the time period for which you want to retrieve alarms.	Yes
to	Indicates the end of the time period for which you want to retrieve alarms	Yes
limit	Specifies the maximum number of alarms to recover.	Yes

Please note the following:

- The maximum number of records returned is defined in the platform configuration. If the limit parameter has a higher value than the configured one it will be dismissed.
- If limit parameter is not specified, it returns only one alarm.
- All dates must follow the format: dd/MM/yyyyTHH:mm:ss

#### Response data

In addition to the appropriate HTTP status code, if the operation runs properly, it will return the last alarms associated with the alert according to your search criteria.

Key	Description	Optional
alarms	Alarms list ( <i>message</i> ) of the alert	Not

Each alarm (message) will be composed by the following attributes:

Key	Description	Opcional
message	Message recorded when the alarm was fired	No
timestamp	The time in which system received the alarm (format dd/MM/yyyyTHH:mm:ss)	No
time	The time when the observation was made in milliseconds	No
sender	Identifier of the entity that issued the alarm	No

#### **Examples**

3.5. Services 29

#### Retrieve the last alarm

To retrieve the latest alarm for the alert with ID 43 we do the following request to the platform:

```
http://<your_api_server.com>/alarm/43
```

In the response we will receive:

#### **Recover N alarms**

To retrieve the last 3 alarms for the alert with id 43 we do the following request to the platform:

```
http://<your_api_server.com>/alarm/43?limit=3
```

In the response we will receive:

```
{"alarms":[
   {
        "message": "threshold exceeded: 34",
        "timestamp":"08/04/2013T09:44:01",
        "time":1510561800000,
        "sender": "appDemo"
    },
        "message": "threshold exceeded: 37",
        "timestamp": "08/04/2013T09:14:01",
        "time":1510561800001,
        "sender": "appDemo"
    },
        "message": "threshold exceeded: 38",
        "timestamp": "07/04/2013T23:23:10",
        "time":1510561800002,
        "sender": "appDemo"
    }
] }
```

#### Retrieve N alarms in a given period

If we want to retrieve the alarms according to a given period of time we should do the following request:

```
http://<your_api_server.com>/alarm/43?limit=3&from=08/04/2013T00:00:00&to=08/04/

$\to 2013T23:59:59$
```

In response the we will receive:

#### **Description**

The alarm service allows you to record and retrieve alarms associated with an alert stored in the system catalog.

All requests for this service will have the following format:

```
http://<your_api_server.com>/alarm/<id_alert>
```

where id\_alert identifies the alert for which you want to perform the action. The alert always should be defined before throwing the alarm using the Catalog or the through the Alert service.

#### **Actions**

The available actions for this service are:

- · Publish a new alarm associated with an alert
- Retrieve the latest alarms associated with an alert

### 3.5.2 Alert

#### **Create Alerts**

#### **Description**

This action allows to register one or more new alerts in the catalog.

http://<your\_api\_server.com>/catalog/alert/<entity\_id>

Formats	json
Method	POST
Permission	Writing
Returns	No output data

The internal alerts should be defined through the catalog console or by the API, but only using the catalog token.

3.5. Services 31

#### **Parameters**

Key	Description	Optional
alerts	Alerts list ( <i>alert</i> ) to register	Not

Every alert element has the following structure:

Key	Description	Optional
id	Alert ID to register	No
name	Alert name	Yes
description	Alert description	Yes
type	Alert type	No
trigger	Trigger type	Mandatory for internal, not applies for externals
expression	Expression to evaluate with the trigger	Mandatory for internal, not applies for externals
component	ID of the component to which the sensor belongs	Mandatory for internal, not applies for externals
sensor	ID of the sensor to which the alert applies	Mandatory for internal, not applies for externals
entity	Related entity identifier associated with the alert	Yes

Please, note the following observations:

- The ID must identify an univocal alert, e.g., 2 alerts may not have the same ID.
- The ID must have only alphanumeric (i.e. letters and numbers) and dashes characters, with no embedded spaces.
- The list of trigger's types and expressions are defined by the platform: Trigger types.
- The possible values for the alert types are: INTERNAL or EXTERNAL.
- Entity parameter is not mandatory, if empty the alert will be associated with the entity specified in the URL

## Response data

This action doesn't return additional data beyond the HTTP status code.

#### **Examples**

#### Adding one external alert

If rec entity wants to register a new custom external alert with REC\_ALERT\_001 identifier, to monitorize that maximum daily values for sensor REC\_001 ranged from 60 and 80, the request will be:

```
http://<your_api_server.com>/catalog/alert/rec
```

and in the body message:

This request will register a new external alert with ID REC\_ALERT\_001 and associated to rec entity (i.e. rec entity is who will publish alarms associated to this alert).

**Note:** External alerts are defined by third party entities(providers or applications), which will be the responsibles of calculating their logic and throw the related alarms when applies.

#### Adding one internal alert

If we want to register a new internal alert with ID REC\_GT\_45\_ALERT\_001, to monitorize that values for sensor's rec REC\_001 are greater than 45, the request to do is the following:

```
http://<your_api_server.com>/catalog/alert/rec
```

and in the body message:

This request will register a new internal alert with REC\_GT\_45\_ALERT\_001 identifier and associated to REC\_001 sensor which will publish an alarm when sensor value will be greater than 45.

This operation must be done using the catalog token.

### **Update Alerts**

#### **Description**

This action allows to update one or more alerts in the catalog.

```
http://<your_api_server.com>/catalog/alert/<entity_id>
```

Formats	json
Method	PUT
Permission	Writing
Returns	No output data

The internal alerts should be updated through the catalog console or by the API, but only using the catalog token.

#### **Parameters**

Key	Description	Optional
alerts	Alerts list (alert) to update	Not

Every alert element has the following structure:

Key	Description	Optional
id	Alert identifier to update	No
name	New alert name	Yes
description	New alert description	Yes
type	Alert type	No
trigger	New trigger type	Mandatory for internal, not applies for externals
expression	New expression to evaluate with the trigger	Mandatory for internal, not applies for externals

Please, note the following observations:

- The list of trigger's types and expressions are defined in: Trigger types.
- The possible values for the alert type are: INTERNAL or EXTERNAL.

### Response data

This action doesn't return additional data beyond the HTTP status code.

#### **Examples**

### Update one external alert

If rec entity wants to update the external alert with REC\_ALERT\_001 identifier to modify its name, the request to do will be:

```
http://<your_api_server.com>/catalog/alert/rec
```

and in the body message:

This request will update the external alert with REC\_ALERT\_001 identifier updating its name to REC\_EXTERNAL\_ALERT\_001.

**Note:** External alerts are defined by third party entities(providers or applications), which will be the responsibles of calculating their logic and throw the related alarms when applies.

### Update one internal alert

If we want to update the internal alert with REC\_GT\_45\_ALERT\_001 identifier to change its description, the request will be:

```
http://<your_api_server.com>/catalog/alert/rec
```

and in the body message:

```
{"alerts":[
    {"id":"REC_GT_45_ALERT_001",
        "type":"INTERNAL",
        "description":"New description"
    }
]}
```

This request will update the description of the internal alert with REC\_GT\_45\_ALERT\_001 identifier changing its value to "New description".

This operation must be done using the catalog token.

#### **Retrieve Authorized Alerts**

### **Description**

This action returns the list of alerts for which the entity\_id could do a subscription, i.e., alerts that belongs to entity\_id or alerts for which entity\_id has read permission over its owner. In addition, the service also allows you to specify search criteria to filter alerts to be retrieved: filter by alert type and / or filter by trigger type.

```
http://<your_api_server.com>/catalog/alert/<entity_id>?<parameter>=<value>
```

The entity\_id is optional and can be an Application or a Provider.

Format	json
Method	GET
Permission	Reading
Return	List of authorized alerts

#### **Parameters**

Key	Description	Optional
type	Alert's type filter	Yes
trigger	Trigger's type filter	Yes

Please, note the following observations:

- The list of trigger's types available are defined by the platform: Trigger types.
- The possible values for the alert type is also defined by the platform and are: INTERNAL, EXTERNAL.

#### Response data

As commented before, this action, in addition to the HTTP status code, returns the list of alerts for which entity\_id has at least read permission.

Key	Description	Optional	
alerts	Alerts list (alert)	Not	

Every alert element has the following structure:

Key	Description	Optional
id	Alert ID	No
name	Alert name	Yes
description	Alert description	Yes
entity	Related entity	No
type	Alert type	No
trigger	Trigger type	No, but only returned for internal alerts
expression	Expression to evaluate with the trigger	No, but only returned for internal alerts
component	Component identifier to which the sensor belongs	No, but only returned for internal alerts
sensor	Sensor identifier to which the alert applies	No, but only returned for internal alerts

## **Examples**

## Request to retrieve all the authorized alerts

The following request shows an example to retrieve all the authorized alerts for rec entity:

```
http://<your_api_server.com>/catalog/alert/rec
```

and the response will be:

```
"alerts" : [
      "id" : "REC_ALERT_001",
     "name" : "REC_ALERT_001",
     "description" : "Custom alert to monitorize that maximum daily values for
⇒sensor REC_001 ranged from 60 and 80",
     "entity" : "SAMCLA",
      "type" : "EXTERNAL"
   },
      "id" : "REC_ALERT_002",
     "name" : "REC_ALERT_002",
     "description" : "Internal alert to check if S00020114-0 value is greater than 45
     "entity" : "SAMCLA",
"type" : "INTERNAL",
      "trigger" : "GT",
      "expression" : "45",
      "component" : "S00020114",
      "sensor" : "S00020114-0"
```

(continues on next page)

(continued from previous page)

```
}
]
}
```

## Request to retrieve all the authorized alerts filtered by type and trigger

The following request shows an example to retrieve all internal alerts for rec entity with trigger type equal to GT.

```
http://<your_api_server.com>/catalog/alert/rec?type=INTERNAL&trigger=GT
```

and the response will be:

#### Remove alerts

## **Description**

This action allows to delete alerts from the catalog. The internal alerts can only be deleted using the Catalog's token or through the Catalog console. The external alerts can only be removed using the entity's owner token.

```
http://<your_api_server.com>/catalog/alert/<entity_id>
```

**Note:** entity\_id can be also an Application or a Provider too.

Format	json
Method	DELETE, PUT
Permission	Writing
Return	No output data

Note that this action can be invoked using two HTTP methods: PUT and DELETE.

- DELETE will be used if we want to delete all of our alerts. It cannot contain any body content.
- PUT will be used when we want to delete a group of alerts. We should add the parameter method with delete value to the request . In this case, the alerts to delete should be specified in the body message.

#### **Parameters**

The structure of input message if we want to delete a group is:

Key	Description	Optional
alertsIds	Array of the alerts identifiers to delete	Yes

Each element of the list corresponds to an identifier to an alert to delete.

#### Response data

This action does not return additional data beyond the HTTP status code.

### **Examples**

#### Request to delete all alerts

If the entity rec wants to delete all its alerts, the request will be:

```
DELETE http://<your_api_server.com>/catalog/alert/rec
```

This action will delete all the external alerts belonging to entity rec. Be careful, if this request is done using the catalog token, it will remove all the internal alerts!.

#### Request to delete a set of alerts

If the entity rec only wants to delete a set of alerts, the request will be:

```
PUT http://<your_api_server.com>/catalog/alert/rec?method=delete
```

and in the body message:

```
{"alertsIds":["REC-ALERT-01","REC-ALERT-02"]}
```

### **Description**

The alert service provides methods to record, edit or retrieve alerts definition.

All requests for this service will have the following format:

```
http://<your_api_server.com>/catalog/alert/<entity_id>
```

where entity\_id is optional and should be included depending on the operation. entity\_id can be an Application or a Provider.

There are two alert types: internal and external.

The internal alerts are related to specific sensors and its logic is defined using basic math rules or configuring an inactivity time. They should be defined through the catalog console or by the API, but only using the catalog token.

The related alarms are triggered always by the Sentilo platform when the alert logic occurs.

The external alerts are defined by third party entities, which will be the responsibles of calculating their logic and throw the related alarms when applies.

For both cases, the Sentilo platform is responsible of publishing the alarm for all entities subscribed to the related alert.

#### **Actions**

### The available actions for this service are:

- · Adding alerts
- Update alerts
- Retrieve list of authorized alerts
- Remove alerts

### Internal trigger types

The list of trigger types accepted by Sentilo (and their associated expressions) are:

ld	Description	Expression value
GT	Greater than <i><expression></expression></i>	Any numerical value
GTE	Greater than or equal <i><expression></expression></i>	Any numerical value
LT	Less than <i><expression></expression></i>	Any numerical value
LTE	Less than or equal <i><expression></expression></i>	Any numerical value
EQ	Equal <expression></expression>	Any value
CHANGE	Any change	Not apply here
CHANGE_DELTA	Any variation greater to delta <i><expression></expression></i>	Any numerical value between 0 and 100
FROZEN	No data received in <i><expression< i="">&gt;minut es</expression<></i>	Any numerical value

The trigger types only apply for the internal alerts.

# 3.5.3 Catalog

## Adding sensors or components to the catalog

## **Description**

This action allows the provider to register one or more sensors / components in the catalog.

http://<your\_api\_server.com>/catalog/<provider\_id>

Formats	json
Method	POST
Permission	Writing
Returns	No output data

#### **Parameters**

Key	Description	Op-
•		tional
sensor	Sensor ID to register	No
description	Sensor description	Yes
type	Sensor type	No
dataType	Sensor data types	Yes
unit	Unit of measure	Yes
component	Component identifier to which the sensor belongs	Yes
componentType	Component type	Yes
componentDesc	Component description	Yes
location	Location/s of the component to which the sensor is	Yes
timeZone	TimeZone used by sensor observations when it is different to UTC	Yes
publicAccess	Visualization check for the sensor in the public zone	Yes
componentPubli-	Visualization check for the component in the public zone	Yes
cAccess		
additionalInfo	Additional params related to the sensor	Yes
componentAddi-	Additional params related to the component	Yes
tionalInfo		
technicalDetails	Technical params related to the sensor	Yes
componentTechni-	Technical params related to the component	Yes
calDetails		
ttl	Time in minutes when sensor data will expire. If not set, the value of redis.	Yes
	expire.data.seconds will be applied.	
state	State of the sensor, either online or offline	Yes

#### Please, note the following observations:

- The state and substate of a sensor cannot be changed via te API, only from the catalog. The default value for state is 'online', default value for substate is empty.
- The identifier must identify an univocal sensor provider, e.g., 2 sensors of the same provider may not have the same ID.
- The identifier must have only alphanumeric (i.e.letters and numbers), undescores and hyphens characters, with no embedded spaces.
- The list of sensor's types are configured in the platform through the catalog web app. If you need a new one, it must be added using the administration.
- The possible values for the data type of the sensor is also defined in the platform configuration. The possible values are: number, text or boolean. The default value is number.
- If the attribute component is not passed as a parameter, the platform itself will create a catalog component with the same name as the sensor (if it does not already exist).
- If the attribute componentType is not reported and the component does not already exists in the system, the component will be defined as a generic component type.
- If the location attribute is not reported, the component is defined as a mobile type (with no fixed location). Otherwise it will be defined as static and set its location with the coordinates provided. If the element has several locations they should be informed separated by comma character.
- If the attribute type and / or componentType values are not configured in the catalog, the system will return a 400 error indicating that the parameters received are invalid.

- publicAccess param refers to the sensor's visibility in the sensor's public page. Default value is false.
- componentPublicAccess param refers to the components's visibility in the public map. Default value is false.
- additionalInfo param is a <key,value> map that allows to store additional sensor information not mapped to any specific parameter. The information of this data map must not follow any internal rule.
- componentAdditionalInfo param is a <key,value> map that allows to store additional component not mapped to any specific parameter. The information of this data map must not follow any internal rule.
- technicalDetails parameter is a <key,value> map that allows to store additional sensor information. The available keys and their possible values are:

Descrip-	Key	Values
tion		
Producer	producer	not restricted
Model	model	not restricted
Serial	serial-	not restricted
number	Number	
Energy	energy	220VAC (electric network), 12_24_VDC (PoE), 185_230_V (lighting network),
		AUT_BAT (battery), SOLAR_BAT (solar battery)

### Response data

This action doesn't return additional data beyond the HTTP status code associated with each request to the platform.

### **Examples**

#### Adding one sensor

If you want to register a new humidity sensor with RE0025 identifier associated with the component whose identifier is METEO-1 of rec provider, the request to do will be the following:

```
http://<your_api_server.com>/catalog/rec
```

and in the body message:

This request will register a new sensor with name METEO\_HUM-1 in the system of humidity type. Additionally, this sensor will be associated with the component METEO-1. If the component does not exist in the system yet, will be registered with the properties defined in the request (componentType, componentDesc and location).

### Adding several sensors

In case it is necessary to add a set of sensors, the request will be very similar to the previous one, modifying the message body:

```
http://<your_api_server.com>/catalog/rec
```

#### in the body message

```
{"sensors":[
   {"sensor":"tt01_REC013",
    "description": "sensor12",
    "type": "humidity",
    "dataType": "number",
    "unit": "grams",
    "component": "METEO-1",
    "componentType": "meteo",
    "location": "41.39479 2.148768"
   },
   {"sensor":"tt01_REC014",
    "description": "sensor12",
    "type": "humidity",
    "dataType": "number",
    "unit": "grams",
    "component": "METEO-1",
    "componentType": "estaciometeo",
    "location": "41.39479 2.148768"
] }
```

In this case, instead of registering a single sensor, there will be added two new sensors associated with the component named METEO-1. If the component does not yet exist in the system, will be registered with the properties specified in the request (type and location).

#### Adding one sensor with additional info

If you want to register a new humidity sensor, as in the first example, but also need additional information for the sensor and its component, the request to do is the following:

```
http://<your_api_server.com>/catalog/rec
```

#### and in the body message:

(continues on next page)

(continued from previous page)

```
"componentAdditionalInfo":{"altitude":"525 m."}
}
]}
```

This request will register a new sensor with name METEO\_HUM-1 in the system of humidity type, as in the first example, and stores with the sensor two new attributes: accuracy and voltage.

### Update data of a component / sensor

## **Description**

This action permits to update the catalog information related to components and/or sensors of a provider.

```
http://<your_api_server.com>/catalog/<provider_id>
```

Format	json
Method	PUT
Permission	Writing
Return	No output data

#### **Parameters**

The structure of the input parameters depends on what we want to modify, sensor or component data.

The following describes the structure of the input parameters in each case:

### **Update components**

Key	Description	Optional
components	Components list (component) to update	Yes

Each element **component** has the following structure:

Key	Description	Optional
component	Component ID to update	No
componentType	Component type	Yes
componentDesc	Component description	Yes
location	Component location/s	Yes
componentPublicAccess	Visualization check for the public area	Yes
componentAdditionalInfo	Additional params	Yes
componentTechnicalDetails	Technical params	Yes

The constraints and validation for the parameters are the same as described in Adding sensors or components.

### **Update sensors**

Key	Description	Optional
sensors	Sensors list (sensor) to update	Yes

Each **sensor** element has the following structure:

Key	Description	Ор-
		tional
sensor	Sensor ID to update	No
description	Sensor description	Yes
type	Sensor type	Yes
dataType	Data type of the sensor	Yes
unit	Measurement unit	Yes
publicAc-	Visualization check for the public area	Yes
cess		
additional-	Additional params	Yes
Info		
techni-	Technical params	Yes
calDetails		
ttl	Time in minutes when sensor data will expire. If not set, the value of redis.expire.	Yes
	data.seconds will be applied.	
state	State of the sensor, either online or offline	Yes

The constraints and validation for the parameters are the same as described in Adding sensors or components.

#### Response data

This action doesn't return additional data beyond the HTTP status code.

## **Examples**

### Request to update the sensor data

If you want to modify the sensor's description fot the identifiers RE0012 and RE0013, from rec provider, the request will be:

```
http://<your_api_server.com>/catalog/rec
```

in the body message:

```
{"sensors":[
    {"sensor":"REC012","description":"sensor 12"},
    {"sensor":"REC013","description":"sensor 13"}
]}
```

This request will update the description of the sensors RE0012 and RE0013.

Note: If you need to move a sensor to another component, it should be done by deleting the sensor and creating it again in the other component.

## Request to update the component data

If we want to update component data of a provider, like update its location and additional info, the request will be:

```
http://<your_api_server.com>/catalog/rec
```

in the message body:

```
{"components":[
    {"component":"COMP-2","location":"41.4051143 2.1320120","componentAdditionalInfo":{
    →"altitude":"530 m."}}
]}
```

### Retrieve providers / sensors list

### **Description**

This resource returns a list of providers and sensors for which you have at least read permission. Sensors that are in the offline state won't be listed. In addition, the service provides optional filtering by sensor type, component type and component name.

```
http://<your_api_server.com>/catalog
```

Format	json
Method	GET
Permission	Reading
Return	List of providers, with their sensors, on which we has at least read permission

#### **Parameters**

Key	Description	Optional
type	Sensor's type filter	Yes
component	Component name filter	Yes
componentType	Component's type filter	Yes

## Response data

As mentioned, this action, in addition to the HTTP status code, returns the list of providers for wich we have at least read permission.

Key	Description	Optional
providers	Providers list (provider) with at least read permission	Not

Each provider will have the following structure:

Key	Description	Optional
provider	Provider ID	No
permission	Indicates whether it readable (R) or write (W) on the provider	No
sensors	Provider list of sensors (sensor)	No

Each list element (sensor) will have the following structure.

Key	Description	Optional
sensor	Sensor identifier	No
description	sensor description	Yes
dataType	Data sensor type:  • AUIDO_LINK • BOOLEAN • FILE_LINK • IMAGE_LINK • JSON • LINK • NUMBER • TEXT • VIDEO_LINK	No
location	Location where de sensor is	Yes
type	Sensor type	No
unit	Unities in the sensor data coming	Yes
timeZone	Sensor's timezone	Yes
publicAccess	Visualization check for the public area	Yes
component	Component is associated the sensor	No
componentType	Component type	No
componentDesc	Component description	Yes
componentPublicAccess	Visualization check for the public area	Yes
additionalInfo	Additional params related to the sensor	Yes
technicalDetails	Technical params related to the sensor	Yes
componentTechnicalDet ails	Technical params related to the component	Yes

## **Examples**

## Request to retrieve all Providers / Sensors

```
http://<your_api_server.com>/catalog
```

in the response we will receive

```
{
    "providers": [{
        "provider": "A",
        "permission": "WRITE",
        "sensors": [{
            "sensors": [{
                  "sensor": "MAR_01_00_SN001_1010",
                 "description": "Sound Sensor MODI 001",
                  "dataType": "NUMBER",
                  "type": "noise",
                  "unit": "dBa",
```

(continues on next page)

(continued from previous page)

```
"state": "online",
        "component": "MAR_01_00_SN001_1010",
        "componentType": "generic",
        "timeZone": "CET"
    } ]
}, {
    "provider": "C",
    "permission": "READ",
    "sensors": [{
        "sensor": "MAR_02_20_PM001_1010",
        "description": "PM10 Sensor IMI 001",
        "dataType": "NUMBER",
        "type": "air_quality_pm10",
        "unit": "ug/m3",
        "state": "online",
        "component": "air_quality",
        "componentType": "generic"
        "sensor": "MAR_02_20_PM001_1012",
        "description": "PM10 Sensor IMI 002",
        "dataType": "NUMBER",
        "type": "air_quality_pm10",
        "unit": "ug/m3",
        "state": "online",
        "component": "air_quality",
        "componentType": "generic",
        "additionalInfo": {
            "supportMail": "support@imi.com"
        "technicalDetails": {
            "producer": "xxxx",
            "model": "x-1",
            "serialNumber": "9999",
            "energy": "220VAC"
        },
        "componentTechnicalDetails": {
            "producer": "XXXX",
            "model": "X-1",
            "serialNumber": "9999",
            "macAddress": "00:17:4F:08:5F:61",
            "energy": "12 24 VDC",
            "connectivity": "WIFI"
    } ]
} ]
```

## Request to recover all the sensors in the catalog filtered by type

The request in this case is very similar to the previous one adding the type parameter:

```
http://<your_api_server.com>/catalog?type=air_quality_pm10
```

In this case as a response we will receive:

```
{"providers":[
    {
     "provider": "C", "permission": "READ",
     "sensors":
       "sensor": "MAR_02_20_PM001_1010",
       "description": "PM10 Sensor IMI 001",
       "dataType": "NUMBER",
       "type": "air_quality_pm10",
       "unit":"ug/m3",
       "component": "air_quality",
       "componentType":"generic"
      },{
       "sensor": "MAR_02_20_PM001_1012",
       "description": "PM10 Sensor IMI 002",
       "dataType": "NUMBER",
       "type": "air_quality_pm10",
       "unit":"ug/m3",
       "component": "air_quality",
       "componentType":"generic",
       "additionalInfo":{"field1":"value1", "field2":"value2"}
     ]
    }
] }
```

### Other examples

```
http://<your_api_server.com>/catalog?component=comp_demo&type=air_quality_pm10
```

http://<your\_api\_server.com>/catalog?componentType=air\_quality&type=air\_quality\_pm10

Note: Only sensors will "online" state are returned by the API.

### Delete components / sensors

### **Description**

This action allows the provider to delete catalog components and/or sensors.

WARNING: this operation performs a cascade delete and the execution of this action cannot be undone.

http://<your\_api\_server.com>/catalog/<provider\_id>?<parameter>=<value>

Format	json
Method	DELETE, PUT
Permission	Writing
Return	No output data

Note that his action can be invoked using two HTTP methods: PUT and DELETE.

- DELETE we be used to delete all the sensors and components of a provider. It cannot contain body content.
- PUT will be used to delete a group of sensors or components. We should add a the parameter method with delete value to the request. In this case, the sensors or components to delete should be specified in the body message.

#### **Parameters**

The structure of the input parameters depends on whether you want to delete components or sensors.

The following describes the structure of the input in each case:

#### **Delete components**

Key	Description	Optional
components	Array of component identifiers to delete	Yes

Each element of the list corresponds to an identifier of a component to delete.

#### **Delete sensors**

Key	Description	Optional
sensors	Array of sensor identifiers to delete	Yes

Each element of the list corresponds to an identifier of a sensor to delete.

### Response data

This action does not return additional data beyond the HTTP status code.

### **Examples**

### Request to delete all components and sensors of a provider

To delete all components and sensors belonging to the provider named rec the request to do is the following:

```
DELETE http://<your_api_server.com>/catalog/rec
```

This request will delete in the catalog all the components and sensors of the rec provider

## Request to delete a set of components of the catalog

To delete a set of components belonging to the provider rec the request to do is the following:

```
PUT http://<your_api_server.com>/catalog/rec?method=delete
```

in the body message:

```
{"components":["COMP-3", "COMP-4"]}
```

# Request to delete a set of sensors of the catalog

To delete a set of sensors belonging to the provider rec the request to do is the following:

```
PUT http://<your_api_server.com>/catalog/rec?method=delete
```

in the body message:

```
{"sensors":["RE001","RE002","RE003"]}
```

### **Description**

The catalog service allows to register or modify your own sensors/components or query the characteristics of a sensor or provider.

All requests for this service will have the following format:

```
http://<your_api_server.com>/catalog/<provider_id>
```

where provider\_id is optional and should be included depending on the operation.

#### **Actions**

The available actions for this service are:

- Adding components / sensors
- Update data components / sensors
- Retrieve list of providers / sensors
- Remove components / sensors

### **Component types**

The list of component types should be configured for each Sentilo instance, the following list could be used as a reference for any city:

ld	Name	Description
temperature	Temperature	Temperature measurement
noise	Soundmeter	Sound measurement
wind	Anemometer	Wind speed
humidity	Humidity	Humidity measurement
air_quality	Air Quality	Air Quality control
water_quality	Water Quality	Water Quality control
meteo	Meteorology	Weather Station
parking	Occupation parking	Parking control
luminosity	Luminosity	Luminosity measurement
glass_container	Occupancy container level	Glass occupancy container measurement

Continued on next page

Table 1 – continued from previous page

ld	Name	Description
paper_container	Occupancy container level	Paper occupancy container measurement
plastic_container	Occupancy container level	Plastic occupancy container measurement
organic_container	Occupancy container level	Organic occupancy container measurement
refuse_container	Occupancy container level	Refuse occupancy container measurement
container_volum	Occupancy container level	Generic occupancy container measurement
soil_moisture	Soil moisture	Soil moisture measurement
park_meter	Parking meter	Parking meter control
traffic	Traffic	Traffic measurement
people_flow	People flow	Pedestrian flow measurement
flowmeter	Water flow	Water flow measurement
solenoid_valve	Electrovalve	Solenoid control
salinity	Salinity	Soil salinity measurement
internal_ambient_cond itions	Internal Environmental Conditions	Temperature, humidity and luminosity measurement
external_ambient_cond itions	External environmental conditions	Temperature, humidity and luminosity measurement
network_analyzer	Network analyzer	Electric network analyzer
gas_meter	Gas meter	Gas consumption meter
electricity_meter	Electricity meter	Electricity consumption meter
water_meter	Water meter	Water consumption meter
soil_sensor	Soil sensor	Soil mesurement of salinity, mosture, etc
generic	Generic component type	Default component type if not specified
plugsense	Plug & Sense	Plug & Sense Libelium component

# Sensor types

The list of sensor types should be configured for each Sentilo instance, the following list could be used as a reference for any city:

ld	Name	Description
temperature	Temperature	Temperature measurement
noise	Soundmeter Class II	Sound level measuring class II.
noise_class_i	Soundmeter Class I	Sound level measuring class I
anemometer	Anemometer	Wind Speed measuring
humidity	Humidity	Humidity measuring
parking	Occupation parking	Occupation parking control
luminosity	Luminosity	Luminosity measuring
container_volum	Occupancy container level	Occupancy container measurement
container_overturn	Container overturned	Container overturned indicator
container_open	Container open	Container opening indicator
status	Sensor status	Status control
battery	Battery level	Battery level measurement
soil_moisture_15	Soil moisture 15 cm.	Soil moisture measurement
soil_moisture_35	Soil moisture 35 cm.	Soil moisture measurement
park_meter	Parking meter	Parking meter control
vehicle_volume	Number of vehicles	Measurement of number of vehicles
vehicle_occupation_av erage	Average occupancy	Measurement of average occupancy in vehicles
vehicle_speed	Speed Vehicle	Vehicle speed measurement
air_quality_no2	NO2	Nitrogen dioxide measurement
air_quality_pm10	PM10	Measurement of suspension particles PM10

Table 2 – continued from previous page

Id	Name	Description
air_quality_pm25	PM25	Measurement of supsension particles PM25
air_quality_o3	O3	Ozone measurement
air_quality_so2	SO2	Sulfur dioxide measurement
air_quality_co	CO	Carbon Monoxide measurement
air_quality_co2	CO2	Carbon dioxide measurement
people_flow	People flow	Measurement of pedestrian flow
flowmeter	Water flow	Water flow measurement
solenoid_valve	Electrovalve	Solenoid actuator
eto	Evotranspiration	Evotranspiration measurement
salinity	Salinity	Soil salinity measurement
pluviometer	Pluviometer	Rain measurement
rain	Rain gauge	Rain indicator (it's raining/it's not raining)
wind	Wind gauge	Wind indicator (>X m/s)
wind_direction_6_m	Wind direction	Wind direction at 6 meters
wind_direction_10_m	Wind direction  Wind direction	Wind direction at 0 meters  Wind direction at 10 meters
voltage	Voltmetre	Electrical voltage measurement. Units: volts (V)
current	Ammeter	Electrical intensity measurement. Units amps (A)
frequency	Frequencymeter	Electrical frequency measurement. Units: herzs (Hz)
active_power	Active power	Active power measurement. Units: kilowatts (kW)
reactive_power	Reactive power	Reactive power measurement. Units: reactive kilovoltiamperis (kv
cosphi	Power factor	Sensor that relates the active and reactive power. No units
active_energy	Active electrical energy meter	Measurement of accumulated active power. Units: kWh.
reactive_energy	Reactive electrical energy meter	Measurement of accumulated reactive power. Units: kwir.
gas_volume	Gas meter	Measurement of accumulated gas consumption. Units: m3 o Nm3
water_meter	Water meter	Measurement of accumulated water consumption. Units: m3 o 1
global_solar_irradian ce	Global solar irradiance	Mesurement of solar irradiance
leaf_moisture	Leaf moisture	Leaf wetness
		O2
oxygen	Oxygen Vertical level	
vertical_level		Vertical liquid level (water)
bend	Bend	Bend Liquified petroleum gases (H2, CH4, ethanol & isobutane)
lpg	Lpg Crack detection	
crack_detection		Crack detection gauge Solar radiation
solar_radiation	Solar radiation	
VOC	Voc	Volatile Organic Compounds  Ion Cl-
chloride_ion	Chloride ion	
temperature	Temperature	Soil/Water temperature
magnessium_ion	Magnessium ion	Ion Mg2+
distance	Distance	Distance (by metalic pressure or by pressure)
conductivity	Conductivity	Conductivity
liquid_leakage_line	Liquid leakage line	Water Leakage / Liquid Detection (Line)
crack_propagation	Crack propagation	Crack propagation gauge
nitrate_ion	Nitrate ion	Ion NO3
hall_effect	Hall effect	Hall effect
vibration	Vibration	Vibration (lamina)
copper_ion	Copper ion	Ion Cu2+
calcium_ion	Calcium ion	Ion Ca+
dendometer	Dendometer	Trunk, stem or fruit diameter
iodide_ion	Iodide ion Bromide ion	Ion I-
bromide_ion	11	Ion Br-

Table 2 – continued from previous page

Id	Name	Description
sodium_ion	Sodium ion	Ion Na+
linear_displacement	Linear displacement	Linear displacement
atmospheric_pressure	Atmospheric pressure	Atmospheric pressure
methane	Methane	CH4
pressure	Pressure	Pressure/ Weight
ammonia	Ammonia	NH3
redox_potential	Redox potential	Oxidation Reduction Potential
proximity_indoor	Proximity indoor	Ultrasound (indoor)
air_pollutant	Air pollutant	Air pollutants-I (NH3, SH2, ethanol and toluene) and air pollutants
liquid_leakage_point	Liquid leakage point	Water Leakage / Liquid Detection (Point)
proximity_outdoor	Proximity outdoor	Ultrasound (outdoor IP67)
potassium_ion	Potassium ion	Ion K+
o_saturation	O saturation	Dissolved Oxygen
presence	Presence	Presence (PIR)
stretch	Stretch	Stretch
liquid_level	Liquid level	Horizontal liquid level (combustibles or water)
load	Load	Load
fluoride_ion	Fluoride ion	Ion F-
ph	Ph	pH
solvent_vapors	Solvent vapors	Solvent vapors (H2, CH4, CO, ethanol and isobutane)
accelerometer	Accelerometer	Accelerometer

# 3.5.4 Data

## Publish observations from a sensor

# **Description**

This action allows a provider to publish the observations made by one of its sensors.

http://<your\_api\_server.com>/data/<provider\_id>/<sensor\_id>

Formats	json
Method	PUT
Permission	Writing
Retorna	No output data

# **Parameters**

Key	Description	Ор-
		tional
observa-	Observations list to publish.	No
tions		
location	Geolocation coordinates in which the sensor got the observations(latitude longitude for-	Yes
	mat).	

Each observation will have the following structure:

Key	Description	Ор-
		tional
value	Observation value to register	No
times-	Date and time when the observation was made (format dd/MM/yyyyTHH:mm:ssZ)	Yes
tamp		
location	Geolocation coordinates, in decimal degrees, in which the sensor got the observa-	Yes
	tions(latitude longitude format)	

#### Please note the following:

- If you send an observation of a sensor without specifying timestamp, the platform will use the current timestamp as measurement time.
- The location of the observations is optional. But in case you want to set it, you can do it for all observations and/or individually for each one. The location informed for each observation takes precedence over the global localization.
- The TimeZone (Z) in the timestamps is optional. Its default value is UTC.
- In previous releases (up to 1.5.x) the system permitted publication of sensors that weren't registered in the catalog. Since 1.6, the sensor has to be correctly registered.
- If the sensor is in offline state, the server rejects the publication.

### Response data

This action does not return additional data beyond the HTTP status code.

#### **Examples**

#### Request to publish the last observation of a sensor

To publish an observation of a sensor service provides two ways to do it.

#### **Abbreviated request**

If we want to publish the last observation for the sensor with RE0012 identifier belonging to the provider with rec identifier we just have to add the value to the URL. In this case we can not send timestamp nor location:

```
http://<your_api_server.com>/data/rec/RE0012/12.3
```

where 12.3 is the observation value.

As indicated previously, this request will register a new observation (value 12.3) for the specified sensor. The timestamp of the observation will be the instant of arrival of the request to the platform.

#### **Normal Request**

If you wish to send the timestamp and the location of the observation too, we should use the format described, and send information in the body of the request.

For example, if in we want to include the timestamp of the observation, the request to do will be the following:

```
http://<your_api_server.com>/data/rec/RE0012
```

#### in the body message

```
{"observations":[{
    "value":"12.3",
    "timestamp":"17/09/2012T12:34:45"}
]}
```

This request will register a new observation(value 12.3) with the received timestamp (UTC time zone in this case) of the measurement.

Another example: it shows how to publish the temperature measured on Barcelona at a given time, sending the time in the Barceloca local time zone (CET):

```
{"observations":[{
    "value":"9.6",
    "timestamp":"17/02/2016T11:43:45CET",
    "location": "41.3888 2.15899"}
]}
```

## Request to publish several observations of the same sensor

If you want to send more of an observation of a sensor, the request is very similar to the previous one, only changing the message body.

```
http://<your_api_server.com>/data/rec/RE0012
```

in the body message

```
{"observations":[{
     "value":"10.1"
}, {
     "value":"11.2",
     "timestamp":"17/09/2012T12:34:45"
}, {
     "value":"12.3",
     "timestamp":"17/09/2012T10:34:45"
}
]}
```

In this case are three observations with the corresponding timestamps.

### Publishing observations from different sensors

### **Description**

This action allows a provider to publish details of the observations made by more than one sensor in a single message.

```
http://<your_api_server.com>/data/<provider_id>
```

Format	json
Method	PUT
Permission	Writing
Return	No output data

## **Parameters**

Key	Description	Optional
sensors	List of sensors (sensor) for which we publish at least one observation	No

Each sensor will have the following structure:

Key	Description	Ор-
		tional
sensor	Sensor identifier	No
observa-	Observations list (observation) to publish	No
tions		
location	Geolocation coordinates in which the sensor observations are obtained (latitude longitude	Yes
	format)	

Each observation will have the structure described on page Publish observations of a sensor:

Key	Description	Ор-
		tional
value	Observation value	No
times-	Date and time at which the observation was made (dd/MM/yyyyTHH:mm:ssZ format)	Yes
tamp		
location	Geolocation coordinates in which the sensor has achieved this observation (latitude longi-	Yes
	tude format).	

### **Response Data**

This action does not return additional data beyond the HTTP status code.

## **Examples**

## Request to send multiple observations of several sensors setting a LTC TimeZone

If we want to send the observations of a set of sensors for the provider named rec, setting timeZone to CET, the request to do is:

http://<your\_api\_server.com>/data/rec

and in the body message:

```
{"sensors":[
   {
    "sensor": "RE0012",
    "observations":[
     {"value":"1.1"},
      {"value":"1.2",
       "timestamp":"17/09/2012T12:34:45CET"},
      {"value":"1.3",
       "timestamp":"17/09/2012T10:34:45CET"}
   ]
   },{
    "sensor": "RE0013",
    "location": "41.12345 2.12354",
    "observations":[
      {"value":"2.1"},
      {"value":"2.2",
       "timestamp":"16/09/2012T15:43:21CET"},
      {"value":"2.3",
       "timestamp":"16/09/2012T10:43:21CET"}
    ]
   }
] }
```

#### **Delete Observations**

### **Description**

This action allows to delete observations made by one or several sensors of a provider.

```
http://<your_api_server.com>/data/<provider_id>/<sensor_id>
```

Formats	json
Method	DELETE
Permission	Writing
Returns	No output data

#### **Parameters**

No additional data is sent.

# Response data

This action does not return additional data beyond the HTTP status code.

## **Examples**

## Request to delete the last observation of a sensor

If we want delete the last observation received by the plataform of the sensor with id REC1102 of the provider named rec, the request to do is:

http://<your\_api\_server.com>/data/rec/RE0012

### Request to delete the last observations of a provider's sensors

If we want to delete the last observation of each sensor of the provider named rec, the request to do is:

http://<your\_api\_server.com>/data/rec

#### **Retrieve sensor observations**

## **Description**

This action allows you to retrieve the latest observations of a sensor. In addition, the service can also permits to specify search criteria to retrieve observations: filter by a given time period and / or to indicate the maximum number of observations to be retrieved.

http://<your\_api\_server.com>/data/<provider\_id>/<sensor\_id>?<parameter>=<value>

Format	json
Method	GET
Permission	Reading
Returns	Observations list

### **Parameters**

Key	Description	Optional
from	Indicates the beginning of the time period for which you want to retrieve observations	Yes
to	Indicates the end of the time period for which you want to retrieve observations	Yes
limit	Indicates the number of observations to retrieve	Yes

Please, note the following:

- The maximum number of records returned will be fixed by the platform settings. If the parameter passed is higher, the number of records returned will be equals to the maximum value configured in the platform.
- If the limit parameter is not set, only one observation will be returned.
- All dates must have the following format: dd/MM/yyyyTHH:mm:ssZ with Z as optional (and with default value UTC)

### Response data

As mentioned, in addition to HTTP status code, the observation data is returned in the body contents as a list of observations:

Key	Description	Optional
observations	List the observations (observation)	No

Each observation has the following structure:

Key	Description	Op- tional
		tional
value	Observation value	No
times-	The time when the observation was made based on UTC (dd/MM/yyyyTHH:mm:ss for-	No
tamp	mat)	
time	The time when the observation was made in milliseconds	No
location	Geolocation coordinates in which the sensor was recorded observation	Yes

### **Examples**

# Request to retrieve the latest observations of a sensor based on a date

The following request shows an example in which a call is made to retrieve the last 20 observations of the sensor with RE0012 identifier of the provider named rec which have been registered from 10/01/2013.

```
http://<your_api_server.com>/data/rec/RE0012?limit=20&from=10/01/2013T10:00:00
```

#### As response we receive:

```
{"observations":[
      "value": "28.61132406103821",
      "timestamp": "13/11/2017T09:00:00",
      "time":1510563600000
  },{
      "value": "20.795568440010314",
     "timestamp": "13/11/2017T08:30:00",
      "time":1510561800000
      "value": "91.01094902496055",
      "timestamp": "13/11/2017T08:30:00",
      "time":1510561800000
      "value": "62.22915604583776",
      "timestamp": "11/01/2013T08:16:38",
      "time":1510561800000
  },{
      "value": "99.96065618303348",
     "timestamp":"11/01/2013T07:16:38",
     "time":1510561800000
  },{
      "value": "94.95685904585568",
     "timestamp": "11/01/2013T06:16:38",
      "time":1510561800000
  },{
      "value": "51.26506022800391",
      "timestamp":"11/01/2013T05:16:38",
      "time":1510561800000
  },{
      "value": "21.43303677241535",
      "timestamp": "11/01/2013T04:16:38",
```

(continues on next page)

(continued from previous page)

```
"time":1510561800000
},{
    "value":"55.6601921120059",
    "timestamp":"11/01/2013T03:16:38",
    "time":1510561800000
},{
    "value":"56.692086830598996",
    "timestamp":"11/01/2013T02:16:38",
    "time":1510561800000
}
```

#### Request to retrieve the last observation of a sensor

If you only want to retrieve the last observation of the RE0012 sensor, the request to do is:

```
http://<your_api_server.com>/data/rec/RE0012
```

As response we will receive:

```
{"observations":[{
    "value":"11.5",
    "timestamp":"18/09/2012T17:20:00",
    "time":1510561800000}
]}
```

#### Read observations from provider's sensors

### **Description**

This action allows to retrieve the latest observations of the sensors of a provider. In addition, the service can also specify search criterias to retrieve observations: filter by a given time period and / or to indicate the maximum number of observations to be recovered.

```
http://<your_api_server.com>/data/<provider_id>?<parameter>=<value>
```

Format	json
Method	GET
Permission	Reading
Return	List with the observations from provider's sensors

#### **Parameteres**

Key	Description	Optional
from	Indicates the beginning of the time period for which you want to retrieve the observations.	Yes
to	Indicates the end of the time period for which you want to retrieve the observations.	Yes
limit	Specifies the maximum number of observations for each sensor to recover.	Yes

Please note the following:

- The maximum number of records returned will be fixed by the platform settings. If the parameter passed is higher, the number of records returned will be equals at the maximum value configured in the platform.
- If the limit parameter is not set, only one record will be returned.
- All dates must have the following format: dd/MM/yyyyTHH:mm:ss

#### Response data

In addition to the HTTP status code, the observation data is returned in the body contents as a list of observations:

Key	Description	Optional
sensor	List of sensors (sensor) for the observations that have been retrieved	No

Each sensor has the following structure:

Key	Description	Optional
sensor	Sensor identifier	No
observations	List of the latest sensor observations	No

Finally, each observation (observation) has the following structure:

Key	Description	Opional
value	Observation value	No
timestamp	The time at which the observation was made (dd/MM/yyyyTHH:mm:ss format)	No
time	The time when the observation was made in milliseconds	No
location	Geolocation coordinates in which the sensor was recorded observation	Yes

## **Examples**

### Request to retrieve the latest observations from a provider after a given date

If we want to retrieve the latest observations of the sensors associated with the provider named rec from a given date we should make the following request:

```
http://<your_api_server.com>/data/rec?from=10/09/2012T10:00:00
```

As response we will receive:

(continues on next page)

(continued from previous page)

```
},{
    "sensor":"RE0013",
    "observations":
    [{
         "value":"24",
         "timestamp":"10/09/2012T10:06:10",
         "time":1510561800000
        }]
    }
}
```

#### Request to retrieve the latest observations from rec provider

If you only want to retrieve the last observation of the RE0012 sensor, the request to do is:

```
http://<your_api_server.com>/data/rec
```

As response we will receive:

```
{"sensors":[
      "sensor": "RE0012",
      "observations":
      [ {
         "value":"1",
         "timestamp":"10/09/2012T10:05:00",
         "time":1510561800000
      } ]
   },{
      "sensor": "RE0013",
      "observations":
      [ {
         "value":"24",
         "timestamp": "10/09/2012T10:06:10",
         "time":1510561800000
      } ]
   }
] }
```

#### **Description**

The data service allows to read, write or delete the observations of the registered sensors.

All requests for this service will have the following format:

```
http://<your_api_server.com>/data/<provider_id>/<sensor_id>
```

where **provider\_id>** and **<sensor\_id>** correspond to the sensor and provider identifiers on which we want to perform the requested action.

### **Actions**

The available actions for this service are:

- Publish observations of a sensor
- Publish observations from sensors of a provider
- Delete observations
- Read observations from a sensor
- Read observations from sensors of a provider

### 3.5.5 Order

### Publish an order

### **Description**

This operation allows to send an order to single sensor or to all sensors of a provider. Once the system receives the order, it sends a notification to all its subscribers.

http://<your\_api\_server.com>/order/<provider\_id>/<sensor\_id>

Format	json
Method	PUT
Permission	Writing
Return	No output data

#### **Parameters**

Each order will have its specific structure with its associated information in the defined format (JSON).

The platform will only transfer the information to the subscribers, without checking its contents nor reading into it.

Key	Description	Optional
order	Orden content	Not

#### Response data

This action does not return additional data beyond the HTTP status code.

### **Examples**

# Publish an order to a sensor/actuator

The following example shows how to send a request to the platform to publish a new order destined to the sensor with RE0012 identifier belonging to the provider with ID rec:

http://<your\_api\_server.com>/order/rec/RE0012

in the body message:

```
{"order": "Stop"}
```

#### Publish an order to all the provider's sensors/actuators

The following example shows how to send a request to the platform to publish a new order to all the sensors belonging to the provider with rec identifier:

```
http://<your_api_server.com>/order/rec
```

#### in the body message

```
{"order":"Start RE0012, RE0013"}
```

#### **Retrieve orders**

#### **Description**

This action allows you to retrieve the last orders associated with a sensor or provider. In addition, we can also specify search criteria to retrieve the orders: filter by a given time period and/or indicate the maximum number of orders that you want to retrieve.

http://<your\_api\_server.com>/order/<provider\_id>/<sensor\_id>?<parameter>=<value>

Format	json
Method	GET
Permission	Read
Retorns	List of orders destined to sensor or provider listed

#### **Parameters**

Key	Description	Optional
from	Indicates the beginning of the time period for which you want to retrieve orders.	Yes
to	Indicates the ending of the time period for which you want to retrieve orders.	Yes
limit	Specifies the maximum number of orders to retrieve.	Yes

Please, note the following:

- The maximum number of records returned will be fixed by the platform settings. If the parameter passed is higher, the number of records returned will be the configured in the platform.
- If the limit parameter is not set, only one record will be returned.
- All dates must have the following format: dd/MM/yyyyTHH:mm:ss

#### Response data

As mentioned, in addition to HTTP status code, the requested data is returned in the body contents as a list of orders.

The response structure depends on what we are retrieving, orders from a sensor or a provider.

### Last orders for a sensor

Key	Description	Optional
orders	List with the last sensor's order	No

Each order will have the following structure:

Key	Description	Optional
order	Order message recorded at the time the order was published	No
timestamp	The time when the order was made (dd/MM/yyyyTHH:mm:ss format)	No
sender	Entity identifier that issued the order.	No
time	The time when the observation was made in milliseconds	No

### Last orders for provider

Key	Description	Optional
sensors	List with sensors (sensor)	No

Each (sensor) will have the following structure:

Key	Description	Optional
sensor	Sensor identifier	No
orders	List with the last orders for the sensor	No

Finally, each command (order) will have the structure that we have defined previously.

Key	Description	Optional
order	Order message recorded at the time the order was published	No
timestamp	The time when the order was made (dd/MM/yyyyTHH:mm:ss format)	No
sender	Entity identifier that issued the order.	No

# **Examples**

#### Retrieve the last order for a sensor

To retrieve the last order for the sensor with RE0012 identifier belonging to the provider named rec, we do the following request:

```
http://<your_api_server.com>/order/rec/RE0012
```

As response we will get:

```
{"orders":[{
    "order":"Shutdown",
    "timestamp":"21/03/2013T14:25:39",
    "sender":"app_demo_provider"}]
}
```

#### Retrieve the last N orders for a sensor

If we want to retrieve more than one order, we can specify the number of records to retrieve with the following request:

```
http://<your_api_server.com>/order/rec/RE0012?limit=3
```

As response we will get:

```
{"orders":
   [ {
      "order": "Shutdown",
      "timestamp": "21/03/2013T14:25:39",
      "sender": "app_demo_provider",
      "time":1510570798597
   },{
      "order": "Start",
      "timestamp":"20/03/2013T23:59:59",
      "sender": "app_demo_provider",
      "time":1510570798597
   },{
      "order": "Shutdown",
      "timestamp": "20/03/2013T14:25:39",
      "sender": "app_demo_provider",
      "time":1510570798597
   }
] }
```

#### Retrieve the last N orders for a sensor between dates

If we want to retrieve orders for a sensor between two dates, we should do the following request:

As response we will get:

#### Retrieve the last orders for a provider

All the previous examples are focused on recovering the last command of a sensor, but the service also allows you to search the latest orders destined for all the sensors of provider.

In this case, we only specify the provider, and the request will be:

```
http://<your_api_server.com>/order/rec2
```

As response we get a list of sensor elements, and each one will contain its last orders.

```
{"sensors":
  [ {
      "sensor": "RE0012",
      "orders":
      [ {
         "order": "Shutdown",
         "timestamp":"21/03/2013T14:25:39",
         "sender": "app_demo_provider",
         "time":1510570798597
      } ]
  },{
      "sensor": "RE0013",
      "orders":
      [ {
         "order": "Shutdown",
         "timestamp": "21/03/2013T14:25:39",
         "sender": "app_demo_provider",
         "time":1510570798597
      }]
  },{
      "sensor":"RE0014",
      "orders":
      [ {
         "order": "Shutdown",
         "timestamp": "21/03/2013T14:25:39",
         "sender": "app_demo_provider",
         "time":1510570798597
      } ]
  } ]
```

#### **Description**

The order service allows to send or retrieve orders to sensors/actuators.

All requests for this service will have the following format:

```
http://<your_api_server.com>/order/<provider_id>/<sensor_id>
```

The sensor identifier, **<sensorId>**, is optional and should be informed depending on the action we want to execute.

### **Actions**

The available actions for this service are:

- Publish orders
- · Retrieve orders

## 3.5.6 Subscription

### Subscription to sensor data

#### **Description**

This action allows to subscribe to observation data associated to sensors.

It's important to note that we only can subscribe to the sensor data over we own read permission.

http://<your\_api\_server.com>/subscribe/data/<provider\_id>/<sensor\_id>

Format	json
Method	PUT
Permission	Read
Returns	No additional data returned

#### **Parameters**

Key	Description	Ор-
		tional
endpoint	URL where the platform will send a HTTP request with the observation data	No
secret-	Secret key for HMAC callbacks	Yes
Call-		
backKey		
maxRe-	Maximum number of retries	Yes
tries		
retryDe-	Delay parameter in minutes. Delays are spaced exponentially according to following equation:	Yes
lay	delay (N) = delay * $2^{(N-1)}$ Where N is the current entry turn. More detailed explanation	
	follows.	

#### Retries

In case the remote endpoint is down or does not respond with an success HTTP 2xx code, Sentilo can try to resend the data later. In order to overcome major number of remote outages, Sentilo sends the data in delay times that are exponential according to equation:

```
delay (N) = delay * 2^(N-1)
```

For example, if we have a subscription configured with 5 retries and 10 minutes, first retry would occur at 10 minutes, the second 20 minutes after the first, the third 40 minutes after the second, etc up to the fifth retry.

The total time used for the 5 retries would occur in 10+20+40+80+160=310 minutes after the first failed intent.

### Response data

This action does not return additional data beyond the HTTP status code.

## **Examples**

## Request to subscribe to a sensor's data

If we want to susbcribe to the sensor's data with RE0012 identifier of the provider named rec, the request will be:

http://<your\_api\_server.com>/subscribe/data/rec/RE0012

#### and the body message:

{"endpoint": "http://<your\_endpoint\_notification\_server.com>/resource"}

### Request to subscribe to provider's data

If we want to subscribe to all the sensors belonging to a provider, the request will be:

http://<your\_api\_server.com>/subscribe/data/rec

#### and the body message:

{"endpoint":"http://<your\_endpoint\_notification\_server.com>"}

## Subscription to orders

#### **Description**

This action allows to subscribe to orders associated to sensors.

It's important to note that we only can subscribe to the sensor data over we own read permission.

http://<your\_api\_server.com>/subscribe/order/<provider\_id>/<sensor\_id>

Formats	json
Method	PUT
Permission	Read
Returns	No additional data returned

## **Parameters**

Key	Description	Ор-
-		tional
endpoint	URL where the platform will send a HTTP request with the order data	No
secret-	Secret key for HMAC callbacks	Yes
Call-		
backKey		
maxRe-	Maximum number of retries	Yes
tries		
retryDe-	Delay parameter in minutes. Delays are spaced exponentially according to following equation:	Yes
lay	delay (N) = delay * $2^{(N-1)}$ Where N is the current entry turn. More detailed explanation	
	follows.	

3.5. Services 69

#### Retries

In case the remote endpoint is down or does not respond with an success HTTP 2xx code, Sentilo can try to resend the data later. In order to overcome major number of remote outages, Sentilo sends the data in delay times that are exponential according to equation:

```
delay (N) = delay * 2^(N-1)
```

For example, if we have a subscription configured with 5 retries and 10 minutes, first retry would occur at 10 minutes, the second 20 minutes after the first, the third 40 minutes after the second, etc up to the fifth retry.

The total time used for the 5 retries would occur in 10+20+40+80+160=310 minutes after the first failed intent.

#### Response data

This action does not return additional data beyond the HTTP status code.

#### **Examples**

#### Request to subscribe to orders for a sensor

If we want to susbcribe to the orders for the sensor with RE0012 identifier of the provider named rec, the request will be:

```
http://<your_api_server.com>/subscribe/order/rec/RE0012
```

and the body message:

```
{"endpoint":"http://<your_endpoint_notification_server.com>"}
```

#### Request to subscribe to orders for a provider

If we want to subscribe to all the sensor's orders belonging to the rec provider, the request will be:

```
http://<your_api_server.com>/subscribe/order/rec
```

and like body message:

```
{"endpoint":"http://<your_endpoint_notification_server.com>"}
```

#### Subscription to alerts

#### **Description**

This action allows to subscribe to alarms associated to sensors.

It's important to note that we only can subscribe to the sensor data over we own read permission.

```
http://<your_api_server.com>/subscribe/alarm/<alert_id>
```

Format	json
Method	PUT
Permission	Read
Returns	No additional data returned

#### **Parameters**

Key	Description	Ор-
		tional
endpoint	URL where the platform will send a HTTP request with the alarm message	No
secret-	Secret key for HMAC callbacks	Yes
Call-		
backKey		
maxRe-	Maximum number of retries	Yes
tries		
retryDe-	Delay parameter in minutes. Delays are spaced exponentially according to following equation:	Yes
lay	delay (N) = delay * $2^{(N-1)}$ Where N is the current entry turn. More detailed explanation	
	follows.	

#### Retries

In case the remote endpoint is down or does not respond with an success HTTP 2xx code, Sentilo can try to resend the data later. In order to overcome major number of remote outages, Sentilo sends the data in delay times that are exponential according to equation:

```
delay (N) = delay * 2^(N-1)
```

For example, if we have a subscription configured with 5 retries and 10 minutes, first retry would occur at 10 minutes, the second 20 minutes after the first, the third 40 minutes after the second, etc up to the fifth retry.

The total time used for the 5 retries would occur in 10+20+40+80+160=310 minutes after the first failed intent.

### Response data

This action does not return additional data beyond the HTTP status code.

#### **Examples**

#### Request to subscribe to alert's alarms

If we want to register a new subscription for alarms belonging to the alert with alert1 identifier, the request will be:

```
http://<your_api_server.com>/subscribe/alarm/alert1
```

and the body message:

```
{"endpoint":"<your_endpoint_notification_server.com>"}
```

3.5. Services 71

## **Retrieve active subscriptions**

#### **Description**

This action allows to retrieve the list of all our active subcriptions. Additionally, we can retrieve only subscriptions from a specific type.

```
http://<your_api_server.com>/subscribe/<event_type>
```

Format	json
Method	GET
Permission	Read
Returns	Active subscriptions

**<event\_type>** is optional and allows to filter the subscription by type.

#### **Parameters**

No additional parameters can be used.

#### Response data

This action, additionally to the HTTP status code, will return a list of our active subscriptions:

Key	Description	Optional
subscriptions	List with all our active subscriptions	No

Each **subscription** element contains this set of attributes:

Key	Description	Optional
endpoint	URL defined in the subscription	No
type	Event type related to the subscription(data, order o alarm)	No
provider	In case the type is <i>data</i> or <i>order</i> this attribute contains the provider identifier	Yes
sensor	In case the type is <i>data</i> or <i>order</i> this attribute contains the sensor identifier	Yes
alarm	In case the type is <i>alarm</i> this attribute contains the alert identifier	Yes

### **Examples**

### Request to retrieve all active subscriptions

```
http://<your_api_server.com>/subscribe
```

As response we will obtain:

```
{
    "subscriptions":
    [{
        "endpoint":"http://<your_endpoint_notification_server.com>",
```

(continues on next page)

(continued from previous page)

```
"type": "ALARM",
   "alert": "alerta1"
},{
   "endpoint":"http://<your_endpoint_notification_server.com>",
   "type": "DATA",
   "provider": "app_demo_provider",
   "sensor": "appdemo_sensor5_test"
},{
   "endpoint":"http://<your_endpoint_notification_server.com>",
   "type": "DATA",
   "provider": "app_demo_provider",
   "sensor": "appdemo_sensor_test"
},{
   "endpoint":"http://<your_endpoint_notification_server.com>",
   "type": "ALARM", "alert": "11"
} ]
```

### Request to retrieve active subscriptions for a specific type

If we want to retrieve only the subscriptions to a specific event type:

```
http://<your_api_server.com>/subscribe/alarm
```

As response we will obtain:

```
{
    "subscriptions":
    [{
        "endpoint":"http://<your_endpoint_notification_server.com>",
        "type":"ALARM",
        "alert":"alert1"
    }, {
        "endpoint":"http://<your_endpoint_notification_server.com>",
        "type":"ALARM",
        "alert":"alert11"
    }]
}
```

#### **Cancel subscriptions**

#### **Description**

This action allows to cancel any or a set of our active subscriptions.

http://<your\_api\_server.com>/subscribe/<event\_type>/<resource\_id>

Format	json
Method	DELETE
Permission	Write
Returns	No additional data returned

3.5. Services 73

<event\_type> and <resource\_id> are optional and allow to filter the subscription to cancel by event type or related
resource.

#### **Parameters**

No additional data can be sent.

#### Response data

This action does not return any additional data beyond the HTTP status code.

#### **Examples**

#### Request to cancel subscriptions

If we want to cancel all our active subscriptions, the request will be:

http://<your\_api\_server.com>/subscribe

#### Request to cancel subscriptions for a specific event type

If we want to cancel all our active subscriptions of a specific event type like order, the request will be:

http://<your\_api\_server.com>/subscribe/order

#### Request to cancel subscriptions for a specific resource

If we want to cancel all our active data subscriptions of a specific sensor like RE0012 belonging to the rec provider, the request will be:

http://<your\_api\_server.com>/subscribe/data/rec/RE0012

#### **Description**

The subscription service allows to the platform clients(application/modules or provider/sensors) to subscribe to system events, which can be:

- Data: related to data observations received by the platform
- Order: related to orders received by the platform
- Alarm: related to alarms received by the platform

It is also possible to retrieve the list of active subscriptions or cancel them.

All requests for this service will have the following format:

http://<your\_api\_server.com>/subscribe/<event\_type>/<resource\_id>

where **<resource\_id>** identifies the system resource to which the request applies (providers, sensors or alerts).

#### **Actions**

The available actions for this service are:

- · Subscription to sensor data
- Subscription to orders
- Subscription to alerts
- Retrieve active subscriptions
- · Cancel subscription

#### **Notifications**

As mentioned before, when we subscribe to a system event, the platform will send us a notification (push process), whenever the event occurs, through a HTTP POST request to the URL configured with the subscription.

The notification message follows the following structure:

```
"message":"...",
"timestamp":"...",
"topic":"...",
"type":"...",
"sensor":"...",
"provider":"...",
"location":"...",
"alertType":"...",
"time":"...",
"ttime":"...",
"publisherTenant":"...",
"publishedAt":"...",
```

where the following fields are mandatory:

- message: contains the event information (observation, alarm or order)
- timestamp: contains the timestamp associated with the event, formatted as UTC (dd/MM/yyyy'T'HH:mm:ss).
- topic: identifies the subscription related to the event.
- type: identifies the event type (DATA, ORDER or ALARM)
- time: same as timestamp but expressed as milliseconds

and the following are optional and depend on the event type:

- sensor: contains the sensor identifier related to the event.
- provider: contains the provider identifier related to the event.
- location: only added in observation notifications when the location is filled in.
- sender: this field has been removed in version 1.6. See *publisher* field.
- alert: only added in alarm notifications. Contains the alert identifier related to the alarm.
- alertType: only added in alarm notifications. Contains the alert type: INTERNAL or EXTERNAL.

3.5. Services 75

- retryAttempt: if the delivery of the message fails, this number indicates a number of the retries. See for example how to define retries in data subscription.
- publisher: identifies the entity who has published the event.
- publishedAt: this field differs from *time* field in that it always stores the time when the event was published on Sentilo.
- tenant: only added in multitenant instances. This field identifies the tenant to which the event belongs.
- publisherTenant: only added in multitenant instances. This field identifies the tenant to which the publisher belongs.

Here are three different examples of notification:

```
"message":"8",
  "timestamp":"26/10/2016T08:50:33",
  "topic":"/data/app_demo_provider/appdemo_sensor_test",
  "type":"DATA",
  "sensor":"appdemo_sensor_test",
  "provider":"app_demo_provider",
  "location": "41.387172 2.17157",
  "time":1477471833000,
  "retryAttempt": 1,
  "publisher":"app_demo_provider",
  "publishedAt":1477471833000,
  "publisherTenant": "",
  "tenant": "",
  "sender": "app_demo_provider"
}
```

```
"message":"Stop",
"timestamp":"16/10/2013T15:39:11",
"topic":"/order/app_demo_provider",
"type":"ORDER",
"sensor": "TEST_SENSOR_001",
"provider":"app_demo_provider",
"time":1477471833000,
"publisher":"app_demo_provider",
"publishedAt":1477471833000,
"publisherTenant": "",
"tenant": "",
"sender": "app_demo_provider"
```

```
"message":"Value greater than 34",
"timestamp":"16/10/2013T15:40:57",
"topic":"/alarm/internalAlarmProve",
"type":"ALARM",
"sensor":"app_demo",
"alert":"ALERT_GT14",
"alertType":"INTERNAL",
"publisher": :"sentilo"
"time":1477471833000,
"publishedAt":1477471833000)
```

If the subscription has included a secret key, the following messages will include the security headers (see more).

#### **Notifications to untrusted HTTPS**

In case that remote endpoint uses a self-signed certificate, add the following configuration in the sentilo-platform.conf of the sentilo-platform-service:

```
# Allows to send notifications from Sentilo to untrusted servers, i.e., servers with self-signed certificates or signed by unknown CAs sentilo.server.api.subs.ssl.no-validate-certificates=false
```

The Application Programming Interface (API) of Sentilo defines a set of commands, functions and protocols that must be followed by who wants to interact with the system externally.

This area defines the Application Programming Interface (API), that any sensor or application must use to interact with the platform.

The starting capacities of the platform related to its external interface are:

- Allows to register applications/modules and providers/sensors in the platform (Catalog).
- Allow to applications/modules and sensors subscribe to services defined in the catalog as well as post events occurring (Publish/Subscribe).
- Allow you to send information from sensors to applications/modules (Data).
- Allows to send orders from applications/modules to sensors (Order).

3.5. Services 77

78 Chapter 3. API Docs

## **Architecture**

Sentilo is a platform aimed to isolate and communicate the applications that are developed to exploit the information generated from the ground by the layer of sensors deployed across to collect and broadcast this information.

Its main modules are:

- · Restful API
- · Web Application which provides an administration console and some public visualizers
- Data publication & subscription system
- · A memory database for storing real time data
- A non-SQL database for storing less volatile data, like the sensor's catalog
- Several agents which extend the platform features

## 4.1 Key Concepts

This section describes the main concepts of Sentilo. Many of these concepts are discussed later deeply.

You can read also some Technical FAQs.

#### 4.1.1 PubSub Platform

Sentilo allows customers to publish and retrieve information and to subscribe to system events. This module is a stand-alone Java process that uses Redis as a publish/subscribe mechanism.

The different types of information considered are:

- · observations
- alarms
- orders

Please, check this out fore more info.

## 4.1.2 RealTime storage

Redis is the primary repository where the platform stores all the information received. It is configured to do periodic backups in the file system. It is also the Publish/Subscribe engine.

#### **4.1.3 REST API**

The client's communication with publish/subscription mechanism is made using the REST API provided by the platform

Services offered by the API can be classified into five main groups:

- data: provides operations to publish, retrieve, delete data.
- order: provides operations to publish, retrieve, delete orders.
- alarm: provides operations to publish, retrieve, delete alarms.
- subscribe: provides operations to subscribe, retrieve and cancel subscriptions.
- catalog: provides operations to insert, update, query and delete catalog resources (sensors, components and alerts).

By default, the information is transmitted using JSON format. Please, check this out fore more info.

## 4.1.4 Agents

Agents are Java processes that expand the core functionality of the platform through a Plug & Play system using the Redis publish and subscribe mechanism.

Sentilo currently provides several agents, for example:

- Relational database agent: used to export historical data to a relational database.
- Alert agent: used for processing each data received by the platform and validate it with the business rules configured in the catalog.
- Activity Monitor Agent: used for upload the events to Elasticsearch.
- **Historian Agent**: used for upload the events to OpenTSDB.

See the complete list here: Sentilo Agents

#### 4.1.5 Authentication Token

The invocation of different REST API services is secured using an authentication token. This token must be sent in every request as a header parameter of the HTTP request named IDENTITY\_KEY. This token is unique for each provider or client application, and is managed by the catalog application.

Please, check this out fore more info.

## 4.1.6 Permission

Permissions allow Sentilo to identify the requester and to ensure that who makes a request is authorized to do it. Permissions are managed by the catalog web app and allow to configure read or write permissions to client application on third party resources (provider or client applications). By default, every platform entity has read and write permissions on its own resources.

Please, check this out fore more info.

#### 4.1.7 Notification mechanism

Sentilo provides two mechanisms for notifying events:

- If the client is capable of having an opened socket, the platform will send a notification to this socket every time an event is triggered (push).
- If the client cannot have an opened socket, then it must be doing periodic requests (polling) to the platform to retrieve last events.

## 4.1.8 Catalog

The Web Application Platform console allows to manage the following resources: providers, applications, components, sensors, sensors types, component types, alerts and users.

It also provides a public console for displaying components and sensors registered in the platform as well as the data that has been received.


Please, check this out fore more info.

#### 4.1.9 Alert

Sentilo allows to manage sensor-level internal alerts, aimed to control the validity of the data received. The set of conditional operators available are: >, >=, <, <=, =, any change, variation, frozen. When the value received from a sensor doesn't met any of the conditions defined, the alert agent publishes an event (alarm) notifying it. These alerts are defined through the console. There are also external alerts which can be defined and triggered externally though the API.


## 4.2 Platform architecture

The following diagram describes the Sentilo platform:



#### 4.2.1 PubSub Server


PubSub Server is a stand-alone java application whose design is divided into two layers:



- Transport Layer: designed following the Thread Pool pattern: http://en.wikipedia.org/wiki/Thread\_pool\_pattern
- Service Layer: Based in Spring and Redis, it's designed to provide high performance rates.

## **Transport Layer**

The transport layer is designed following the Thread Pool pattern and is implemented with Apache HttpCore library. The following diagram shows the main flow for a request within this layer:



- The client sends a Http request to the REST platform
- The server accepts and queues it on the list of pending requests
- When a Worker is available, a pending task is assigned to it for processing (removing it from the queue)
  - delegates the request to an element of the service layer
  - and constructs the HTTP response from the information received
- Send the response to client's request


The values of the job queue and the workers' pool are fully configurable via properties file, for easily adjust to the load requirements of each environment:

```
# Properties to configure the pool of workers which handle incoming API requests.
sentilo.server.api.thread.pool.group-id=ApiRequestHandler
sentilo.server.api.thread.pool.group-name=API-Server
sentilo.server.api.thread.pool.queue-size=100
sentilo.server.api.thread.pool.keep-alive-seconds=60
sentilo.server.api.thread.pool.size.core=4
sentilo.server.api.thread.pool.size.max=10
```

#### **Service Layer**

The design of this layer has the main premise of minimizing the request processing time, so all the main job is held in memory(Redis). Redis stores data in a memory database but also has the possibility of disk storage to ensure the durability of the data.

The following diagram shows the main flow for a request within this layer:



**NOTE:** (\*) Executed asynchronously to the main process.

- The Worker delegates the request to the associated handler depending on the type of request (data, order, alarm, ...)
- The following validations are performed on each request:
  - (2a) Integrity of credential: checks the received token sent in the header using the internal database in memory containing all active credentials in the system.
  - (2b) Authorization to carry out the request: validate that the requested action can be done according to the permission database.
  - the validity of the request parameters: mainly, structure and typology.
- After that:
  - stores the data in Redis (in memory)
  - and depending on the type of data

- \* (3a) publish the data through publish mechanism
- \* (3b) or register of the subscription in the ListenerMessageContainer
- Redis is responsible for sending the published information to ListenerMessageContainer event, who is responsible for managing the subscription in Redis as a client for any type of event.
- The container notifies the event to each subscription associated with it sending a request, via HttpCallback

The platform registers a task that runs periodically who is responsible for credentials & permissions synchronization, stored in memory in server (A). These data is retrieved from the catalog application. This will maintain anytime an exact copy of these values in memory and allows to check credentials and permissions instantly.

Finally, access to Redis is done through a connection pool fully configurable through the *sentilo.conf* properties file, which allows you to adjust to the specifics of each environment.

```
# Pool properties
sentilo.redis.client.maxTotal=300
sentilo.redis.client.maxIdle=300
sentilo.redis.client.minIdle=10
```

#### **Comments**

- This design allows system scalability both vertically and horizontally:
  - vertically: increasing the boundaries of work queue & workers.
  - horizontally: distributing the load across multiple instances or server nodes.
- It also reduce response time because the process is carried out in memory.

## 4.2.2 Catalog application

The catalog application platform is a web application built with Spring on the server side (Spring MVC, Spring Security, ..) using jQuery and bootstrap as presentation layer and MongoDB as data storage database.

This webapp consists of:

- a public console for displaying public data of components and sensors and their data
- a secured part for resources management: providers, client apps, sensors, components, alerts, permissions, ...

It is fully integrated with the Publish/Subscribe platform for data synchronization:

- permission and authentication data
- register statistical data and the latest data received for showing it in different graphs of the Web application.

# CHAPTER 5


Integrations

## 5.1 Agents

Agents are internal modules oriented to expand its functionality without having to alter its core. The installation is based on the principle of Plug & Play: they are recognized by the system and started automatically to be up and running.

Every agent is a process that acts as a subscriber for the publish/subscribe platform. These processes will subscribe directly to Redis as a independent clients. This subscription will provide the input data to do the underlying business logic (store in a relational database, process alarms, generate statistics, ...)

The following diagram shows the design that every agent should follow:



- 1. When agent is started, it subscribes as client to Redis for the event that wants to receive notifications.
- 2. When Redis receives a publication of any of these data, the agent is automatically notified with a new message.
- 3. The message is processed and transferred to the corresponding agent's service responsible to carry out the underlying business logic.

Sentilo currently provides 7 agents:

- Relational database agent
- · Alarm agent
- · Activity Monitor agent
- · Historian agent
- · Federation agent
- Kafka agent
- Metrics Monitor Agent

**Note:** Agents use a base setting described under the **sentilo.agent** path, which is defined in the sentilo.conf file, and which can be overwritten by them in their own *agent-xxx.conf* file.

## 5.1.1 Relational database agent

This agent stores all information received from PubSub platform into a relational database. It could be configured to filter the data to store according to a business rules through a configuration file.

#### Configuration

Relational Database Agent is configured in the file: sentilo-agent-relational/src/main/resources/properties/sentilo-agent-relational.conf.

Property	Description	Comments
subscriptions	Regexp pattern on event name that enables including/excluding events	Examples of configuration:  /alarm/*,/data/*,/order/* Subscribes to all events
		/data/PROVIDER1/*, /data/ →PROVIDER2/*  Subscribe only to data of 2 providers

#### **Datasource**

The dataSource is defined in the persitence context file: sentilo-agent-relational/src/main/resources/spring/relational-persistence-context.xml.

```
<br/>bean id="dataSource" class="org.apache.tomcat.jdbc.pool.DataSource" destroy-method=
→"close">
    → driverClassName }" />
    cproperty name="url" value="${sentilo.agent.relational.ds.url}" />
    property name="initialSize" value="${sentilo.agent.relational.ds.
→initialSize:1}" />
    \hookrightarrow />
    property name="testOnConnect" value="${sentilo.agent.relational.ds.
→testOnConnect:true}" />
    cproperty name="testOnBorrow" value="${sentilo.agent.relational.ds.
→testOnBorrow:true}" />
    ferty name="testWhileIdle" value="${sentilo.agent.relational.ds.
→testWhileIdle:true}" />
    → relational.ds.timeBetweenEvictionRunsMillis:10000}" />
    property name="validationInterval" value="${sentilo.agent.relational.ds.
→validationInterval:30000}" />
    property name="validationQuery" value="${sentilo.agent.relational.ds.
→validationQuery}" />
</bean>
```

and all its params can be configured in the .conf file.

Several database initialization files are located into the sentilo-agent-relational/src/main/resources/db directory that you can use for your own database.

5.1. Agents 89

## 5.1.2 Alarm agent

This agent processes each internal alert defined in the catalog and publish a notification (a.k.a. *alarm*) when any of the configured integrity rules are not met.

Due to the type of available rules, this validation process integrity is divided into two threads:

- An internal process that runs every minute, evaluates the status of each sensor that have associated (*frozen* type) alerts.
- · Additionally, each time a Redis notification is received, alerts associated with the data received are evaluated.

Finally, an internal process regularly synchronize the alert list, to synchronize the information stored in memory with the catalog repository.

## 5.1.3 Activity Monitor agent

#### **Background on Activity Monitor Agent**


Sentilo is a publication-subscription platform. The amount of data held in the system is proportional to Redis deployment and directly depends on the amount of physical memory available for the Redis server. In another words, the data has to be probably deleted after a certain amount of time to free the Redis memory. For example, in the Barcelona deployment, the data is deleted after approximately one week.

Additionally to data expiration, Sentilo does not provide many dashboards and those dashboards are not customizable.

In order to fill the gap of historization and dashboards, we use Elasticsearch and Kibana. Elasticsearch is a powerful Java-based fulltext search database with REST API. It is frequently used together with it's modules, Kibana for dashboards and Logstash for collecting of logs. The combination of Elasticsearch, Logstash and Kibana is often called the ELK stack. ELK provides a comfortable way to store and exploit historical information, and also a near-realtime monitoring of the platform. Note that Elasticsearch behaves excellently in cluster mode.

Sentilo events are uploaded to Elasticsearch through a Sentilo agent called Activity Monitor Agent. The configuration of this agent is described further in this chapter.

The following image illustrates a possible setup of Sentilo with ELK stack. Logstash is optional and can be used e.g. for monitoring of Sentilo logs (like login errors, invalid messages etc.), as well as monitoring of system resources.



The setup of the ELK stack is well documented and beyond the scope of this page.

#### Configuration

Activity Monitor Agent is configured in the file: sentilo/sentilo-agent-activity-monitor/src/main/resources/properties/sentilo-agent-activity-monitor.conf.

Property	Description	Comments
subscriptions	Regexp pattern on event name that	Examples of configuration:
	enables including/excluding events	/alarm/*,/data/*,/order/*
		Subscribes to all events
		/data/PROVIDER1/*, /data/ →PROVIDER2/*
		Subscribe only to data of 2 providers
elasticsearch.url	URL of the ES instance	

The agent will create index(es) called sentilo-YYYY-MM.

Configuration of Elasticsearch, Logstash and Kibana is beyond the scope of this document and can be easily followed on their respective web pages.

#### **Compatible versions**

Sentilo has been successfully used in with these versions of ELK (which does not mean other versions shouldn't work as well):

• ELK 5+

## 5.1.4 Historian agent

#### **Background on Historian Agent**

As you already might have learned, Sentilo does not persist data forever because of limited system resources.

Commonly used setup of a Sentilo instance is to employ one of the agents to copy the data into some external database or storage.

Since the data volumes can be fairly big and the data are mostly structured (except when the observations are text), it is convenient to use a scalable solution for time series such as OpenTSDB.

OpenTSDB installs of top of HBase and HDFS. Exposes a HTTP REST API and can be used from Grafana as one of it's data sources.

#### Configuration

Historian Agent is configured in the file: sentilo/sentilo-agent-historian/src/main/resources/properties/sentilo-agent-hitorian-opentsdb.conf.

5.1. Agents 91

Property	Description	Comments
subscriptions	Regexp pattern on event name that	Examples of configuration
	enables including/excluding events	/alarm/*,/data/*,/order/*
		Subscribes to all events
		/data/PROVIDER1/*,/data/ →PROVIDER2/*
		Subscribes only to data of 2 providers
opentsdb.url	URL of the OpenTSDB instance	
metrics.fromSensorType	Change the metrics name by using	If set to true, metric name will have
	sensor type	for of i.e. data.sensorType, oth-
		erwise metric name will result in
		data.providerName.sensorName
metrics.usePublishedAtTimestamp	URL of the OpenTSDB instance	If set to true, OpenTSDB's data-
		point will have the timestamp of the
		'publishedAt' property of the event,
		otherwise, the datapoint will use the
		'time' property of the event message

Configuration of HDFS, HBase, OpenTSDB and is beyond the scope of this document and can be easily followed on their respective web pages.

#### **Compatible versions**


Sentilo has been successfully used in with these versions:

- Hadoop 2.7.2
- HBase 1.2.1
- Opentsdb 2.2.0, 2.3.0
- Grafana 3 +

## 5.1.5 Federation agent

## Description

The federation agent is a module that permits to share events between two independent instances of Sentilo. The sharing is unilateral - one Sentilo instance is emitting events and the other is receiving. The agent is installed at the side of the receiving instance:



The administrator of the emitting Sentilo instance only needs to create a new application and provide the token the administrator of the receiving instance. As with any Sentilo application, the administrator is in control of which provider's data are readable by the remote federation agent.

Providers, components and sensors are created automatically in the catalog of the receiving instance by the federation agent. The agent uses its application token to query the emitting catalog API to obtain remote objects, and uses the local catalog application id to replicate the locally.

The federation agent creates subscriptions on data it has permission. It creates a HTTP endpoint and tells the emitting instance to forward the events to this endpoint URL.

#### Configuration

Federation Agent's configuration is in file sentilo/sentilo-agent-federation/src/main/resources/properties/sentilo-agent-federation.conf.

Property	Default Value	Description
server.port	8082	Agent's HTTP port
sen-	http://127.0.0.1:8081	Endpoint of the local API Server instance
tilo.agent.federation.api_server.loc	al.endpoint	
federation.subscription.endpoint	http://localhost:	Agent URL that will be used in subscriptions in the
	8082/data/federated/	remote Sentilo instance.
federa-	secret-callback-key-	HMAC secret used for incoming subscription.
tion.subscription.secret.key.callbac	kchange-it	
federa-	3	Number of retries used for subscription
tion.subscription.max.retries		
federa-	5	Delay used for subscription
tion.subscription.max.delay		


Further configuration of the agent is available in the "Federation services" menu.

The menu is available when running Tomcat with the option:

-Dsentilo.federation.enabled=true

The "Client application token" input is the token created in the emitting Sentilo instance:

5.1. Agents 93



## 5.1.6 Kafka agent

#### **Description**

The Kafka agent publishes Sentilo events to Kafka.

#### Configuration

Kafka Agent's configuration is in file sentilo/sentilo-agent-kafka/src/main/resources/properties/sentilo-agent-kafka.conf.

Property	Default Value	Description
kafka.bootstrap.servers	localhost:9092	Comma-separated list of Kafka brokers
zookeeper.nodes	localhost:2181	Comma-separated list of Zookeeper nodes
kafka.request.timeout.ms	30000	
kafka.linger.ms	100	Milliseconds before the contents of buffer are sent or until batch fills up, whichever comes first.
kafka.batch.size	20000	Number of bytes of internal buffer. If the size fills up before, contents are sent to Kafka,.  Otherwise contents are sent once kafka.linger.ms passed.
sentilo.agent.kafka.topic.prefix	sentilo	Topics in Kafka will start with following prefix. May be left blank
sentilo.agent.kafka.topic.separator		The compound name of topic in Kafka will be separated with this string.
sentilo.agent.kafka.topic.nameMode	topicPerSensor	Possible values of topicNameMode for the "data" event type: * topicPerSensor: sentilo.data.providerName.sensorName * topicPerProvider: sentilo.data.providerName * topicPerSensorType: sentilo.data.temperature * topicPerMessageType: sentilo.data * singleTopic: sentilo
subscriptions	Regexp pattern on event name that enables including/excluding events	Examples of configuration  /alarm/*,/data/*,/order/*  Subscribes to all events  /data/PROVIDER1/*,/data/  —PROVIDER2/*  Subscribes only to data of 2 providers

## **Compatible versions**

Sentilo has been successfully used in with these versions:

- Kafka 0.11.0
- Kafka 0.10.2

## **5.1.7 Metrics Monitor Agent**

The agent persists internal Sentilo metrics, such as memory usage or number of threads and persists them in Elastic-search.

Elasticsearch template definition for this agent is located in /sentilo-agent-metrics-monitor/src/main/resources/elasticsearch. The template name is *sentilo-metrics* and the index pattern created by the agent is *sentilo-metrics\**.

5.1. Agents 95

The configuration /sentilo/sentilo-agent-metrics-monitor/src/main/resources/properties/sentilo-agent-metrics.conf and it's same as for the *Activity Monitor Agent*. Example configuration:

```
# Endpoint for elasticsearch
elasticsearch.url=http://localhost:9200

# Properties to configure the index process
sentilo.agent.batch.size=1
```


## 5.2 Clients

## 5.2.1 Node-red


Node-RED is a visual programming platform ideal for non-complex integrations and prototyping.

Sentilo plugin is available in Node-RED's marketplace.


Simply search for "sentilo" in Palette configuration:



Following nodes should appear in the nodes palette:



Now, you should be able to use Sentilo from Node-RED. For example:



The package contains documentation on how to use Sentilo nodes. More info at the 'Sentilo library page at Node-RED website https://flows.nodered.org/node/node-red-contrib-sentilo'\_\_.

5.2. Clients 97

## 5.2.2 NodeJS



We provide a Node.js client library that facilitate access to the Sentilo API. The library is no yet a npm package, but you can still use easily. Lastest version of this library is tested with Node 10 and 12.

More information is in this repository: https://github.com/sentilo/sentilo-client-nodejs

There is also a tutorial on how to use this library with Raspberry Pi and GPIO with javascript.

## 5.2.3 Java Client



Sentilo platform includes a Maven artifact sentilo-platform-client-java. Its source code is here. This library is used internally by Sentilo and its agents.

You can check the tutorial of 'how to create creating sample web application /tutorials/java\_client\_tutorial.html'\_\_. The example uses Spring MVC and can be deployed on a Tomcat. The code of this tutorial is available at https://github.com/sentilo/sentilo-client-sample-java.

Regardless of the example, the library can be used in any Java application. Its dependencies are tiny and is framework-agnostic.

## 5.2.4 Arduino



Arduino client HTTP Request library is available here: https://github.com/sentilo/sentilo-client-arduino

There's also a tutorial on Arduino with Sentilo. The source code for the tutorial is available here: https://github.com/sentilo/sentilo-client-arduino

## 5.3 Cloud

#### 5.3.1 AWS S3

The AWS S3 can be used together with Sentilo, if your solution needs to upload files such as audio snippets, images or files in general.

Sensor can publish links to multimedia files. If these links are always public, catalog will preview them without any additional configuration.


If these media links are private and managed by S3, catalog needs these properties in the file sentilo-catalog.conf:

**Note:** Sentilo is is currently using path-style API requests.

Note: Sentilo is probably compatible with variety of S3-like platforms on the market that implement the S3 interface.

In the end, you will be able to visualize private links in S3, for example:

5.3. Cloud 99



# CHAPTER 6

## Catalog and Maps

The Catalog is a web application that enables you to administer, rule and monitor the Sentilo platform resources and activity. In this section, you will learn how to manage Sentilo resources and how to monitor its activity.

Contents:

## 6.1 Map Viewers

In the publicly accessible section of the Catalog, Sentilo offers two different map viewers that display data in real-time, as they are being published in the system.


Both viewers are accessible from the Explore item at the top menu bar (Universal viewer and Route viewer).

#### 6.1.1 Universal viewer

The map system is prepared to be displayed through various managers and cartography rendering servers. The default system is *Open Street Map* powered by *Leaflet*. You can find more information in the section *Map Providers* 

#### **Components map**

The catalog provides a default map, which shows all the public components registered at the platform. If the user is logged as administrator, all the private components will be displayed as well.




## **Component types filter**

On this page, you can filter the components to show by selecting a component type by clicking on the left top menu




button

, that will expand the left sidebar:




From here, you can select or deselect **component typologies** and **categories** (a *category* is a grouping of typologies), and or select / unselect all the categories / typologies (by checking / unchecking the *All* checkbox).

### Check All:




6.1. Map Viewers

#### Uncheck All:



In addition, it is also possible to perform a search within the typology tree. Writing in the upper text field we will obtain a list of only those typologies that match the searched text:



**Note:** The **organization by categories** is achieved through the *tags of the component type*. That is, a typology belongs to each of the categories added as tags to that typology. For more information, consult the section: Component types

### Map controls


Apart from the button to open the left sidebar, on the universal map we have 6 more buttons, all located on the right side.

In order from top to bottom:

- Search on map (magnifying glass icon): hover your mouse over this icon to display a text field with which you can search for an address or point of interest on the map, which will be centered after the correct result
- Locate me (arrow icon): locate your position on the map (requires location permissions on the browser)
- Maximize/Minimize map (axpand/unexpand icon): maximize or minimize the map in full screen (F11 effect)
- Zoom in / Zoom out (plus / minus icons): zoom in or out on the map
- **Change map layers (layers icon)**: changes the layer represented on the map (it will show each of the layers configured in the catalog application, see *Map Providers*)

### **Component concentration**

In case there is a high concentration of pois in the same point, the map will show a considerable agglomeration of them:



There is the particularity that if you click on one of them, the whole set of pois in esperial will open, to be able to select them in a simple and clear way:


6.1. Map Viewers 105



# **Component details**

# **Sensors list**


When you select a component, a popup window is opened above the map and displays the list of sensors related to it with the last activity for each one of them (as noted above, the private sensors will be displayed only for logged users):




# Sensors last activity view


If you click into the content area of the popup window, a new page is open displaying some basic details about the component, and a time-series graph with the last activity of each of its sensors:

6.1. Map Viewers



You may also click the bottom-right corner icon shareable, i.e. it is possible to send it by email.





# Navigate the last data chart

You can navigate along the dates of the graph by using the buttons located in the lower right corner of it:



- **left arrow**: navigate to the past (only if there are older data)
- reload data (center button): reload last data / reset chart data
- right arrow: navigate to the future (only if you have navigated or gone into the past before)

### Displaying complex data


In some cases, you may want to inform **complex data** as an observation on Sentilo, such like a large json object. For these cases, Sentilo will detect that the text is a json object and then it will be shown to you as a prettify json value:



You can expand or compress the prettified json with the bottom buttons under the status field.

### 6.1.2 Route viewer

As the name suggest, the route viewer is a specific map that shows the routes followed by the mobile components (keep in mind that only the last 20 points are displayed for each route):



The same features described previously apply on this map and its markers (popup window, ...), but with the particularity that if you click over a *route point* then the popup window displays sensor activity related to the time instant in which component was at that location.

6.1. Map Viewers 109



# 6.1.3 Background map configuration

### **Center and Zoom**

Each Organization can have it's own map center and zoom level. Please refer to corresponding part in the Administration Console section: Organization Map configuration

## **Map Providers**

For all background maps, you can use either Leaflet (by default) or other map provider. Through the latter you can consume any OGC WMS/WMTS service that provides a EPSG 3857 SRID.

The configuration is in /sentilo-catalog-web/src/main/resources/properties/sentilo-catalog.conf.

Example of using Google Maps provider (you must provide the Google Maps Key):

```
# Google API key to use Google Maps
sentilo.catalog.map.provider=gmaps
sentilo.catalog.map.google.key=
```

Example of the default Leaflet maps configuration, using a public Open Street Maps WMS service:

(continued from previous page)




**Note:** If you insert multiple layers in the *catalog.map.wms.layers* property, a layer selector in the bottom-right corner of the map will appear.

# 6.2 Administration console


The administration console is composed of several CRUDs used to maintain all the entities of the Catalog such as providers, components, sensors, users, ... Only registered users can access it, so you must be logged before starting to manage the Catalog (the login access is located at the top right menu bar). Remember that, by default, the admin user has admin/1234 as access credentials.

All admin pages follow the same structure and layout for ease of use and to facilitate future maintenance. Therefore, below there is only a brief description of each admin page rather than to repeat the same things over and over in every section. In these sections will focus only on the particularities of each one.


When you select any option of the menu admin, the first page that you will see will be a list with the resources of this type already registered on the Catalog. These lists are very intuitive and extremely easy-to-use: you could filter, page and order it. You could delete an existing resource selecting the corresponding checkbox and clicking the *Delete selected* button; you could add new resources selecting the corresponding button and you could edit anyone clicking over the corresponding row.



When you select to add a new resource, a traditional form page is displayed. Here, you must have filled in the mandatory fields before clicking the *Save* button. If some mandatory field is not filed in or it have a no valid value, the page shows you information about what is wrong:




Otherwise, the resource will be registered into the Catalog and you will be redirect to the list page (at the top right




corner you will see a confirmation message that the resource have been successfully created):


The same applies when you try to delete a resource, but with the peculiarity that the browser will always ask for your confirmation before deleting it:



If the resource has been successfully removed, the list is reloaded and a confirmation message is displayed at the top right corner:



Otherwise, you will see an error page with a description about what is wrong. For example, if you try to delete a component type that is associated with an existing component the response will be:




# 6.2.1 Organization

The organization is the entity that describes the Sentilo instance.

# Detail


By default, this organization is created and its identifier is sentilo.



We can also edit the organization's name other contact details, except the.

# **Config params**

In addition, we can edit the visualization formats and public map settings, using the Config params tab:



There we can configure the Visual configuration and the Map configuration.

# Visual configuration

These params will apply to the entire catalog application visual customization, and how the user will see the data. Note that time zone & date format are directly relationated.


Prop-	Description	Comments
erty		
Time	Defines the time zone of the organiza-	You can define hourly difference or time zone abbreviations:
zone	tion, and modifies the way to display	CET, UTC, +001
	data on screen, such as dates	
Date	Defines the date format with which the	Example: dd/MM/yyyy HH:mm:ss = 30/11/2017 15:34:56
format	data will be displayed in the application	See all possible formats as Java Date Format, at: Java Date
	(lists, details)	Format
Chart	Number of observations displayed on	It must be a positive integer number greater or equals to 10.
values	chart	If blank, it will be a default value of 10. This value will be
number		overwritten by sensor's configuration one.

# **Map configuration**


These params configure the universal map visualization.

Property	Description	Comments
Zoom	Zoom level of the univer-	Default value is 14. And you can define a value between 1 and 20.
level	sal map	See possible values in: https://developers.go ogle.com/maps/documen
		tation/static-maps/in tro#Zoomlevels
Latitude	Defines the map center in	
/ Longi-	latitude & longitude val-	
tude	ues format	
Map	Define the background	Possible values applies with the colorpicker, or input a valid css / html
back-	color of the map	color value
ground		
color		

For example, set the map background color to #ffc900:




## will result in:



# **6.2.2 Users**

The "Users" section is for managing users of the catalog application. It's possible to A catalog user can be one of these three roles:

- Super Admin: role for super-administration purposes (for *multitenant* version only).
- Admin: role for administration purposes.
- User: visualisation role, they could access to the administration console and read all the data, but they haven't permission for changing anything, except own contact details and password.
- Platform: platform role for internal use (hidden, non selectable).




**Note:** A non-admin account will only see a menu "User" with his/her own details. A User role cannot see list other users.

### User properties editable by administrator

ld	Name	Description
Id	User identifier	After its creation can't be modified
Password	Password	Admin user can rewrite user's password
Repeat	Password check	
Name	User name	
Description	Description	
Creation date	Creation date	Automatically generated
Update date	Last update date	Automatically generated
E-Mail	User e-mail	
Active	Checkbox for removing access	
Role	Related role	Value list

### **Edit a User**



**Note:** A password has to have 8-10 characters, and have at least 1 uppercase, 1 lowercase and 1 digit.

# 6.2.3 Applications


Applications are the data clients of the Sentilo platform and, by default, if you have loaded the default data, you will see two applications registered into the Catalog:

• **sentilo-catalog**: it is a internal application, used by the catalog to make calls to the API REST and therefore MUST NOT be removed.

• testApp: as the name suggest, this application is used for testing the platform status.

### List

Access the Application list. This is the main Application page. From here you'll can access to the desired application to show its details by click on it.




You'll be able to list, filter, show application details, create (*New application* button) and delete selected applications (select from left checkbox, and apply by *Delete selected* button).

Further, you'll be able to export the list to Excel, by clicking on *Export to Excel* button. The result file will contain the list columns and a number of extra ones from internal database use.

Use the button panel at the bottom right to navigate through the list (first page, previous page, page number, next page and last page, respectively).

### **Details tab**

The detail page is structured into three tabs:




#### where:

- the *Details* tab contains the main properties of the application (described below).
- the *Permissions*tab allows to manage the permissions for other entities (applications or providers)
- the Active subscriptions tab displays a list with all the active subscriptions for the current application.

The main properties of the *Details* tab are the following:

Property	Description	Comments
Id	Application Identifier	Mandatory. After its creation it can't be modified. It is the identifier used in the API calls.
Name	Display name	If not filled in by the user, its default value will be the <i>Id</i> .
Token	Access key	Automatically generated by the system when application is created. It is the identity_key value used in the API calls. NOTE: only users with ADMIN role will show the entire token chain, other user roles only will see obfuscated text at this place (see below)
Description	Description	Optional. The application description text.
Force HTTPs	Application accepts data over HTTPS	The Sentilo Server itself does not support SSL at the moment, however you can put a reverse proxy such as Nginx in front of the Sentilo Server. If this option is checked, the Sentilo Server expects the standard header
		X-Forwarded-Proto Please note that when configuring Nginx, you should also use the parameter
		underscores_in_hea ders on; so Nginx would forward sentilo
Active	Indicates if the resource is active or not (if it is not, it will not accept any type of interaction nor will it be shown in other sections) person responsible for the application	headers to the Sentilo Server.
Input quota	Max number of inputs per hour (set to 0 to don't limit it)	Optional, 0 indicate unlimited quota (see <i>Rate Limiting</i> )
Output quota  Max number of outputs per hour (set to 0 to don't limit it)		Optional, 0 indicate unlimited quota (see <i>Rate Limiting</i> )
Creation date Creation date		Automatically generated
Updates date	Last update date	Automatically generated
Contact name	The name of the person responsible for the application	Mandatory.
Contact email	Email address of the person responsible for the application	Mandatory.

How users that has not ADMIN role see the detail section:



#### **Permissions tab**


As commented before, the *Permissions* tab allows you to define and manage the authorization privileges that are granted to an application (such privileges are named *permissions*) which are required for access to the data from other entities.

There are 3 possibles permissions:

- Read: Only allows to read the data but not modify it (e.g. cannot publish orders to sensors/actuators).
- *Read-Write*: allows to read and write data over the resources of an entity, but not administer them (e.g., cannot create new sensors for a provider)
- Administration: full control over an entity and its resources.

By default, the application sentilo-catalog has granted the Administration permission over all entities registered into Catalog and, as you would expect, an application has full control over itself.

For example, at the following case where the permissions of the application *testApp* are displayed:




We will see the following:

- The application *testApp* could administer the entity *testApp* (obviously!)
- The application *testApp* could read any data from the entity *testApp\_provider*.


## **Active subscriptions tab**

This tab allows you to inspect the subscriptions that an application has registered on the platform (remember that subscriptions are [created with the API REST](./api\_docs/services/subscription/subscription.html)), as shown in the following picture:




# 6.2.4 Providers

In Sentilo, providers are those who send data, i.e. those who publish the data (in contrast to applications, which consume the data). If you have loaded the default data, you will see one default provider registered into the Catalog:




- testApi\_provider: as the name suggests, this provider is used for checking platform api status.
- testApp\_provider: as the name suggests, this provider is used for checking catalog application status.

One singularity of the providers list is the *Delete* action: **if you remove a provider, not only the provider will be deleted from the backend, but also all its related resources** such as components, sensors, alerts ... and any data published by its sensors, **so be very careful with this command**.



### List

Access the Providers list. This is the main Provider page. From here you'll can access to the desired provider to show its details by click on it.




You'll be able to list, filter, show provider details, create (*New provider* button) and delete selected providers (select from left checkbox, and apply by *Delete selected* button).

Further, you'll be able to export the list to Excel, by clicking on *Export to Excel* button. The result file will contain the list columns and a number of extra ones from internal database use.

Use the button panel at the bottom right to navigate through the list (first page, → previous page, page number, next page and last page, respectively).

### **Details tab**

The detail page of a provider is structured into five tabs:




#### where

- The *Details* tab contains the main properties of the provider (described below).
- The *Sensors/Actuators* tab displays a list with all sensors owned by the current provider (i.e. associated with this provider).
- The Components tab displays a list with all components owned by the current provider.
- The Active subscriptions tab displays a list with all the active subscriptions for the current provider.
- The *Documentation* In this tab you can upload any files relevant to provider, such as a maintenance guide, etc.

The main properties of the *Details* tab are the following:


Property	Description	Comments
Identifier	Provider identifier	Mandatory. After its creation can't
		be modified. It is the identifier used
Name	Display name	in the API calls.
Name	Display name	If not filled in by the user, its default value will be the <i>Id</i> .
Authorization Token	Access key	Automatically generated by the sys-
		tem when application is created. It is the* identity_key* value used in
		the API calls. NOTE: only users
		with ADMIN role will show the en-
		tire token chain, other user roles
		only will see obfuscated text at this
		place (see below)
Description	Description	Optional. The provider description text.
HTTPS API REST	Provider sends data over HTTPS	The Sentilo Server itself does not
III II S / WI KLSI	Trovider serius data over 111 11 5	support SSL at the moment, how-
		ever you can put a reverse proxy
		such as Nginx in front of the Sentilo
		Server. If this option is checked, the
		Sentilo Server expects the standard header
		X-Forwarded-Proto
		Please note that when configuring
		Nginx, you should also use the pa-
		rameter
		underscores_in_hea
		ders on;
		so Nginx would forward sentilo headers to the Sentilo Server.
Contact name	Name of the person responsible for	Mandatory
	the provider	No. 1
Contact email	Email address of the person respon-	Mandatory.
	sible for the application	

How users that has not ADMIN role see the detail section:



### Sensors/Actuators tab

As mentioned before, this tab displays a list with all sensors associated with the current provider, as shown in the picture below where the sensors of the provider CINERGIA are listed:



You could filter, page and order the list but you cannot access to the sensor detail: it must be done from the sensor list administration.

# Components tab

As explained early, this list is very similar to the previous one but with components.

### Active subscriptions tab

The meaning of this tab is the same as described for the applications.

#### **Documentation tab**


In this tab you can upload any files relevant to provider (up to 4MB each). The documents in total should not surpass ~16MB, which the limit of MongoDb.

### 6.2.5 Sectors

In Sentilo, resources are managed through applications and providers, globally, through an administrator user. In the case of a multi-tenant instance, in the same way, it will be the entity's administrator user who will be able to manage said resources, but only within his own entity.

But you can also do this using resource groups. It is the management called "by sectors" or "delegated administration". In this type of administration, one or more users are given the ability to manage a group of resources, called a "sector", so that the responsibility does not always fall on a single administrator. In this way, a user becomes a sector administrator when they are associated with a resource group or sector.

#### List




For example, we can divide all the resources and devices, of a Sentilo entity or instance, into several groups that unify their purpose. In the example above we can see three groupings: buildings, citizens and traffic. This type of partitioning could describe a small pool of resources in a smart city that Sentilo has access to:

- buildings: smart building data processing
- citizens: treatment of the use of roads, detection of passage and occupation of streets and avenues
- *traffic:* treatment of the occupation and use of public roads on which vehicles circulate, detection of passage, capacity of vehicles, etc...

In short, we will call a "sector" to a group of applications, providers and all the resources that they encompass, and that can be managed by one or more users.


A sector is defined by its identifier, its name and its description:




ld	Name	Description
Id	Sector identifier	After its creation can't be modified
Name	Sector name	
Description	Sector description	

The date and time of creation and modification are generated automatically.

Sectors can only be created and managed by admin users:




#### then:



#### Sector users

The users of a sector are added from the "Users" tab.


Click on "Add" and then a modal popup will appear:



From this window we can add one or several users, registered globally in the instance, as administrators of the sector. In the case of multi-tenant, we can only add users from our own entity.


## Sector providers

They are found in the "Providers" tab, and they are the providers that a sector can manage.



To add or remove providers to the sector, we must access the tab and click on the add or remove buttons, as needed.


To add a provider to the sector, we will click on the "Add" button, and a modal popup window will appear from which we can select the provider and the level of access we wish to grant (read only, or administration):



From now on, the sector will be able to manage these providers with the level of permissions selected.


### Sector applications

They are found in the "Applications" tab, and they are the applications that a sector can manage.



To add or remove applictions to the sector, we must access the tab and click on the add or remove buttons, as needed.

To add an application to the sector, we will click on the "Add" button, and a modal popup window will appear from which we can select the applications and the level of access we wish to grant (read only, or administration):




From now on, the sector will be able to manage these applications with the level of permissions selected.

### Access as sector user

Since a user is added to a sector, this user will only be able to see the resources that were added to that sector. Let's remember the user "building\_user".


This is how we would see the detail of the user:




Notice the last parameter, named "Associated sectors" which indicates to which sectors it belongs.

Therefore, if we access the lists of providers and applications, we can only see those resources that have been assigned to us to be managed within our sector, and their granted permissions:

# **Applications list**



# **Providers list**



From this moment on, the user of the sector will be able to manage the resources of the sector with the previously granted permissions.

# 6.2.6 Components

Within the context of Sentilo, components have a special meaning: they are not linked to the API REST (except for the catalog service), i.e., components are not required to publish or read data. We use components in Catalog to group together sensors sharing a set of properties, such as location, provider, power or connectivity.


You could think of them as physical devices with a set of sensors, like a weather station or a microcontroller, with multiple sensors connected. But not necessarily a component needs to have sensors physically connected to it. A gateway could also be modeled as a component: you could have a wireless sensor network (WSN) where each sensor sends data to a gateway and then it sends data to Sentilo using its Ethernet/WiFi/.. connection. In this case, the gateway will also be a *component*. And finally, if you have a sensor that connects to Sentilo directly then you will have a component with only one sensor.

In short: in Sentilo, a sensor always need to be related to a component and providers have its sensors grouped by components, as shown in the following picture:



### List

One singularity of the components list page are the two buttons that allows us to change the visibility of a set of components from *public* to *private* and vice versa. These buttons apply on the selected rows.




You'll be able to list, filter, show components details and create (*New component* button). Like with the providers list, the component list have a *Delete* button that works as follows:\* *if you remove a component, not only the component will be deleted from the backend, but also all its related resources will be deleted*\* such as sensors, alerts ... and any data published by its sensors, **so be very careful with this command**.

Further, you'll be able to export the list to Excel, by clicking on *Export to Excel* button. The result file will contain the list columns and a number of extra ones from internal database use.

Use the button panel at the bottom right to navigate through the list (first page, ⊔ → previous page, page number, next page and last page, respectively).

### **Details tab**

The detail page of a component is structured into five tabs:



### where:

- The *Details* tab displays the main properties of the component.
- The Technical details tab displays several categorized properties of the component.
- The *Additional information* tab displays custom properties of the component which are not predefined by Sentilo. See the parameter additionalInfo of the API docs
- The Related components tab shows other components linked with the current component .
- The Sensors/Actuators tab shows the sensor element located in the current component.

The main properties of the *Details* tab are the following:

Prop-	Description	Comments
erty		
Name	Display name	Mandatory. After its creation can't be modified. It is the identifier used in the API calls.
Type	Component type.	Mandatory. Select from a list of available types.
De-	Description	Optional. The component description text.
scrip-		
tion		
Provider	Component owner	Mandatory.
Photo	URL of the component photogra-	It could be defined for each component or it will be inherited using
URL	phy	the defined one for the component type.
Ex-	Define an external details page	Here you can inform an external url that will replace the default
tended	for the component type	details component page
URL		
Access	Checkbox to set the component	
type	visibility as public or private in	
	the viewer	
Cre-	Creation date	Automatically generated
ation		
date		
Update	Last update date	Automatically generated
date		
Tags	Related custom tags of the com-	Are displayed at the public page
	ponent	
Static	To mark the component as static	If the component is static then location is mandatory
or	or mobile	
Mobile		
Ad-	Address where the component is	The address, longitude and latitude fields work together with the lo-
dress	located	cation list field. It's possible to use the map to set the points adding
		new locations.
Lati-	Latitude in decimal format	
tude		
Longi-	Longitude in decimal format	
tude		
Loca-	Location/s of the component	You can configure the component as a POI, a polyline or a polygon
tions		(future feature) depending the location composition.
List		

# **Technical details tab**

As noted above, this tab displays a set of properties related to the technical details of the component such as manufacturer, serial number, . . . .

# test\_component

Details Technical details Additional information Related components Sensors / Actuators

Data

Producer Solar devices

Model So120

Serial number S2E0195

MAC 0080:D0:63:C2:26

Power type 220VAC

Connectivity type 36

#### where:

Property	Description	Comments
Producer	Manufacturer	
Model	Component model	
Serial number	Serial number	
MAC	Mac address of the device	
Power type	Energy type used by the device	Select from a list of available values (see the API for de-
		tails)
Connectivity	Connection type used by the de-	Select from a list of available values (see the API for de-
type	vice	tails)

### **Additional information tab**

This tab displays the set of additional properties related to the component. See the parameter componentAdditionalInfo of the API docs.

These fields are not categorized, i.e., here you could stored any device information which will be of interest.

For each property, it will be displayed as a *label-value* entry where the property's key will be the label and the property's value will be the value, as shown in the following picture:


### test\_component



where the following map, stored on the backend, has been rendered

```
"State": "Spain",
"City": "Barcelona",
"Location": "Right next to the fire hose"
}
```

It is also possible to edit these parameters from the catalog application, in editing mode:



#### Sensors/actuators tab

The meaning of this tab is the same as for the providers, but restricted to the current component.


# 6.2.7 Sensors

These section is used for creating, updating or deleting sensors or actuators. Usually these elements are created by the provider autonomously using the API.

The sensors list page follows the same structure as described for components (you could change the public/private visibility or delete sensors massively through the list).

## List

It is possible to full-text search the list in the "Filter" box. The filter works for all filter attributes except the creation date. The Filter field is case-sensitive. Only search by the substate's code is possible at the moment.




You'll be able to list, filter, show sensors details, and create (*New application* button) and delete selected sensors (select from left checkbox, and apply by *Delete selected* button).

Further, you'll be able to export the list to Excel, by clicking on *Export to Excel* button. The result file will contain the list columns and a number of extra ones from internal database use.

Use the button panel at the bottom right to navigate through the list (first page, previous page, page number, next page and last page, respectively).

### **Details Tab**

The detail page of a sensor is structured into four tabs:



where


- The *Details* tab displays the main properties of the sensor.
- The *Technical details* tab displays several categorized properties of the sensor.
- The Additional information tab displays the custom properties of the sensor.
- The *Latest data* tab shows the latest observations received from the sensor.

The main properties of the *Details* tab are the following:

Property	Description	Comments
Sensor / Actuator	Name of the sensor/actuator.	Mandatory. After its creation can't be modified. It is the identifier used in the API calls.
Provider	Sensor provider owner	Mandatory
Description	Description Description	- Triandatory
Component	Component to which the sensor belongs	Mandatory
Access type	Checkbox to set the sensor visibility to public or private	
Creation date	Creation date	Automatically generated
Update date	Last update date	Automatically generated
Type	Sensor type	Mandatory. Select from a list of available types
Data type	Type of data published by the sensor	Mandatory. Possible values are:
Unit	Measurement unit	
Time zone	Time zone for the data sent by the sensor	
Tags	Related custom tags of the sensor	
State	State of the sensor	Possible values: online   offline. If the sensor is configured as offline the API will reject any data publica- tion, the alerts will be disabled and the sensor won't be visible in the map. Likewise, offline sensors are excluded from the /catalog GET re- quest. Default value is online.
Substate	Substate of the sensor	The list of possible values that have informational purpose and are specific for every deployment. You can customize the list of possible substate values editing the contents of table sensorSubstate in mongoDB. No default value.
TTL (min)	Time of expiration of sensor's data in minutes	This value can be configured only from the catalog, Only admin should control this value. The default value is the sentilo.redis.expire.key.seconds parameter from the sentilo.conf file (expressed in secods)

### Technical details tab

As noted above, this tab displays a set of properties related to the technical details of the sensor ( such as the *manufacturer*, the *model*, the *serial number* and the *power type*, all of which are described in the component section) as shown in the following picture:



### Visual configuration tab

The only configurable option in this tab is "Chart values number". This integer indicates how many measures will be show in the observation chart of the sensor.

### Additional information tab

The meaning of this tab is the same as for the *components*.

This tab displays the set of additional properties related to the component See the parameter additionalInfo of the API docs.

These fields are not categorized, i.e., here you could stored any device information which will be of interest.

For each property, it will be displayed as a *label-value* entry where the property's key will be the label and the property's value will be the value.

Once again, it is possible to edit them from the catalog as we have done with the component.

### Latest data tab

This tab, as shown in the following picture:

# test\_sensor ID: testApp\_provider.test\_component.test\_sensor Details Technical details Visual configuration Additional information Latest data Last data Date 10/10/2022 11:06:20 Data type Numerical Measurement unit °C Value 16.82 Back Activity

End date: 10/10/2022 11:06:45

displays both the latest observation published by the sensor and a graph with its last activity.

Start date: 10/10/2022 11:06:03

Navigate the last data chart

< 2 >

You can navigate along the dates of the graph by using the buttons located in the lower right corner of it:

\_static/images/catalog\_and\_maps/catalog\_and\_maps/chart\_controls.png

- **left arrow**: navigate to the past (only if there are older data)
- reload data (center button): reload last data / reset chart data
- righth arrow: navigate to the future (only if you have navigated or gone into the past before)

Number of chart observations at chart


You can change the number of values shown in the graph. To do this, within the sensor editing tabs, go to "Visual configuration", and there edit the value of the "Chart values number" field

# Edit sensor Details Technical details Visual configuration Additional information Visual configuration Chart values number

You must inform a positive value number. If blank, then default value shall be applied as that has been configured in the organization visual configuration.

### Showing complex data

If your sensor data type is text, and it contains a complex data in json format, Sentilo will show it as a prettified value:



in this case you will have the possibility to inspect, expand or contract the json map shown as a value using the navigation buttons:

**Collapse data:** the json map will be collapsed at all



**Expand data:** the json map will be expanded at all (default view)



**Collapse to level X:** insert a correct value for the X, and click the button to collapse to the specified level (default level is 0, first level)



### 6.2.8 Alerts

Used for managing internal or external Alerts. Usually, external Alerts are created by a third party autonomously via the API. This third party could be a provider or application. Internal Alerts can be defined from the console or using


the API. Internal alerts will always be associated to a provider.

It's also possible to delete the items massively from the alerts list.


### **Create alerts**

Thare are two types of alerts, and them has its own properties.

### **External alert**



### **Internal alert**




### **Properties**

ld	Name	Description
ID	Alert identifier	After its creation can't be modified
Name	Display name	
De-	Description	
scrip-		
tion		
Active	Indicates whether the alert	When a sensor goes into the offline state, the associated alerts are also
	is activated or not	automatically deactivated.
Cre-	Creation date	Automatically generated
ation		
date		
Update	Last update date	Automatically generated
date		
Type	Alert type	Internal/External
Provider	Related provider	For external alerts, a provider which will generate the associated alarms.
		For internal alerts, the related data provider.
Appli-	Related provider	Only for external alerts, application which will generate the associated
cation		alarms
Compo-	Related component	Only for internal alerts
nent		
Sensor	Related sensor	Only for internal alerts
Trigger	Type of trigger that will be	Only for internal alerts. Value list, see the API for details
type	applied	
Expres-	Expression to be evaluated	Only for internal alerts
sion		

### List

Access the Alerts list. This is the main Alert page. From here you'll can access to the desired alert to show its details by click on it.




You'll be able to list, filter, show alerts details, create (*New alert* button) and delete selected alerts (select from left checkbox, and apply by *Delete selected* button).

Further, you'll be able to export the list to Excel, by clicking on *Export to Excel* button. The result file will contain the list columns and a number of extra ones from internal database use.

Use the button panel at the bottom right to navigate through the list (first page, previous page, page number, next page and last page, respectively).

### Filtering the alerts list

It is possible to full-text search the list in the "filter" box. The field is case-sensitive. That means that you can search for full or partial text contained in the identifier, type, trigger or status field. If you want to search for certain trigger type, currently only searching by trigger type's code is possible (e.g. a search for "GT" would return results in the above screen, whereas a search for "GT(40)" wouldn't).




### 6.2.9 Alerts creation rules

It is possible to bulk-create alerts for a group of sensors. For example, attach a rain alert rule to all pluviometers of certain provider.

### List

Accessing "Alert creation rules" menu option opens a list of existing Alert Rules.




You'll be able to list, filter, show alert rules details, create (*New rules* button) and delete selected rules group (select from left checkbox, and apply by *Delete selected* button).

Further, you'll be able to export the list to Excel, by clicking on *Export to Excel* button. The result file will contain the list columns and a number of extra ones from internal database use.


Use the button panel at the bottom right to navigate through the list (first page, previous page, page number, next page and last page, respectively).

### **Create rules**

To create new alerts, use the "New Rules" button.



After pressing the "Confirm" button, a modal window will inform on how many alerts will be created for given combination of provider, component type and sensor type.




Subsequently, alerts are created, all having the same rule. At the moment it is not possible to bulk-create alerts without specifying the provider.

To bulk-delete alerts with associated with a particular rule, just select the item from the Alert Rule list and press Delete.

### 6.2.10 Active Subscriptions

Active Subscriptions is a handy section that gives a view of situation of the subscriptions to Sentilo.

The some system subscribes to Sentilo and then is inaccessible for a long time, this creates a unnecessary queue in the system.



## 6.2.11 Sensor types

Used for creating, updating or deleting sensor types. The sensor types should be defined through the administrator console before adding elements to the catalog.


It's possible to delete elements massively through the sensor list.

### **Properties**

ld	Name	Description
Id	Type identifier	After its creation can't be modified
Name	Display name	
Description	Description	
Creation date	Creation date	Automatically generated
Update date	Last update date	Automatically generated

### List

Access the main Type of Sensors / Actuators list page, will show you a complete list of type of sensors.




You'll be able to list, filter, show typologies details, create (*New typology* button) and delete selected typology (select from left checkbox, and apply by *Delete selected* button).

Further, you'll be able to export the list to Excel, by clicking on *Export to Excel* button. The result file will contain the list columns and a number of extra ones from internal database use.

Use the button panel at the bottom right to navigate through the list (first page, previous page, page number, next page and last page, respectively).

### New

Access to create new typology pressing *New typology* button. You must inform an identifier, name and description (optional) for the new typology.




### 6.2.12 Component types

Used for creating, updating or deleting component types. The component types should be defined through the administrator console before adding elements to the catalog.

It's possible to delete elements massively through the component list.

### List

Access the main Component's typology list page, will show you a complete list of available type of components.




You'll be able to list, filter, show typology details, create (*New application* button) and delete selected typologies (select from left checkbox, and apply by *Delete selected* button).

Further, you'll be able to export the list to Excel, by clicking on *Export to Excel* button. The result file will contain the list columns and a number of extra ones from internal database use.

Use the button panel at the bottom right to navigate through the list (first page, previous page, page number, next page and last page, respectively).

### New

Access to create new typology pressing *New typology* button. You must inform an identifier, name, description (optional), photo (optional) and icon for the new typology.



### **Properties**

ld	Name	Description
Id	Type identifier	After its creation can't be modified
Name	Display name	
De-	Description	
scrip-		
tion		
Cre-	Creation date	Automatically generated
ation		
date		
Update	Last update date	Automatically generated
date		
Photo	Related photo	Generic picture for the component type, will be used if there isn't any spec-
URL		ified for the component itself
Ex-	Define an external details	Here you can inform an external url that will replace the default component
tended	page for the component	details page for all componenents of the type, if them hasn't defined its own
URL	type	one
Icon	Related icon	Value list from the deployed icon list. Used in the maps for representing
		the component
Tags	organizational tag	Typology categorization tags list separated by comma / enter. It is used
		to create organizational categories in the Universal Map Viewer typology
		filter tree

**Note:** The extended URL allows to replace the component details, integrating an external page within the general framework of the application. It must be an absolute URL and accessible without authentication (only http or https protocols are accepted). It will be used for all the typology components, except for the ones configuring their own URL. It can include the following wildcards \${component\_id}\$ and/or \${provider\_id}\$, which will be replaced at execution


time.

**Note:** A component typology can contain one, several or no associated tags. For each one of them, the typology will be located within the branch that bears the same name in the filter tree by typology categories in the universal map viewer. If a typology does not contain any tags, this typology will appear in the "Other" category in the filter tree by typology categories of the universal map viewer.


### **6.2.13 Metrics**

The new *Metrics* section provides a real-time monitoring of all Sentilo modules, including agents. This information is useful when you want to rapidly assess the state of the service. However, for production monitoring, we recommend to also setup some process watcher and alerting system.

Example of the timeline:



Example of dashboard:



**Note:** Since the metrics are in real-time only, no history is shown unless you leave the Metrics page open for a while. The page will show graphics for this time. If you reload the page, the history will be reset.

New internal monitor API runs on different port that the Sentilo API. It's port number is configured in /sentilo-platform/sentilo-platform-service/src/main/resources/properties/sentilo-server.conf. The default value is 7081.

monitor.port=7081

The agent Metrics Monitor Agent gathers these metrics and persists them in Elasticsearch.

# 6.3 Statistics page

The public section of the Catalog allows us to display some Sentilo statistics through a set of features/pages which allow us to inspect the current platform activity and to display the components/sensors over a map.

The statistic dashboard, which is accessible from the top menu bar, displays some basic use indicators, like total requests processed, number of sensors registered, current requests per second, max daily average and max average requests per second, ..... These values are automatically updated every 30 seconds.

These values are never being reset, unless you re-create Redis database.

# Sentilo | SmartCities - Sensors and Actuators Platform

Statistic



Requests

1,086,218,312

Requests processed
0 Orders
0 Alarms

Performance

11.2


Requests per second
2 Max. daily average
4,846.66 Max. average

Accounts

1 O

Active users
30 Providers
21 Applications

It also shows a time-series graph which displays the platform activity (such as observations, orders and alarms) for the last 100 minutes. This graph is automatically updated every 5 minutes.



# 6.3.1 Navigate the last data chart

Note: You can navigate along the dates of the graph by using the buttons located in the lower right corner of it:



- left arrow: navigate to the past (only if there are older data)
- reload data (center button): reload last data / reset chart data
- right arrow: navigate to the future (only if you have navigated

or gone into the past before)

6.3. Statistics page

162

Multi Tenant

### 7.1 Introduction

The Multi Tenant feature provides the capacity of creating and managing virtual Sentilo instances related with different organizations(e.g. cities). Every organization has its own context, entities and data, and it can share information with third parties at its will, even it's possible to have different look & feel for every tenant.

Above all the tenants, a new role emerges for administer the platform, manage the organizations and create the necessary users for administer each one. Additionally, the platform can provide additional services to its organizations, like common integrations and offer a single map showing the public information of all its organization.

The Sentilo multi-tenancy model implements level 3 of SAAS maturity model, which offers a good levels of efficiency and scalability balanced with a complexity and a reasonable operational costs:

- Single instance for all the tenants.
- Same software deployed version for all the entities.
- Unique typologies for components and sensors.
- Common data repositories for all the tenants.
- Personalization and access control for entities through admin console.
- Personalization of look & feel for tenants.
- Delegated administration for each entity, allowing them to administer its own data, devices, users and to share data a their will.

After configuring it, every organization has its own virtual Sentilo instance and can be administered autonomously.

### 7.1.1 The Organization concept


The Organizations represent the different entities, usually cities, that owns a virtual Sentilo instance. Every one can manage autonomously its own applications, providers, components and sensors. All these elements are property

of the organization, and nobody outside the organization can access to them, unless the organization grants access permissions to other organizations.

Organizations are administered through the various existing user roles, and according to them, be managed in different ways:

Role	Access type
Super	The Super Admin user can create and administer organizations, users and typologies
Ad-	
min	
Ad-	The Admin user can only manage its own organization parameters and has capacity for creating his own
min	users, applications, providers, components, sensors and alerts, which will be automatically related to its
	organization
User	The User can only access to public information data about the applications, providers, components,
	sensors and alerts which belong to its own organization

Below you can see an organization list from a multi tenant Sentilo instance, when connecting as super admin user:



### 7.2 Sentilo contexts

There are several virtual contexts(URL paths) for a multi tenant Sentilo instance, one for every organization and one for the public common area. It's important to remark that for accessing to each organization console, you should choose the correct path, otherwise you won't be able to access, even using correct credentials.

### 7.2.1 Organization console

You should access to the administration console through the corresponding url address, adding the organization id as a last parameter, as follows.

http://sentilo\_instance\_host[:port]/sentilo-catalog-web/organizationId

In the parameter **organizationId** you should inform the organization identifier where you want access to. For example, we could access to an organization named **Sample Organization**, with a **sample\_organization** as organization identifier in a Sentilo instance deployed in a host with name **example.com**:

http://example.com/sentilo-catalog-web/sample\_organization

### 7.2.2 Platform console

**Super Admin** users should access to the catalog console without informing any organization identifier in the url. In this case, no data is filtered by organization, and all the public information is visible in the public map and statistics:

```
http://your_sentilo_server_ip/sentilo-catalog-web
```

Super Admin users are responsible of configuring the platform organizations and its users, and also to define the component and sensor typologies.

### 7.2.3 Anonymous access

Anonymous users(not logged) can access the universal viewer directly without informing organization in the url. In this case, no data is filtered by organization, and all public information is displayed in the public maps and statistics, using the platform common look & feel.

```
http://sentilo_instance_host[:port]/sentilo-catalog-web
```

In this case, the user will see all the public information provided for the instance organizations.

Alternatively, the users can access to a specific organization public information, specifying a different URL context:

```
http://sentilo_instance_host[:port]/sentilo-catalog-web/organizationId
```

For example, we could access to an organization named **Sample Organization**, with a **sample\_organization** as organization identifier in a Sentilo instance deployed in a host with name **example.com**:

```
http://example.com/sentilo-catalog-web/sample_organization
```

Then the user will see all the public data offered by the Sample Organization, displayed using the organization custom look & feel.

For the rest of it, the features and behaviour of the public area is the same as described in Catalog and Maps section.


### 7.3 Platform administration

Super Admin users are responsible of configuring the platform organizations and its users, and also to define the component and sensor typologies. They cannot see any organization data, such as components, sensors, alerts.

### 7.3.1 Organization administration


### List

Only the **Super Admin** user can *list, create and delete organizations*. After the organization is created, an **Admin** user can edit its own configuration settings. **User** role don't have access to this information.



### **Details**

Below, the organization creation form, as a Super Admin:



In order to create an organization, we must inform, at least, these parameters:

- identifier: an unique organization identifier
- name: the organization name


- contact name: the name of the responsible person
- contact email: the email of the responsible person

Some other parameters are optional:

• description: some description about the organization

### **Config params**

There are some additional parameters for customizing the public & private behavior.



### Visual configuration

These params will apply to the entire catalog application visual customization, and how the user will see the data. Note that time zone & date format are directly relationated.

Prop-	Description	Comments
erty		
Time	Defines the time zone of the organiza-	You can define hourly difference or time zone abbreviations:
zone	tion, and modifies the way to display	CET, UTC, +001
	data on screen, such as dates	
Date	Defines the date format with which the	Example: dd/MM/yyyy HH:mm:ss = 30/11/2017 15:34:56
format	data will be displayed in the application	See all possible formats as Java Date Format, at: Java Date
	(lists, details)	Format
Chart	Number of observations displayed on	It must be a positive integer number greater or equals to 10.
values	chart	If blank, it will be a default value of 10. This value will be
number		overwritten by sensor's configuration one.

### Map configuration

These params configure the universal map visualization.


Property	Description	Comments
Zoom	Zoom level of the univer-	Default value is 14. And you can define a value between 1 and 20.
level	sal map	See possible values in: https://developers.go ogle.com/maps/documen
	_	tation/static-maps/in tro#Zoomlevels
Latitude	Defines the map center in	
/ Longi-	latitude & longitude val-	
tude	ues format	
Map	Define the background	Possible values applies with the colorpicker, or input a valid css / html
back-	color of the map	color value
ground		
color		

### 7.3.2 Users administration

The Super Admin user can create, edit and delete any user from any Organization whatever role they have. In Addition, Super Admin role is the unique user role that can create additional Super Admin users.

In a multi tenant instance, except for Super Admin users, when creating users, it's mandatory to specify the related organization.


### List




### New user

### **Details**

The next image shows how the new user's form is:



Alternatively, we can inform some configuration params that will modify the catalog visualization for this user:



These params will apply to the entire catalog application visual customization, and how the user will see the data. Note that time zone & date format are directly relationated.

Prop-	Description	Comments
erty		
Time	Defines the time zone of the user,	You can define hourly difference or time zone abbreviations: CET,
zone	and modifies the way to display	UTC, +001 Example: dd/MM/yyyy HH:mm:ss = 30/11/2017
	data on screen, such as dates	15:34:56* Note that this value overrides the organization's one, if in-
		formed*
Date	Defines the date format with	See all possible formats as Java Date Format, at: Java Date Format Note
for-	which the data will be dis-	that this value overrides the organization's one, if informed
mat	played in the application (lists,	
	details)	

### 7.3.3 Component and Sensor types administration

Only the Super Admin user can administer the components and sensor types. In this case, the behaviour is the same like for a normal Sentilo instance.

See more information about it in the Catalog and Maps section.

### 7.4 Tenant administration


Admin role users are directly related with an specific organization. They are the only ones who are able to administer the organization private data, such as its providers, applications, components, sensors and alarms. They can also manage its own users. The admin users will also be capable of seeing all the defined component and sensor typologies, but they wont be able to modify them.

Basically, the only difference between the simple Sentilo instance and a Multi Tenant instance version is that only users from one organization can see and access to information from its own organization. It's also possible to share information with another organizations, as described later. This data isolation make possible taking advantage of user and organization hierarchy.

Below, we review the specific behaviour of tenant administration, remarking is specificities. For more information, you can read the Catalog and Maps section section.

### 7.4.1 Organization administration

Admin users can only manage its own organization information.




Alternatively, Admin user can manage their config params and third party from/to permissions for sharing information purposes. You'll find them in the two last tabs that located in the top of the detail section.

### Permission administration


© Barcelona Council 2013

### **Permissions list**




### **Adding permissions**

Adding to third party read & write permission:




Response upon permission has been created:



In this case we had granted **read&write** permissions from our organization and our provider **sample\_provider** to third party organization named **Sentilo**. So, now the Sentilo organization can access to the sample\_provider data and manage it (publish data).

In the other side, the Sentilo organization can see these permissions in the second tab, *Permissions from others*:



And now, from this tab, we can change the permission visibility on the map. Simply select the checkbox from the permission and click on **Show in map** or **Hide in map**.

When sharing providers with other organizations, their related entities(providers, components, sensors), will appear on the other tenant console, but only in read mode.

# 7.5 Tenant resources administration: unique identifiers


Resources related to a tenant, such like *providers* and *applications*, must have unique identifier into a Sentilo instance. But, in a multi tenant instance, it is possible to repeat it identifier, based on its tenant. So tenant resources are completely independent between their tenants.

Multi tenant instances offers to the user a little visual difference. You will inform the resource identified with its own tenant identifier as prefix.

It is transparent for users, but in administration console you'll see a flag that informs you that you're in a multi tenant instance: **sentilo@the identifier**, is related to an identifier from Sentilo tenant organization

### 7.5.1 Applications


For application creation form you'll see this in the Identifier field:



In this case, we're creating a application named My Application with identifier sentilo@myapp\_identifier.

### 7.5.2 Providers

For the providers, we would be facing the same case as for the Applications. Therefore, you can choose the desired identifier, regardless of the tenant you are managing.



In this case, we're creating a provider named My Provider, with identifier sentilo@myprovider\_identifier.

**Tutorials** 

Contents:

# 8.1 Java Client Tutorial

\_static/images/tutorials/java\_logo.jpg

The Sentilo Java Client is a library developed for working with webapps or standalone java applications. You can download an example of a client from https://github.com/sentilo/sentilo-client-sample-java.

For this example, we'll use a basic maven based web application, that retrieve some system data and send it as a sensor observation to the Sentilo Platform. This webapp is named **sentilo-client-java-sample** and you'll find it into the source code (see above).

# 8.1.1 Hardware

We don't need any specific hardware for running this example, only one PC with Internet connection.

# 8.1.2 Software

You'll need some software packages, as you're developing in Java environment:

- Java SE 1.8
- Eclipse IDE or STS Spring IDE

- The **Sentilo Client Java Library**, which you can download and install it as a *Maven dependency* into your project (please, see the **pom file** in the project form more information)
- Tomcat 7+
- If you don't have access to a working Sentilo instance, you might as well use our 'Sentilo VM </use a virtual machine.html>'.

# 8.1.3 The example

#### The code

Please download this sample webapp project from Git repository: https://github.com/sentilo/sentilo-client-sample-java

Once you have the project, open it with Eclipse or another IDE and construct it using *Maven* goals: **clean package**, for downloading dependencies, compile the code and package it.

After your project is compiled and packaged, you can deploy it in a Tomcat webapp container (standalone or the one your IDE provides).

**Note:** In case you use our VM on the same machine as Tomcat of this example, you might have a problem with port 8080 already being used. That's because Virtualbox will NAT the VM's Tomcat on 8080 to port 8080 on your host machine. If it's your case, you should change the port of your Tomcat to, for example, 8888.

Now you can then navigate into the project and edit the source code.

# The properties file

You must modify the properties file application.properties located in src/main/resources/properties in order to provide your correct Sentilo Platform Client configurations.

```
# Sentilo Platform API Services IP
rest.client.host=YOUR_SENTILO_PLATFORM_CLIENT_ADDRESS

# User configurations
rest.client.identityKey=YOUR_IDENTITY_KEY
rest.client.provider=samples-provider
rest.client.component=sample-component
rest.client.component.type=generic
rest.client.component.location=41.387015 2.170047
rest.client.sensor=sample-sensor-java
rest.client.sensor.type=status
rest.client.sensor.dataType=TEXT
rest.client.sensor.location=41.387015 2.170047
```

This settings should be updated:

- **rest.client.host**: provide a correct host or ip address of your Sentilo Platform Client, and replace the *YOUR\_SENTILO\_PLATFORM\_CLIENT\_ADDRESS* with it. Needs the protocol and the port. Ex: http://localhost:8081
- **rest.client.identityKey**: provide your correct application security token, and replace the *YOUR\_IDENTITY\_KEY* with it
- *optionally* **rest.client.sensor.type**: you can select a default type (anemometer, humidity, noise... etc) in the catalog or you can create one of your election there.

• *optionally*, you can provide your component / sensor locations, modifying the values rest.client.component.location and rest.client.sensor.location

## The samples controller

There's a Spring MVC controller which displays a view with the sensor data retrieved from system and the publish result. Navigate to **src/main/java** and open this resource **org.sentilo.samples.controller.SamplesController**.

This is a Spring Framework Controller that creates a view where you'll see a sample data value obtained from the System, and then send it as observation to your Sentilo Platform instance. The webapp is based on Maven & Spring foundations, so you must modify and provide some configurations before start the example execution (see above).

```
@Controller
public class SamplesController {
   private final Logger logger = LoggerFactory.getLogger(SamplesController.class);
   private static final String VIEW_SAMPLES_RESPONSE = "samples";
    @Autowired
   private PlatformTemplate platformTemplate;
    @Resource
   private Properties samplesProperties;
   @RequestMapping(value = {"/", "/home"})
   public String runSamples(final Model model) {
        // All this data must be created in the Catalog Application before start this
        // sample execution. At least the application identity token id and the
\rightarrowprovider id must be
        // declared in system twice
        String restClientIdentityKey = samplesProperties.getProperty("rest.client.
→identityKey");
        String providerId = samplesProperties.getProperty("rest.client.provider");
        // For this example we have created a generic component with a status sensor,
→that accepts text
        // type observations, only for test purpose
        String componentId = samplesProperties.getProperty("rest.client.component");
        String sensorId = samplesProperties.getProperty("rest.client.sensor");
        logger.info("Starting samples execution...");
        String observationsValue = null;
        String errorMessage = null;
        try {
            // Get some system data from runtime
            Runtime runtime = Runtime.getRuntime();
            NumberFormat format = NumberFormat.getInstance();
            StringBuilder sb = new StringBuilder();
            long maxMemory = runtime.maxMemory();
            long allocatedMemory = runtime.totalMemory();
            long freeMemory = runtime.freeMemory();
            sb.append("free memory: " + format.format(freeMemory / 1024) + "<br/>br/>");
```

180

(continued from previous page)

```
sb.append("allocated memory: " + format.format(allocatedMemory / 1024) + "
\rightarrow <br/>");
           sb.append("max memory: " + format.format(maxMemory / 1024) + "<br/>br/>");
           sb.append("total free memory: " + format.format((freeMemory + (maxMemory -
→ allocatedMemory)) / 1024) + "<br/>");
           // In this case, we're getting CPU status in text mode
           observationsValue = sb.toString();
           logger.info("Observations values: " + observationsValue);
           // Create the sample sensor, only if it doesn't exists in the catalog
           createSensorIfNotExists(restClientIdentityKey, providerId, componentId,...
⇒sensorId);
           // Publish observations to the sample sensor
           sendObservations(restClientIdentityKey, providerId, componentId, sensorId,
→ observationsValue);
       } catch (Exception e) {
           logger.error("Error publishing sensor observations: " + e.getMessage(),...
→e);
           errorMessage = e.getMessage();
       }
       logger.info("Samples execution ended!");
       model.addAttribute("restClientIdentityKey", restClientIdentityKey);
       model.addAttribute("providerId", providerId);
       model.addAttribute("componentId", componentId);
       model.addAttribute("sensorId", sensorId);
       model.addAttribute("observations", observationsValue);
       ObjectMapper mapper = new ObjectMapper();
       try {
           if (errorMessage != null && errorMessage.length() > 0) {
               Object json = mapper.readValue(errorMessage, Object.class);
               model.addAttribute("errorMsg", mapper.
→writerWithDefaultPrettyPrinter().writeValueAsString(json));
           } else {
               model.addAttribute("successMsg", "Observations sent successfully");
       } catch (Exception e) {
           logger.error("Error parsing JSON: {}", e.getMessage(), e);
           errorMessage += (errorMessage.length() > 0) ? "<br/>" : "" + e.
→getMessage();
           model.addAttribute("errorMsg", errorMessage);
       return VIEW_SAMPLES_RESPONSE;
   }
    * Retrieve catalog information about the sample provider. If the component and/
→or sensor doesn't
    * exists, then let create they
```

```
* @param identityToken Samples Application identity token for manage the rest.
→connections
    * @param providerId
                          Samples provider id
    * @param componentId Samples component id
                           Samples sensor id
    * @param sensorId
    * @return {@link CatalogOutputMessage} object with provider's catalog data
   private CatalogOutputMessage createSensorIfNotExists(String identityToken, String)
→providerId, String componentId, String sensorId) {
       List<String> sensorsIdList = new ArrayList<String>();
       sensorsIdList.add(sensorId);
       // Create a CatalogInputMessage object for retrieve server data
       CatalogInputMessage getSensorsInputMsg = new CatalogInputMessage();
       getSensorsInputMsg.setProviderId(providerId);
       getSensorsInputMsg.setIdentityToken(identityToken);
       getSensorsInputMsg.setSensors(createSensorsList(providerId, componentId,_
⇔sensorsIdList));
       // Obtain the sensors list from provider within a CatalogOutputMessage,
→response object type
       CatalogOutputMessage getSensorsOutputMsg = platformTemplate.getCatalogOps().
// Search for the sensor in the list
       boolean existsSensor = false;
       if (getSensorsOutputMsg.getProviders() != null && !getSensorsOutputMsg.
→getProviders().isEmpty()) {
           for (AuthorizedProvider provider : getSensorsOutputMsg.getProviders()) {
               if (provider.getSensors() != null && !provider.getSensors().
→isEmpty()) {
                   for (CatalogSensor sensor : provider.getSensors()) {
                       logger.debug("Retrieved sensor: " + sensor.getComponent() + "_
→- " + sensor.getSensor());
                       existsSensor |= sensorId.equals(sensor.getSensor());
                       if (existsSensor) {
                           break:
                   }
               }
           }
       // If the sensor doesn't exists in the retrieved list, we must create it.
→before publish the
       // observations
       if (!existsSensor) {
           // Create a CatalogInputMessage object for retrieve server data
           CatalogInputMessage registerSensorsInputMsg = new__
→CatalogInputMessage(providerId);
           registerSensorsInputMsg.setIdentityToken(identityToken);
           registerSensorsInputMsg.setSensors(createSensorsList(providerId,_

→componentId, sensorsIdList));
           // Register the new sensor in the server
           platformTemplate.getCatalogOps().registerSensors(registerSensorsInputMsg);
```

```
return getSensorsOutputMsg;
   }
   /**
    * Publish some observations from a sensor
    * @param identityToken Samples Application identity token for manage the rest.
→connections
    * @param providerId Samples provider id
    * @param componentId Samples component id
    \star @param sensorId Samples sensor id
    * @param value
                          Observations value, in our case, a String type
    */
   private void sendObservations(String identityToken, String providerId, String,
→componentId, String sensorId, String value) {
       List<String> sensorsIdList = new ArrayList<String>();
       sensorsIdList.add(sensorId);
       createSensorsList(providerId, componentId, sensorsIdList);
       List<Observation> observations = new ArrayList<Observation>();
       Observation observation = new Observation(value, new Date());
       observations.add(observation);
       SensorObservations sensorObservations = new SensorObservations(sensorId);
       sensorObservations.setObservations(observations);
       DataInputMessage dataInputMessage = new DataInputMessage(providerId,...
⇒sensorId):
       dataInputMessage.setIdentityToken(identityToken);
       dataInputMessage.setSensorObservations(sensorObservations);
       platformTemplate.getDataOps().sendObservations(dataInputMessage);
   }
   /**
    * Create a component list
    * @param componentId Component identifier
    * @return A {@link CatalogComponent} list
   private List<CatalogComponent> createComponentsList(String componentId) {
       List<CatalogComponent> catalogComponentList = new ArrayList<CatalogComponent>
\hookrightarrow ();
       CatalogComponent catalogComponent = new CatalogComponent();
       catalogComponent.setComponent(componentId);
       catalogComponent.setComponentType(samplesProperties.getProperty("rest.client.
catalogComponent.setLocation(samplesProperties.getProperty("rest.client.
→component.location"));
       catalogComponentList.add(catalogComponent);
       return catalogComponentList;
   }
    * Create a sensor list
```

```
* @param componentId
                           The Sample Component Id
    * @param sensorsIdList A list with the sensor ids to create
    * @return A {@link CatalogSensor} list
   private List<CatalogSensor> createSensorsList(String providerId, String_
→componentId, List<String> sensorsIdList) {
       List<CatalogSensor> catalogSensorsList = new ArrayList<CatalogSensor>();
       for (String sensorId : sensorsIdList) {
           CatalogSensor catalogSensor = new CatalogSensor();
           catalogSensor.setComponent(componentId);
           catalogSensor.setSensor(sensorId);
           catalogSensor.setProvider(providerId);
           catalogSensor.setType(samplesProperties.getProperty("rest.client.sensor.
\rightarrowtype"));
           catalogSensor.setDataType(samplesProperties.getProperty("rest.client.
→sensor.dataType"));
           catalogSensor.setLocation(samplesProperties.getProperty("rest.client.
⇔sensor.location"));
           catalogSensorsList.add(catalogSensor);
       return catalogSensorsList;
   }
```

#### What's happenning?

- · First of all, we're looking for some configuration settings, like the component and sensor names
- Next, we're using some runtime status values, so we can the publish them as a observations (mem status, for example)
- First of all, we check if the sensor has been created before in the Catalog, and if it doesn't exists we add it
- After that, we'll publish the sensor observations
- Then, we pass all this information to the view for displaying it the navigator window

This is an observation sample:

```
CPU states: 5.8% user, 1.9% system, 0.0% nice, 0.0% wait, 91.7% idle
```

### The samples page view

And finally, this is the source code of the view:

```
<%@ taglib prefix="c" uri="http://java.sun.com/jsp/jstl/core" %>
<%@ page contentType="text/html; charset=UTF-8" pageEncoding="UTF-8"%>
<!DOCTYPE html>
<html>
<head>
</head>
<body>
```


This source code is quite easy, so don't need to comment it.

# **Executing the sample application**

Using the IDE or copying the WAR file, deploy your webbapp into the Tomcat deployments directory, and start it.

You must access to this url (we assume that you're in your localhost and your port is the 8080, the default values): http://localhost:8080/sentilo-samples (http://localhost:8888/sentilo-samples if using VM)

And then you must see a result page like this:



As you can see, there's a button named *Send observations*. You can use to re-send observations and reload the page. Every page reload send the observations to the Sentilo Platform Client.

# 8.2 RaspberryPi Client



The **SentiloClientNodeJS** is a library written in javascript that brings to you the possibility to connect any device and embedded device with Node.js to a Sentilo instance easily.

For this example we'll use a Raspberry pi device, because its special features, like cheap price, small dimensions and the great input-output possibilities.

# 8.2.1 Hardware

We need some hardware to execute this example:

Material	Description
Raspberry Pi	Of course, we need a Raspberry Pi, doesn't matters its version. You need a Raspbian distro
	installed too
Ethernet cable or	Doesn't matter what network hardware do you use, it's up to you, but you'll need the correct
wifi dongle	drivers correctly configured for connecting to Internet
Some cables	Some "dupont" male-to-female cables to make breadboard connections
A LED	We'll use a LED as an output for simulating order execution, you can pick any color
A resistor	A 470 Ohms 1/4W resistance
A breadboard	You'll need an electronic connections base to make some circuits, so we'll recommend you
	to get a breadboard

# 8.2.2 Software

We need to install some node.js alternative modules or libraries. We'll install them through *npm* or download them from the Internet. See the next section for more information.

# 8.2.3 Setup the Raspi

In this example we'll show to you how to implement a sensor and a actuator with several capabilities such as:

- get values from one o more sensors connected to it GPIO port and publish them in Sentilo
- receive orders from a Sentilo application and actuate on the GPIO in consequence

If you don't have node.js installed, install it with:

```
sudo apt-get install nodejs
sudo apt-get install npm
```

#### The software

# Create the workspace

First of all, create a directory named sentilo (for example) in our user home and change to it:

```
pi@raspberrypi ~ $ mkdir sentilo && cd sentilo
```

Here we'll work with all our files.

# Install the sample code and its dependencies

Download the sample project for this tutorial from the Sentilo git repository, and clone it into your working directory:

```
pi@raspberrypi ~/sentilo $ git clone https://github.com/sentilo/sentilo-client-sample-

→nodejs
```

We need some Node.js modules to work with our library. So you need to download and install the through npm.

You can download via npm update:

```
pi@raspberrypi ~/sentilo/sentilo-client-sample-nodejs $ npm install
```

#### Or install them directly:

```
pi@raspberrypi ~/sentilo/sentilo-client-nodejs $ npm install express
pi@raspberrypi ~/sentilo/sentilo-client-nodejs $ npm install sync-request
pi@raspberrypi ~/sentilo/sentilo-client-nodejs $ npm install onoff
```

Which dependencies have been installed?

- sentilo-client-nodejs: it is a client library for Sentilo (see its main GiHub page or the NPM library page for more information)
- express: it is a rest server interface for Node.js that allow to us to create a rest server easily (see this link for more information)
- sync-request: allow to us to create synchronous http calls (see this link for more information)
- onoff: it is a GPIO driver that allow to us to turn on and off a LED very easily! (see this link for more information)


Now, we can start to develop with node in our working directory

# Connecting the hardware

We'll assume that you have your Raspberry Pi connected to the Internet, a Raspbian system correctly installed and enough permissions to create and runs scripts in your user home. Usually, we will use the **pi** user.

To simulate a sensor's actuator, we'll use a LED connected to the GPIO 14 from the Raspberry Pi.

Let see it below:



As you can see, we only connect the **LED annode** to the **14 GPIO** pin, and the **kathode** to the **GND** pin. We're ready to turn ON and OFF this LED from the Sentilo platform.

# 8.2.4 The example

Our example is a complete test of the Sentilo Client Node.js library.

The library allows you to perform these operations:

- Catalog
  - Get sensors from a provider
  - Register sensors for a provider

- Update sensors configuration
- Register alerts
- Alarm
  - Publish alarms
- Data
  - Retrieve last observations from a sensor
  - Publish observations
- · Subscription
  - Subscribe orders from a sensor
  - Subscribe orders for all the sensors of a provider

#### The code

#### actuator.js

This file contains code to control the output LED, that performs a simulation of a possible actuator controlled by the Raspberry Pi and orders published on the Sentilo platform. In the example, the system is being subscribed as endpoint to receive incoming order actuation calls.

```
var Gpio = require('onoff').Gpio;
var led;
module.exports = {
    init : function() {
         // Configure the GPIO as OUTPUT
         led = new Gpio(14, 'out');
         console.log('Turning OFF the LED');
         // Turn off the LED on startup
         led.writeSync(0);
     },
      * Execute an order in the actuator. For this example, we've mounted a LED
      * in GPIO 14, where we can turn it ON (order=ON) or OFF (order=OFF)
       @param order
                  A Sentilo order object structure
    executeOrder : function(order) {
         console.log('Executing order: ' + order.message);
         if (order.message === 'ON') {
             console.log('Turning ON the LED');
             led.writeSync(1);
         } else if (order.message === 'OFF') {
             console.log('Turning OFF the LED');
             led.writeSync(0);
```

```
}
};
```

What's happening here?

- The init function configures the GPIO 14 as an output to control the LED (don't forget to call it!)
- The executeOrder function performs the actuator order execution, for our case, it turns the LED ON and OFF
  if the order was either ON or OFF. The main server code will access this function.

#### sensor.js

This file contains the code that performs a possible sensor data read and return its value. For our example, we only emulate a random value as a possible sensor data value. You may develop an data input sensor with a GPIO library.

```
module.exports = {
    readSensorValue : function() {
       var sensorValue = Math.floor((Math.random() * 255));
       return sensorValue;
    }
};
```

What's happening here?

• The **readSensorValue** function reads a possible sensor input data value from an external way. The main server code will access to this function to read the sensor data.

NOTE: as you see, you must implement this function to complete your requirements

## server.js

This is the main node file. This file performs a rest server and still waiting for incoming calls that apply to the actuator.

```
// The OS information module
var os = require('os');

// Include some Sentilo operations from the Nodejs client library
var sentilo = require('sentilo-client-nodejs');

// Module that interacts with the local sensor
var sensor = require('./sensor.js');

// Module that interacts with the local actuator
var actuator = require('./actuator.js');
actuator.init();

// Get some OS values, like the sensor IP
var interfaces = os.networkInterfaces();
var addresses = [];
```

```
for (var k in interfaces) {
    for (var k2 in interfaces[k]) {
        var address = interfaces[k][k2];
        if (address.family === 'IPv4' && !address.internal) {
            addresses.push (address.address);
    }
var myIp = addresses[0];
var myPort = 3000;
var myEndpoint = 'http://'+myIp+':'+myPort;
var myOrderEndointPath = '/order';
var myOrderEndoint = myEndpoint + myOrderEndointPath;
var systemObservationsTimeout = 60000;
// Service and example options
// You must modify it under your requeriments
var samplesOptions = {
   host : 'YOUR-SENTILO-INSTANCE-HOST-IP',
   port : 'YOUR-SENTILO-INSTANCE-HOST-PORT',
   headers : {
        identity_key : 'YOUR_SENTILO-INSTANCE-DEFAULT-IDENTITY-KEY'
   },
   tokenId : 'YOUR-SENTILO-INSTANCE-IDENTITY-KEY',
   providerTokenId : 'YOUR-SENTILO-INSTANCE-PROVIDER-IDENTITY-KEY',
   provider : 'samples-provider',
   sensor : 'sample-sensor-nodejs',
   component: 'sample-component',
   componentType : 'generic',
   sensorDataType : 'TEXT',
   sensorType : 'status',
    sensorUnit : '',
    sensorLocation: '41.4122494 2.2101553'
};
// A very simple RESTFul server module
var express = require('express');
var server = express();
server.use(express.json()) // for parsing application/json
server.use(express.urlencoded({ extended: true })) // for parsing application/x-www-
→form-urlencoded
server.get('/', (req, res) => {
    var output = `Test server is listening at port: ${myPort}`;
    output += `The server is now ready to receive POST incoming callsat: $
→ {myOrderEndoint} `;
    res.send(output);
});
// We only need a POST endpoint service to receive ordercs callbacks
// The path will be [POST] http://localhost:3000/order
server.post('/order', function(req, res, next) {
    var order = req.body;
    console.info("[server][POST] Order received: " + JSON.stringify(order));
    res.json(req.body);
```

```
// Execute the order in the actuator
   actuator.executeOrder(req.body);
   var value = 'Order received and executed: ' + JSON.stringify(order.message);
   sentilo.publishObservations(value, samplesOptions);
   return next();
});
function sentiloInit() {
    console.log('[server][sentilo-init] Initializing the NodeJS client example for_
→Sentilo');
    // Init Sentilo services for this example
    // Here you must pass as paramether the specific configuration
    sentilo.init(samplesOptions);
    // Test if is there the sensor configured in the catalog
    console.log(`[server][sentilo-init] Registering the ${samplesOptions.sensor}_
⇒sensor...`);
    var existsSensor = sentilo.existsSensorInCatalog(samplesOptions);
    if (!existsSensor) {
         // If not, then create it
         sentilo.createSensor(samplesOptions);
        console.log(`[server][sentilo-init] Sensor ${samplesOptions.sensor}_
⇒successfully created`);
    } else {
             console.log(`[server][sentilo-init] Sensor ${samplesOptions.sensor}...
→already exists, we'll use it`);
    // Now we can publish a first alarm that informs that the sensor is up
    // First of all let create an external alert
    console.log('[server][sentilo-init] Registering the System Status Alert...');
    var alertsListInputMessage = {
        alerts : [ {
            id : 'SYSTEM_STATUS_ALERT',
             name : 'SYSTEM_STATUS_ALERT',
             description : 'Custom alert to inform the system status',
             type : 'EXTERNAL'
         } ]
    sentilo.createAlerts(alertsListInputMessage);
    // And then, we can publish an alarm to inform that the system is up now
    var alarmInputMessage = {
        message: 'The system goes up on ' + new Date()
    sentilo.publishAlarm('SYSTEM_STATUS_ALERT', alarmInputMessage);
    console.log('[server][sentilo-init] Alarm published: ' + alarmInputMessage.
→message);
    // Subscribe the sensor orders
    // We'll manage it throught our server on POST service
    var subscriptionInputMessage = {
        endpoint : myOrderEndoint
    };
```

```
sentilo.subscribeOrder(subscriptionInputMessage);
     // sentilo.subscribeOrderToAll(subscriptionInputMessage);
    console.log('[server][sentilo-init] Sensor\'s orders successfully subscribed to...
→this server');
     // Now, we can publish observations every 60 seconds
     // And still waiting for incoming orders
    publishTestData();
function publishTestData() {
    console.log('[server][publishTestdata] The sensor is now up, and we\'ll be_
→sending some observations every ' + systemObservationsTimeout + ' ms');
    setInterval(function() {
         // Send some System information
        var freeMemValue = "OS freemem: " + os.freemem();
         console.log('[server][publishTestdata] Retrieved system freemem value: [' +_
→freeMemValue + '] and publishing it as an observation...');
         sentilo.publishObservations(freeMemValue, samplesOptions);
         // Retrieve some sensor data and send it as observation...
         var sensorDataValue = "Sensor value: " + sensor.readSensorValue();
         console.log('[server][publishTestdata] Retrieved sensor value: [' +_
→sensorDataValue + '] and publishing it as an observation...');
         sentilo.publishObservations(sensorDataValue, samplesOptions);
     }, systemObservationsTimeout);
server.listen(myPort, () => {
    console.log(`[server] My ip address is: ${myIp}`);
    console.log(`[server] Test server is listening at: ${myEndpoint}`);
    console.log(`[server] The server is now ready to receive POST incoming calls at:
→${myOrderEndoint}`);
    // Initialize the example
    sentiloInit();
})
```

First of all, we'll see the configuration options (line 62). They must be changed before run this example.

You must provide the correct values for these variables located into the samplesOptions object:

- YOUR-SENTILO-INSTANCE-HOST-IP & YOUR-SENTILO-INSTANCE-HOST-PORT: provide the correct **ip address** or host of your Sentilo's instance rest server and port
- YOUR\_SENTILO-INSTANCE-DEFAULT-IDENTITY-KEY: you must provide your **private security key** (tokenId) that identifies your **application** or **provider** (normally same as **YOUR-SENTILO-INSTANCE-IDENTITY-KEY**). If it is an application, it must have ADMIN permissions over your provider.
- YOUR\_SENSOR\_LOCATION: this is optional, identifies the component location of the sample sensor. It can be for example '41.387015 2.170047'

Now, what's happens in this code?

- First, we start a **rest server** with the *express* module, that allows to us to provide an endpoint for incoming order calls (POST method). After that, we create a subscription for our orders.
- When a POST request is received, the server will invoke the **actuator's executeOrder function**, so we can manage the order correctly (turn ON/OFF the LED, for example)

- Initialize the **sentilo's helper module** (as you can see above), implemented by the *sentilo.js* file
- We're passing to it our specific services configuration, like the sensor id, provider's token, etc...
- Request for the sensor in the Sentilo Catalog platform, and if it doesnt't exists, create it
- Once we have created the sensor, we're creating an alert, named SYSTEM\_STATUS\_ALERT, and publishing an initial alarm that says The system goes up on {date}. Then, the sensor is up and we're informing it to the system
- After that, retrieve some system and sensor data values and publish them every 60000ms (1 minute) in a infinite loop

## **Executing the example**

Now we can finally execute the example.

### Simple type:

```
pi@raspberrypi ~/sentilo/sentilo-client-nodejs $ node server.js
[actuator] Turning OFF the LED
[server] My ip address is: 127.0.0.1
[server] Test server is listening at: http://127.0.0.1:3000
[server] The server is now ready to receive POST incoming calls at: http://127.0.0.

1:3000/order
[server][sentilo-init] Initializing the NodeJS client example for Sentilo
[server][sentilo-init] Registering the sample-sensor-nodejs sensor...
[server][sentilo-init] Sensor sample-sensor-nodejs successfully created
[server][sentilo-init] Registering the System Status Alert...
[server][sentilo-init] Alarm published: The system goes up on Mon Nov 21 2022_

16:56:32 GMT+0100 (hora estándar de Europa central)
[server][sentilo-init] Sensor's orders successfully subscribed to this server
[server][publishTestdata] The sensor is now up, and we'll be sending some_

observations every 60000 ms
```

And now, the server is waiting for publish the observations every 60 seconds:

```
[server][publishTestdata] Retrieved system freemem value: [OS freemem: 2927603712] → and publishing it as an observation...
[server][publishTestdata] Retrieved sensor value: [Sensor value: 51] and publishing → it as an observation...
```

# Publishing and accepting orders

The server also is writing for incoming POST calls that responses the ORDER requests. You can practice with orders, sending a PUT message to the Sentilo platform, some like this:

```
http://sentilo_platform_ip:8081/order/samples-provider/sample-sensor-nodejs
```

With these values:

```
HEADER > identity_key : 'YOUR_IDENTITY_KEY'
BODY > {"order" : "ON"} > this turns ON the LED
BODY > {"order" : "OFF"} > this turns OFF the LED
```

After that, you'll see in the console some log like this when you're turning the LED ON, sending **order = ON**:

```
[POST] Order received: {"message":"ON","timestamp":"07/05/2015T13:58:20","topic":"/
→order/samples-provider/sample-sensor-nodejs","type":"ORDER","sensor":"sample-sensor-
→nodejs","provider":"samples-provider","sender":"samples-provider","time
→":1431007100595}
Executing order: ON
Turning ON the LED
```

### Or turning it OFF, with **order = OFF**:

```
[POST] Order received: {"message":"OFF", "timestamp":"07/05/2015T14:01:13", "topic":"/

→order/samples-provider/sample-sensor-nodejs", "type":"ORDER", "sensor":"sample-sensor-

→nodejs", "provider": "samples-provider", "sender": "samples-provider", "time

→ ":1431007273310}

Executing order: OFF
Turning OFF the LED
```

# **Debugging the library**

If you need to debug your execution, you can edit the file node\_modules/sentilo-client-nodejs/src/utils/SentiloLogs.js and edit the logs configuration properties, as you need:

```
var options = {
    className : 'Sentilo',
    enableLogs : true,
    enableDebug : true,
    enableInfo : true,
    enableWarn : true,
    enableError : true,
    enableFatal : true
};
```

For our purpose, we only have DEBUG, INFO and ERROR logs. Try tu use **true** or **false** for each one.

# 8.3 Arduino Tutorial



The **SentiloClient Library** for Arduino offers a basic C++ library implementation that allows to the developer a quick integration sketch with the Sentilo Platform through its API Rest Client.

For these examples we'll create a new sensor in the Sentilo Platform, only if it doesn't exists, and then we're going to publish some observations obtained from the local sensors.

#### 8.3.1 Hardware

We'll need some hardware materials:

Material	Description
>Arduino board	We recommend that you use a <b>Mega 2560</b> board, which brings to you a bit more program
	memory than Uno.
>Official Ethernet	The library is based on the communication layer that provides the Official Ethernet
Shield for Arduino	Shield. Basically, it is a http rest client module.
Some sensors	For these examples we'll use two types of sensors: a LM35 temperature sensor, and a
	basic LDR brightness sensor (photocell)
Resistors	Two 1KOhm resistors 1/4W
Breadboard	A breadboard that allow to you the quick connection of the electronic components
Wires	Connection wires, like 'dupont' male-to-male ones, that brings to you easily connection
	between the Arduino board and the breadboard and the sensors
Ethernet cable	A cable for connecting the Ethernet Shield to the Internet through your router o modem
B type USB cable	A cable for connecting your Arduino board to the PC

# 8.3.2 Software

We'll use the **Official Arduino IDE**, that you can download from here. Of course, you'll need a PC, with Windows or Linux, or a Mac computer.

# 8.3.3 Setup the Arduino

#### The Arduino IDE

We assume that you have installed the **Arduino IDE** and you know how to use it :). If not, then you can have a look on this link.

# Download and install the library

Download our **SentiloClient** library or clone it from Git via this link: https://github.com/sentilo/sentilo-client-arduino, and then install it as a custom library into your Arduino IDE. If you don't know how to install custom libraries, you can have a look on this link, see the **Importing a .zip Library** section.

# 8.3.4 The example

# First example: publishing a basic observation

Once you have installed the library into the Arduino IDE, you can go to the menu option **File > Examples > Sentilo- Client > SentiloClient-Example-01** and open the sample code. In this example Arduino is going to connect to the network and publish a basic observation with these contents: "**This is a sample observation**".

8.3. Arduino Tutorial 195

# Sentilo configuration

You must have configured this information in the Sentilo catalog:

- A provider (in our case, named **samples-provider**) and its token
- A component (in our case, named **sample-component**)
- A sensor (in our case, named **sample-sensor-arduino-01** for the first example, and another one named **sample-sensor-arduino-02** for the second one), with this minimum configuration settings:

```
sensor = sample-sensor-arduino-01
type = status
dataType = TEXT
component = sample-component
componentType = generic
```

Then, you must replace the client connection data code (next section) with yours settings:

- Change the value "YOUR\_API\_KEY" with the api key of your provider (variable apiKey)
- Change the value "YOUR\_IP\_ADDRESS" with the ip address of your Sentilo instance (variable *ip*)
- Change the value "YOUR\_PORT" with the port of your Sentilo server instance port (variable *port*)

#### The code

You'll should see this code in the editor:

```
#include <Ethernet.h>
#include <SPI.h>
#include "SentiloClient.h"
/*********************************
/***************
char* apiKey = "YOUR_API_KEY";
char* ip = "YOUR_IP_ADDRESS";
int port = YOUR_PORT;
char* componentId = "sample-component";
char* providerId = "samples-provider";
char* sensorId = "sample-sensor-arduino-01";
// The Sentilo Client object
SentiloClient sentiloClient = SentiloClient(ip, port);
/**** NETWORK *****************/
/*************/
const int networkConnectionTimeout = 30;
/***************
/**** GLOBAL VARS *************/
const int generalCalibrationTimeout = 1000; // Wait after system setup is complete
String response = ""; // Rest call response (normally as JSON message)
int statusCode = -1; // Rest call return code (the HTTP code)
```

```
void setup() {
        // Begin serial for debug purposes
        Serial.begin(9600);
        // Setup the Sentilo Client and the network connection
        setupSentiloClient();
        // Wait time for a general calibration
        delay(generalCalibrationTimeout);
void loop() {
        // Create the Observation object
        SentiloClient::Observation observation;
        observation.value = "This is a sample observation";
        Serial.println("[loop] Publishing a sample observation...");
        // Publish the observation to Sentilo Platform
        statusCode = sentiloClient.publishObservation(providerId, sensorId,

→ observation, apiKey, response);
        // Read response status and show an error if it is necessary
        if (statusCode !## 200) {
                Serial.print("[loop] [ERROR] Status code from server after publish,
→the observations: ");
                Serial.println(statusCode);
                Serial.print("[loop] [ERROR] Response body from server after publish.
\hookrightarrowthe observations: ");
                Serial.println(response);
        Serial.println("[loop] Sample observation published!");
        Serial.println("[loop] Program ended");
        // The example has ended, so we are going to execute an infinite loop
        while (true) {}
/** Setup the Sentilo Client object, this process also configures the network.
→connection **/
void setupSentiloClient() {
        Serial.print("[setup] Connecting to network via DHCP ");
        sentiloClient.dhcp();
        for (int i = 0; i < networkConnectionTimeout; i++) {</pre>
                Serial.print(".");
                delay(100);
        Serial.println(" done!");
        Serial.println("[setup] Connection is now established!");
```

What can we see in this example?

• We are setting up the Serial channel for debug output

8.3. Arduino Tutorial 197

- Setup the SentiloClient object (sentiloClient), which configures the client and connects to the network
- Once we're connected to the server, we publish a basic observation, with these contents: "This is a sample observation"
  - If the publish works properly, the system don't return any special data
  - Otherwise, it will show to you the system return code and message, if it is possible
- The test ends after publish only one observation

#### Second example: publishing sensors data as observations

In this case we'll retrieve data from sensors (LDR and LM35), and then we'll publish them as a observation, with a message in JSON format, like that:


```
{"ldr":"{ldrValue}","lm35":"{lm35Value}"}
```

Where the **ldrValue** contains the LDR photocell value, and the **lm35Value** contains the LM35 temperature value. Open the sample code in **File > Examples > SentiloClient > SentiloClient-Example-02**.

#### Connect the sensors and and other connections

Now, it is the time to connect the sensors and others elements.

See below:



fritzing

198 Chapter 8. Tutorials

In the upper image, you can see how the components has been located:

- Connect the *positive* pin from **Arduino** (+5**V**) to the upper channel of the breadboard (*red channel*)
- Connect the *negative* pin from **Arduino** (**GND**) to the second channel of the breadboard (*blue channel*)
- LDR photocell sensor connection:
  - Connect the LDR photocell between GND signal and A0 (Analog IO 0 from Arduino) with a dupont wire, in this case, the orange color wire
  - Connect the LDR pin that holds the orange wire with a 1KOhm resistor, and the other resistor pin to
     Arduino +5V (red wire)
- LM35 temperature sensor:
  - Connect the LM35 positive pin (left pin, front side) to Arduino +5V
  - Connect the LM35 **center pin** (signal) to the A5 (Analog IO 5 from Arduino) with a dupont wire, in this case, the orange color wire
  - Connect the LM35 negative pin (right pin, front side) to Arduino GND

#### The code

You should see this code in the editor:

```
#include <Ethernet.h>
#include <SPI.h>
#include "SentiloClient.h"
/**** SENSORS ****************/
int LDR = 0; // LDR input is A0
int LM35 = 5; // LM35 input is A5
const int ldrSetupTimeout = 10; // Time that LDR needs to be configures (dummy time)
const int lm35SetupTimeout = 10; // Time that LM35 needs to be configures (dummy time)
/***************
/**** SENTILO *********************
/**********************************
char* apiKey = "YOUR_API_KEY";
char* ip = "YOUR_IP_ADDRESS";
int port = YOUR_PORT;
char* componentId = "sample-component";
char* providerId = "samples-provider";
char* sensorId = "sample-sensor-arduino-02";
// The Sentilo Client object
SentiloClient sentiloClient = SentiloClient(ip, port);
/***********************************
/**** NETWORK ****************/
/***********************************
const int networkConnectionTimeout = 30;
/**** GLOBAL VARS **************/
```

(continues on next page)

8.3. Arduino Tutorial 199

```
/***************
const int generalCalibrationTimeout = 1000; // Wait after system setup is complete
const int loopTimeout = 60000; // Loop timeout, time between observations (in ms)
String response = ""; // Rest call response (normally as JSON message)
int statusCode = -1; // Rest call return code (the HTTP code)
boolean existsSensor = false;
void setup() {
       // Begin serial for debug purposes
       Serial.begin(9600);
       // Setup the LDR sensor
       setupLDR();
       // Setup the LM35 sensor
       setupLM35();
       // Setup the Sentilo Client and network connection
       setupSentiloClient();
       // Wait time for a general calibration
       delay(generalCalibrationTimeout);
void loop() {
       // Get the LDR value
       int ldrValue = getLdrValue();
       // Get the LM35 value
       float lm35Value = getLM35Value();
       // Create the observation input message like this: {"ldr":"234","lm35":"24.5"}
       String obsInputMsg =
                "{\\\"ldr\\\"" + String(ldrValue) +
                "\\\",\\\"lm35\\\":\\\"" + String(lm35Value) +
               "\\\"}";
       int bufLength = obsInputMsg.length() + 1;
       char obsMsgBuffer[bufLength];
       obsInputMsq.toCharArray(obsMsqBuffer, bufLength);
       // Create the Observation object
       SentiloClient::Observation observation;
       observation.value = obsMsgBuffer;
       // Debug on Serial the observations value. Note that we must scape special,
⇔characters
       Serial.print("[loop] Publishing actual sensors values as observations: ");
       Serial.println(obsMsgBuffer);
       // Publish the observation to Sentilo Platform
       statusCode = sentiloClient.publishObservation(providerId, sensorId, __
⇒observation, apiKey, response);
       // Read response status and show an error if it is necessary
       if (statusCode !## 200) {
               Serial.print("[loop] [ERROR] Status code from server after publish,
                                                                        (continues on next page)
→the observations: ");
```

200 Chapter 8. Tutorials

```
Serial.println(statusCode);
                Serial.print("[loop] [ERROR] Response body from server after publish,
\rightarrowthe observations: ");
                Serial.println(response);
        } else {
                Serial.println("[loop] Sensors observations published!");
        delay(loopTimeout);
/** Emulate a possible LDR initialization process, if it is necessary **/
void setupLDR() {
        Serial.print("[setup] Setting up the LDR brightness sensor ");
        for (int i = 0; i < ldrSetupTimeout; i++) {</pre>
                Serial.print(".");
                delay(100);
        Serial.println(" done!");
        delay(50);
/** Get the brightness value from th LDR **/
int getLdrValue() {
        return analogRead(LDR);
/** Emulate a possible LM35 initialization process, if it is necessary **/
void setupLM35() {
        Serial.print("[setup] Setting up the LM35 temperature sensor ");
        for (int i = 0; i < lm35SetupTimeout; i++) {</pre>
                Serial.print(".");
                delay(100);
        Serial.println(" done!");
        delay(50);
/** Get the LM 35 temperature value in Celsius degrees **/
float getLM35Value() {
        int val = analogRead(LM35);
        float mv = (val / 1024.0) * 5000;
        float cel = mv / 10;
        //float farh = (cel * 9) / 5 + 32;
        return cel;
/** Setup the Sentilo Client object. This process also configures the network,
void setupSentiloClient() {
        // Connect via DHCP
        Serial.print("[setup] Connecting to network via DHCP ");
        sentiloClient.dhcp();
        for (int i = 0; i < networkConnectionTimeout; i++) {</pre>
                Serial.print(".");
                delay(100);
```

(continues on next page)

8.3. Arduino Tutorial 201

```
Serial.println(" done!");
Serial.println("[setup] Connection is now established!");
}
```

What can we see in this example? There're some additions compared with the first example.

- Setup Arduino and the SentiloClient is the same of the first sample
- We're making a sensors setup, but in this case it isn't necessary, so it only informs us in debug mode what is happening in every moment...
- Into the loop
  - We're retrieving the LDR and LM35 values, and putting them into variables
  - Once we've retrieved the sensors data, we're mounting the new observation message, with value: {"ldr":"{ldrValue}","lm35":"{lm35Value}"}
  - The SentiloClient library gets the value and transforms it on a complete observation message using the publishObservation method (see below)
- The sketch loops sleeps until **loopTimeout** millis has been reached, and then turns up and repeats the same process of data publication (in this example the sleep time is 60000ms, 1 minute per loop / publish)

This is the observation sent by to the Sentilo platform:

If you want, you can include the timestamp variable in UTC format inside the observation object:

```
Observation observation;

observation.value = {"ldr":"382","lm35":"23.4"};

observation.timestamp = "05/05/2015T12:34:45";
```

And the message will be generated as:

```
{"observations": [{
         "value":"{\"ldr\":\"382\",\"lm35\":\"23.4\"}",
         "timestamp":"05/05/2015T12:34:45"
    }]
}
```

As you can see, the library object Observation (struct type) offers you an abstraction. In the next sample we will see them in working together with the Sensor object.

#### Third example: initialize sensor, create it in the catalog and publish observations continuously

In this third example we'll see that how the SentiloClient library can create a sensor "on-the-fly" and publish observations continuously. Next, we'll use the second example, plus a little bit of additional code that help us to check if the sensor exists in the catalog, and if not create it before publish observations. Open the sample code in **File > Examples > SentiloClient > SentiloClient-Example-03**.

#### The code

You should see this code in the editor:

```
#include <Ethernet.h>
#include <SPI.h>
#include "SentiloClient.h"
/***************
/**** SENSORS *****************/
int LDR = 0; // LDR input is A0
int LM35 = 5; // LM35 input is A5
const int ldrSetupTimeout = 10; // Time that LDR needs to be configures (dummy time)
const int lm35SetupTimeout = 10; // Time that LM35 needs to be configures (dummy time)
/**************
/**************
char* apiKey = "YOUR_API_KEY";
char* ip = "YOUR_IP_ADDRESS";
int port = YOUR_PORT;
char* componentId = "sample-component";
char* providerId = "samples-provider";
char* sensorId = "sample-sensor-arduino-03";
// The Sentilo Client object
SentiloClient sentiloClient = SentiloClient(ip, port);
/**** NETWORK *****************/
/************************************/
const int networkConnectionTimeout = 30;
/**************
/**** GLOBAL VARS *************/
const int generalCalibrationTimeout = 1000; // Wait after system setup is complete
const int loopTimeout = 60000; // Loop timeout, time between observations_
→publications (in ms)
String response = ""; // Rest call response (normally as JSON message)
int statusCode = -1; // Rest call return code (the HTTP code)
boolean existsSensor = false;
void setup() {
      // Begin serial for debug purposes
      Serial.begin(9600);
      // Setup the LDR sensor
      setupLDR();
      // Setup the LM35 sensor
      setupLM35();
      // Setup the Sentilo Client
```

(continues on next page)

8.3. Arduino Tutorial 203

204

(continued from previous page)

```
// and network connection
        setupSentiloClient();
        // Setup the Sentilo sensor
        // and create it if doesn't exists
        setupSentiloSensor();
        // Waiting for the next release of the observation
        delay(generalCalibrationTimeout);
void loop() {
       if (existsSensor) {
                // If the sensor exists,
                // we can start publishing observations
                // Get the LDR value
                int ldrValue = getLdrValue();
                // Get the LM35 value
                float lm35Value = getLM35Value();
                // Create the observation input message
                // like this: {"ldr":"234","lm35":"24.5"}
                String obsInputMsg =
                        "{\\\"ldr\\\":\\\"" + String(ldrValue) +
                        "\\\",\\\"lm35\\\":\\\"" + String(lm35Value) +
                        "\\\"}";
                int bufLength = obsInputMsg.length() + 1;
                char obsMsgBuffer[bufLength];
                obsInputMsg.toCharArray(obsMsgBuffer, bufLength);
                // Create the Observation object
                SentiloClient::Observation observation;
                observation.value = obsMsgBuffer;
                // Debug on Serial the observations value
                // Note that the message includes slashes (\) because we must scape_
⇒special characters as "
                Serial.print("[loop] Publishing actual sensors values as_

→observations: ");
                Serial.println(obsMsgBuffer);
                // Publish the observation to Sentilo Platform
                statusCode = sentiloClient.publishObservation(providerId, sensorId,__

→ observation, apiKey, response);
                // Read response status and show an error if it is necessary
                if (statusCode !## 200) {
                        Serial.print("[loop] [ERROR] Status code from server after_
→publish the observations: ");
                        Serial.println(statusCode);
                        Serial.print("[loop] [ERROR] Response body from server after...
→publish the observations: ");
                        Serial.println(response);
                } else {
                        Serial.println("[loop] Sensors observations published!");
```

```
}
        // Waiting for the next loop
        delay(loopTimeout);
        } else {
                // If the sensor does not exist and it could
                // not be created in the catalog, we must stop running
                Serial.println("[loop] [ERROR] Oops! The sensor doesn't exists, so I.
→can't publish data to it...");
                Serial.println("[loop] [ERROR] I'm sorry with you, but now I'm going,
→to halt...");
                Serial.println("[loop] [ERROR] Bye!");
                while (true) { }
        }
// Emulate a possible LDR initialization process, if it is necessary
void setupLDR() {
        Serial.print("[setup] Setting up the LDR brightness sensor ");
        for (int i = 0; i < ldrSetupTimeout; i++) {</pre>
                Serial.print(".");
                delay(100);
        Serial.println(" done!");
        delay(50);
// Get the brightness value from th LDR
int getLdrValue() {
       return analogRead(LDR);
// Emulate a possible LM35 initialization process, if it is necessary
void setupLM35() {
        Serial.print("[setup] Setting up the LM35 temperature sensor ");
        for (int i = 0; i < lm35SetupTimeout; i++) {
                Serial.print(".");
                delay(100);
Serial.println(" done!");
       delay(50);
// Get the LM 35 temperature value in Celsius degrees
float getLM35Value() {
        int val = analogRead(LM35);
        float mv = (val / 1024.0) * 5000;
        float cel = mv / 10;
        //float farh = (cel * 9) / 5 + 32;
       return cel;
// Setup the Sentilo Client object
// This process also configures the network connection
void setupSentiloClient() {
        // Connect via DHCP
        Serial.print("[setup] Connecting to network via DHCP ");
```

(continues on next page)

8.3. Arduino Tutorial 205

```
sentiloClient.dhcp();
        for (int i = 0; i < networkConnectionTimeout; i++) {</pre>
                Serial.print(".");
                delay(100);
        Serial.println(" done!");
        Serial.println("[setup] Connection is now established!");
// Setup the Sentilo Sensor (this Arduino)
// If the sensor doesn't exists in the catalog, create it
void setupSentiloSensor() {
       Serial.println("[setup] Retrieving catalog info from Sentilo and search for,
→the sensor...");
        // Get catalog data for the provider with the supplied api key
        statusCode = sentiloClient.getCatalog(apiKey, response);
        // If the server status response is not ok, show the error
        if (statusCode !## 200) {
                Serial.print("[setup] [ERROR] Status code from server getting.
→catalog: ");
                Serial.println(statusCode);
                Serial.print("[setup] [ERROR] Response body from server getting,
→catalog: ");
                Serial.println(response);
        } else {
                // If we get a correct response, we must search the sensor
                if (find_text(sensorId, response) >## 0) {
                        // The sensor is in the catalog
                        Serial.println("[setup] The sensor is in the catalog");
                        existsSensor = true;
                } else {
                        // The sensor isn't in the catalog, so we must create it
                        Serial.println("[setup] The sensor isn't in the catalog, so,
→let register it now...");
                        // Create the basic Sentilo Sensor Object
                        SentiloClient::Sensor sensor;
                        sensor.sensor = sensorId;
                        sensor.type = "status";
                        sensor.dataType = "TEXT";
                        sensor.component = componentId;
                        sensor.componentType = "generic";
                        sensor.location = "sensorLat sensorLng";
                        // Call the SentiloClient Register Sensor function
                        statusCode = sentiloClient.registerSensor(sensor, providerId,...
→apiKey, response);
                        // Read the server status response
                        if (statusCode 200) {
                                // If ok, the sensor has been yet created
                                existsSensor = true;
                        } else {
                                // If nok, then we can't continue with the program
                                existsSensor = false;
```

```
Serial.print("[setup] [ERROR] Status code from server...
Serial.println(statusCode);
                               Serial.print("[setup] [ERROR] Response body from_
→server getting catalog: ");
                               Serial.println(response);
                       }
               }
        }
// Auxiliary function for search text in a String
int find_text(String needle, String haystack) {
       int foundpos = -1;
       for (int i = 0; (i < haystack.length() - needle.length()); <math>i++) {
               if (haystack.substring(i, needle.length() + i) needle) {
                       foundpos = i;
                }
       return foundpos;
```

And finally, in the last example, we can see:

- Initialization is the same that in the other examples
- Before ending the initialization process, we search for the sensor in the catalog:
  - Into the setupSentiloSensor() method, the sentiloClient.getCatalog retrieves all the catalog data related to
    the provider, so we can now search for the value of our sensor, in this case, sample-sensor-arduino-03,
    and we see that it doesn't exists in the catalog (you must not create it manually!)
  - Then, create it with **sentiloClient.registerSensor**, including a Sensor object (see values below), if you want to publish its location **don't forget** to initialize the *sensorLat* and *sensorLng* values!
  - Once the sensor is created, we end the setup process and starts the loop
  - If there is any error registering the sensor, the serial prints the error message and the server status code in the console
- In the loop, like in Example 2, retrieve sensors data (LDR and LM35), and publish them as new sensor observation

Next, there is an example of Sensor object message with the example values:

```
SentiloClient::Sensor sensor;
sensor.sensor = "sample-sensor-arduino-03";
sensor.type = "status";
sensor.dataType = "TEXT";
sensor.component = "sample-component";
sensor.componentType = "generic";
sensor.location = "41,385063 2,1734034";
```

And before invoking the Sentilo API Rest platform, the SentiloClient library transforms this object in a JSON message like this:

```
{"sensors":[{
    "sensor":"sample-sensor-arduino-03",
    "description":"",

(continues on next page)
```

8.3. Arduino Tutorial 207

```
"type":"status",
    "dataType":"TEXT",
    "unit":"",
    "component":"sample-component",
    "componentType":"generic",
    "componentDesc":"",
    "location":"41,385063 2,1734034",
    "timeZone":"CET"
}]
```

As you can see, the type is generic and the data type is text, because this is the best way to publish any data without any format problem.

On this page you will find several tutorials about how to connect to Sentilo using various existing platforms and languages.



Java library that allows access to Sentilo Platform through its REST API Client



Independent platform library created with NodeJS that allows embedded architectures, such as Raspberry Pi, to communicate with Sentilo Platform through its REST API Client

208 Chapter 8. Tutorials



A simple Arduino library that allows connect with the Official Ethernet Shield to the Sentilo Platform

8.3. Arduino Tutorial 209

210 Chapter 8. Tutorials

# CHAPTER 9

Technical FAQ

# 9.1 In which platforms has been Sentilo tested?

The first deployment for the Barcelona City Council has the following infrastructure:

- Four virtual machines, two for the front-ends and another two for the back-end
- All of them use as operating system Ubuntu server LTS 18.04
- The real time database server(Redis) works with 32 GB of memory and 36 GB of hard disk
- The other three servers work with 4 GB of memory and 16 GB of hard disk

Another deployment configurations should work properly, always keeping in mind the expected load by the system.

All known Sentilo instances are deployed on Linux servers, mainly CentoOS 6+ and Ubuntu Server 14.04+.

# 9.2 I successfully published an observation, but I cannot see the data in catalog.

Check that the Catalog and Sentilo API Server are in the same timezone, for example in UTC. Make sure the sentiloserver is executed with the following VM option:

-Duser.timezone=UTC

Also, make sure that the Tomcat that hosts the Catalog application has the same option, for example en \$JAVA\_OPTS variable.

# 9.3 Google Maps is not showing up in Catalog application

Recently Google changed it policy regarding Maps key. Please go to https://developers.google.com/maps/documentation/javascript/get-api-key and create one.

You can define the API key inside the /etc/sentilo/sentilo-catalog.conf configuration file:

```
# Google API key to use Google Maps
sentilo.catalog.map.google.key=<your key>
```

Remember you'll have to restart tomcat in order to let sentilo-catalog-web.war reload these changes.

# 9.4 I created a provider and immediately after that, an observation using the new provider's token is rejected with 401 "Invalid credential"

The providers are activated in a background job that runs every 5 minutes. Please wait a moment :-)

Another possible reason is that the Sentilo API server started before the Catalog application (probably deployed on your Tomcat).

At startup, the API server performs a call to:

```
/sentilo-catalog-web/api/entities/permissions
```

in order to mirror the permissions stored in MongoDB with Redis.

If this call fails because the sentilo-catalog-web is not deployed yet, the permissions are not correctly created. To resolve the issue, reboot your Sentilo and ensure that the API server starts always after the sentilo-catalog-web is fully deployed.

# 9.5 The command mvn package appassembler:assemble fails.

You have to execute the command in the directory of the component you want to install.

# 9.6 I think I installed Sentilo. How can I confirm all is up & running?.

You can use this script:

```
./scripts/testServerStatus.sh
```

You also might want to check Platform Testing

If you installed everything on your local machine, you can access the catalog at http://localhost:8080/sentilo-catalog-web and the REST API at http://localhost:8081

# 9.7 How can I activate debug logs?

You can pass the property sentilo.log.level to the JVM. For example, you might add the following code to the script in the **bin** directory of the component you want to debug:

-Dsentilo.log.level=DEBUG

# CHAPTER 10

**Platform Testing** 

To check everything is properly configured and running, you can run the following set of tests.

# 10.1 Infrastructure servers test

# 10.1.1 Status page


To validate that all services are up and running (Redis, MongoDB and PubSub), you can access to the following catalog page:

http://ip:port/sentilo-catalog-web/status/



In this screen you can check the status independently for each Sentilo main service. In each case it will be indicated, through a green status message, the correct operation of the same. In the event either it is not possible to connect to the service or there is an error, an error message will be displayed.

Next screenshot shows to you an error connecting to the API:




# Deactivating the status page

By default, the status page is enabled in your Sentilo instance.

To disable it, you must provide a JVM Tomcat parameter:

```
-Dsentilo.state_page.enabled=false
```

Then, the status page will be inaccessible:



# 10.2 Postman tests

To test the API REST services individually, you can also test end-end functionality with Postman, or if you prefer CLI, via Newsman:

```
newman run postman-script.json -e postman-script-env.json --delay-request 5000 --
→reporters cli, json --reporter-json-export outputfile.json
```

where files postman-script.json and postman-script-env.json are located in subdirectory scripts/test from your local copy of Sentilo.

This script provides tests all Sentilo REST API resources and can serve you also as example of the API usage.

Note: Before executing tests with newman, you should review the values of the variables api\_url, api\_port, provider and provider\_token in the environment file postman-script-env.json so that they match your Sentilo instance

Before executing the postman script / or you should replace default values (extracted from the init\_test\_data.js file) with the ones that you want to use to execute it (api\_url, api\_port, provider and provider\_token)

10.2. Postman tests 217

# Sentilo Official Docker Images

Since version 2.0.0, the official docker images of each of the platform modules have been made available to the community.

These images can be downloaded from the Docker Hub library at: https://hub.docker.com/u/sentilo

From there you'll can pull and create your own Sentilo containers as needed.

# 11.1 Available Sentilo official docker images

- sentilo/agent-activity-monitor
- sentilo/agent-alert
- sentilo/agent-federation
- sentilo/agent-historian
- · sentilo/agent-kafka
- sentilo/agent-location-update
- sentilo/agent-metrics-monitor
- sentilo/agent-relational
- · sentilo/catalog-web
- sentilo/platform-server

# 11.2 Sentilo platform as multi-container Docker applications

Alternatively, a **Docker Compose** image script has been created that creates a basic Sentilo instance with the necessary services to be able to test them from our desired development environment.

You can download the project from: https://github.com/sentilo/docker

Available Sentilo services:

- Sentilo Platform Server (REST API)
- Sentilo Alert Agent
- Sentilo Location Updater Agent
- Sentilo Catalog (web application)

Also available external services (non Sentilo official images):

- Redis
- MongoDB

All the necessary documentation is available at the **README.md** file from the project.

Once all the services have been started, with the proposed default configuration, and with Docker running in our local environment, we can access the platform through the following urls:

- Sentilo Catalog Web Application:
  - URL: http://localhost:8080/sentilo-catalog-web
  - credentials: admin/1234
- Sentilo API Rest endpoint:
  - URL: http://localhost:8081

All your conf files and logs will be available at local directories as data volumes:

- ./logs
- · ./conf